


Online Help MOBOTIX MxManagementCenter 2.4

© 2020 MOBOTIX AG



Beyond **Human Vision**



Table of Contents

Table of Contents	2
What's new in MxMC 2.4?	9
Basics/Introduction	12
MxManagementCenter- Function Overview	12
Camera Feature Overview	13
Working With The Live View	14
Working With the Graphic View	20
Searching And Playing Back In Playback View	22
Exporting Recordings	
Operate Door Stations	42
Checking System Security	45
Working With The Grid View	48
About The MxManagementCenter Online Help	53
Program Structure and Operating Concept	54
Device Bar	57
Camera Bar and Camera Group Bar	61
Alarm Bar And Export Bar	63
MxMC Views	
The Grid View	65
The Graphic View	66
The Live View	66
The Playback View	67
The Grid Playback	68
The Research View	69
The Smart Data View	70
The Components View	70
The Al Camera Apps View	71
The Info View	72
The Wizards & Tools view	73
Configuration: Overview	74

Setup	82
Basic Installation: Overview	82
Adding cameras, devices and sources	83
Adding Cameras	83
Adding devices and sources	92
Setting Up Camera Groups	94
Adding Users	98
Configuring Basic Camera Settings	100
Basic Camera Settings: General Settings	
Basic Camera Settings: Time	107
Basic Camera Settings: Image settings	108
Basic Camera Settings: Recordings	112
Basic Camera Settings: MxActivitySensor	116
Basic Camera Settings: Network	117
Checking System Security	119
Backing Up System Settings	122
Import Existing Project	124
Creating MXU Files for Imports	126
Using The Application	129
Live surveillance	129
Working With The Live View	129
Working With The Grid View	136
Working With the Graphic View	141
Operate Door Stations	143
Working With Multiple Monitors	147
Working In Different Network Environments	150
Alarm Processing	151
Researching in MxMC	156
Searching And Playing Back In Playback View	156
Searching And Playing Back In The Grid Playback	166
Searching And Playing Back In The Research View	
Searching And Playing Back Door Events	
Exporting Recordings	175
Special Search Functions	

Integrating MOBOTIX storage device	193
Management	200
Group Views	200
Door Station Settings	207
Network Environments	213
Camera configuration	214
Cameras And Camera Groups	215
Camera Configuration	219
Multi-Camera Configuration	226
User Management	227
Program Settings	230
Components Settings	244
File Server Settings	245
Smart Data Settings	250
MxThinClient Settings	254
Wizards & Tools	256
Checking System Security	258
Health Check	261
Managing SSL Certificates	262
Door Station Wizard	272
Licensing	276
MxMC Licensing	276
Camera App Licensing	278
System Configuration	285
Configuration: Overview	285
Graphical operation	292
Context Help	294
Temporarily Assign Supervisor Passwords to Functions	
Histogram Bar	
Smart Data Bar	
Export Bar	298

Door Station Events	301
Status Display	301
Highlighted Images	301
Internal Events	302
Refresh	302
Multi-camera Configuration	302
Program Call	304
Live images	304
Alarm Bar	305
List View	306
Event Images	306
Freezing Grid Layout	307
Establishing/Closing Audio Connections	307
Search Results in Tiles	308
Connection Monitoring	308
Cameras of the Camera Group	
Cameras of the Camera Group Adding Cameras, Devices, Clips and Recordings, Creating Groups	310
	310
Adding Cameras, Devices, Clips and Recordings, Creating Groups	310
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed	310
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View	310 310 313 313
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events	310 313 313 313
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode	310310313313313
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings	310313313313313
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings Camera Configuration	310310313313313313313
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings Camera Configuration Post Video Motion Detection	310310313313313315318
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings Camera Configuration Post Video Motion Detection Device Bar	310310313313313315318320
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings Camera Configuration Post Video Motion Detection Device Bar Live Recorder	
Adding Cameras, Devices, Clips and Recordings, Creating Groups Playback Speed Tile View Time Events Edit Mode Bell Settings Camera Configuration Post Video Motion Detection Device Bar Live Recorder Meta Events	310310313313313315318320323324

Camera Sequencer	325
Search Results in Lists	326
Image Correction: PTZ and Display Modes in Recordings	327
Mailbox Settings	328
Highlight Recorded Images	329
Image Settings	329
Alarm Settings	329
Bandwidth	330
Control Elements of the Focus Window	330
Focus Window	331
Save Snapshots	331
Projects and Network Environments	331
Display Focus Window	333
Message Events	333
Forward Playback	333
Camera Group	333
Environment Events	334
Creating Users or Administrators	334
Access and Save the Home View	336
Select View	336
Searching Recordings for a Specific Point in Time	336
Signal Events	337
Setting the Playback Mode	337
Controls of a Camera Group	338
Backward Playback	338
Open Doors	338
Audio Functions of a Camera Group	339
Creating Camera Groups	339
Notification	340

Exporting Recordings	340
Alarm Info Bar	342
Image Correction: PTZ and Display Modes	342
Adjust the Volume	344
Camera Live Images	344
Recording Date/Time	345
Temperature Display	345
Group Sequencer	346
Zoom and Change the Views of Event Images	346
Camera Bar and Camera Group Bar	347
Set Grid Layout	347
Executing Hyperlinks	348
User Management	349
Setting Group Functions	351
Set Reference Time	351
Entering MxThinClient Settings	351
Searching Transaction Data	352
Previous Image	353
Camera Date and Camera Time	353
Switching Lights	354
Undo the Last Change	354
Applying Modified Values	354
General Settings	354
Image Settings	356
Time	359
Expert Settings	360
Save Configurations	360
Resetting to Factory Settings	360
Configuration Bar	360
MxActivitySensor	361

Network	362
Recording	364
Redo the Last Change	366
License Management	366
Edit Network Data	368
Add Cameras	368
Rename a Camera	368
Change the Camera Access Data	368
Next Page	369
Importing *.mxu files	369
Creating MXU Files for Imports	370
Format for Simple Imports	370
Format for Advanced Imports	371
Import MxControlCenter	373
Import MxEasy	373
List View	373
Open and Integrate an Existing Project	373
Previous Page	373
Search Cameras	374
Search Filters	374
Log in User	374
Removing All Cameras and Camera Groups	374
Update Software	374
Tile View	375
Activate Licenses	375

What's new in MxMC 2.4?

SSL certificates for cameras

SSL is the standard technology for securing an Internet connection by encrypting the data sent between a website and a browser (or between two servers). This function allows an administrator to upload or create a SSL certificate to the selected cameras.

See Managing SSL Certificates, p. 262.

New Histogram

The histogram can now be used horizontally in the bottom bar according to its purpose. The functions are the same.

See The Histogram: Graphical Representation Of The Frequency Distribution Of Events, p. 188.

P7 Apps as Smart Data Source

In MxMC2.4 you are able to detect license plates with the P7 Apps from Vaxtor and FF Group as well as faces with the P7 App from Visage.

If a license plate or face is recognized, the user can see the result in a list in the MxMC Smart Data Search View.

See Smart Data Settings, p. 250

Custom color schemes and logo

This setting enables you to adapt MxMC optically to your needs. You user can freely select the primary color of the headers and the font displayed there. You also can add an individual logo.

See Program Settings, p. 230



Basics/Introduction

This chapter provides an overview of the features in MxMC and provides guidance on using the online help. You will also find explanations of the program structure and operating concept of MxMC.

MxManagementCenter- Function Overview

MxManagementCenter is a video management software for setting up and using a complete video surveillance system that offers a variety of features for different tasks and user groups:

Area	Features			
Camera Management	Unlimited number of cameras, definition of hierarchical camera groups, different system environments (e.g., with different network addresses)			
Live Video Surveillance	Display of individual cameras and freely definable grid views (with up to 80 cameras simultaneously), user-defined graphics and info views, automatic camera switching (camera sequencer and group sequencer), multi-monitor support (number of available display devices can be further extended with MxThinClient devices), manual recording of live images (live recorder)			
Alarm Processing	Visual and audible alerting to new events, alarm filtering (specific alarms for specific types of alarms), background monitoring of cameras			
Research, Analysis and Recording Playback	Search and playback for individual cameras in the Playback view, time-synchronized search for several cameras simultaneously (grid playback), special search view with the latest alarm images of selected cameras, research and playback of data directly using the camera or via direct connection to the file server, fast display of the latest alarm images during live display (instant playback), subsequent distortion correction of hemispheric camera images, special search functions (subsequent video motion detection, histogram, Smart Data System)			
Data Export	Export of single or multiple time ranges in the recording at the same time, export of the data by the camera or via direct connection to the file server, export of individual image areas (subsequent PTZ), export at variable frame rates, resolution with and without audio			
Door Station Functions	Bell signaling and live two-way communication, open doors and switch lights, play back mailbox messages			
Security Functions	Definition of users and user rights, supervisor function (dual control), system security check, health check			
Special Pro-	Softbuttons for executing special functions, action logs, remote control			

gram Func- tions	
Program Operation	Fast switching between different views with different functions, fast display of cameras via drag & drop, touchscreen operation supported, various program behavior settings

Camera Feature Overview

MxMC allows MOBOTIX MOVE cameras and third-party cameras providing an ONVIF-compatible interface to be integrated and operated. However, the full range of MxMC features is not available for all camera types. The following table briefly lists the functions that be used with the different camera types.

Function	MOBOTIX Camera	MOBOTIX MOVE Camera	ONVIF Camera
Camera Configuration	yes	no	no
Alarm Processing	yes	no	no
Recording Access	unlimited	only via MOBOTIX NAS	only via MOBOTIX NAS
Recording Playback	unlimited	only forward playback	only forward playback
Export	unlimited	only as MJPEG and H.264 (H.264 with corresponding license)	only as MJPEG and H.264 (H.264 with corresponding license)
Research View	yes	only for marked events	only for marked events
Special Search Functions (post-VM, histogram, Smart Data)	yes	no	no
Check System Security	yes	no	no
PTZ	Camera PTZ	mechanical PTZ	mechanical PTZ
Subsequent Equalization of Hemispherical Images	yes	no	no
Live Recorder	yes	no	no
Camera Groups	unlimited	group functions	group functions
Door Station Functions and Switching Functions	yes	no	no
MxThinClient Devices	yes	no	no
Snapshots	yes	no	no

Working With The Live View

The Live view allows you to control the live images of individual cameras. This also includes switching various functions, e.g, opening doors or switching lights.

Showing Cameras




Fig. 1: Showing cameras

To view a camera, you can use the Device or Camera bar. To do this, either drag and drop the desired camera from the Device bar into the display area or click on the desired camera in the Camera bar. The displayed camera is marked with a yellow bar in the Device bar as well as in the Camera bar.

Customizing Image Settings




Fig. 2: Customizing image settings

Use the **Brightness** and **Contrast** controls to adjust the image display of the displayed camera to the current environment.

Move the corresponding slider upwards or downwards. The new settings are stored automatically for the current camera. The default values can be restored by double-clicking on the corresponding slider.

Note:

Adjusting the image settings does not have any effect on the camera settings. These will not be changed

Performing PTZ Actions




Fig. 3: Performing PTZ actions

Note

On a secondary monitor, a single camera image can only be zoomed with the mouse wheel or panned with the mouse button pressed down. PTZ controls are only available on the MxMC main screen or on the secondary monitor in Grid View.

To better identify objects in an image section, you can zoom the live image and move the resulting image area around (PTZ). To facilitate quick loading of these image sections, several image positions are already pre-configured for loading using the slider ...

The program also shows the 🗂 slider on Dual cameras. Use this slider to show the live images of either the right, the left or both image sensors.

When showing the live images of hemispheric cameras, you can configure different display modes (slider 🔘



Zooming and Moving Image Sections

You can zoom using the slider 🛖 or the mouse wheel. Zooming with the slider takes place only on the computer. This means that only the image section of the current live image is modified.

To see other image sections, you can move the live image using the mouse.

If you want to execute the PTZ actions on the camera, you can also switch to camera PTZ. In this case, the PTZ actions are applied to the camera's live image and also influence the recordings (but only if the camera does not record the full image). To use this feature, click on the slider 🛖 and keep it pressed until it starts flashing. You can now adjust the zoom level as needed. To store the setting, click again on the slider and keep it pressed until the slider stops flashing.

Selecting and Adjusting Image Sections

Selecting Image Sections

To quickly focus on a specific image section, you can use one of the factory default image positions that are predefined in the camera.

- Preview ♠, detail ♠, overview ♠ and point of interest♠
- Top ①, bottom ①, left ②, right

The camera will then move to the selected position. Note that the PTZ actions are executed on the camera and also influence the recordings (only if the camera does not record the full image). Move the M slider to the next position or until you have found a suitable position.

Adjusting Image Sections

You can adjust the pre-defined image positions of the factory default. Select a position and modify it as needed. Keep the slider on this position until it flashes once. The new image section has been stored.

Choosing a Sensor

If you want to show the live images of only the right or the left image sensor, you can move the slider to the right to (left sensor) or further to the right to

Correcting The Distortion Of Hemispherical Images

When showing the live images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. This requires that you enabled **OpenGL** in the settings (Mac: **MxManagementCenter > Settings > General** menu; Windows: **File > Settings > General** menu). In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. The selection of a display mode is always done locally and thus does not influence the camera settings. However, the selection is also applied to the other program views. When selecting a display mode in the live view for a specific camera, this mode is also applied if the camera shows up in the focus window of the Grid view as well as in the live images of the Graphic view. Consequently, the alarm images in the Alarm bar and in the Research view are also shown in the selected display mode.

Selecting The Distortion Correction Mode

- **Full image:** Shows the entire (distorted) full image.
- Normal: Shows a distortion-corrected image and allows executing PTZ actions.
- Panorama: Shows the entire distortion-corrected image (corrected 180° panorama) from the left to the right border. The aspect ratio (width to height) is 8:3.
- **Surround:** This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This mode makes sense for a hemispheric camera that is mounted to the ceiling. It can be customized subsequently using local PTZ.
- Panorama focus: This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.

To select a mode, move the slider **()** to the right until you reach the desired position. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined. For example, if the image in Panorama mode is not centered, you may see a trapezoidal distortion. The panorama correction allows adjusting the skewed (vertical) lines of the image to produce a more naturally-looking image. To do


so, move the slider to the right to sand use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.

Status Display

The Status bar displays different states by means of icons. The status displays always refer to the displayed camera. This gives you an up-to-date overview, e.g., showing you at a glance whether a door has been closed again or is still open.



Fig. 4: Status display



Switching additional devices via hyperlink

Hyperlinks can be used to switch additional devices or to send HTTP requests. When defining hyperlinks, you can select an individual button icon for the hyperlink (there are several pre-defined icons to choose from) or set one button from which to run all hyperlinks.




Fig. 5: Switching additional devices via hyperlink

To define a hyperlink, right-click on and then on .

In case you did not assign an icon for the individual hyperlinks, they will be combined under one button.

To execute such a hyperlink, click on and then on the name of the desired hyperlink.

Manually recording live images

In the Live view as well as in the Grid view, you can start manual recording at any time, such as when you observe a suspicious situation that should be recorded. While you keep track of the situation in the live image, the images are recorded and saved as a MXG file.

Users with administrator rights can specify where the clips are saved and how long the recordings can be in the Program Settings (Mac: menu: MxManagementCenter > Preferences > Live Recorder, Windows menu: File > Settings > Live Recorder).

Notes:

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview. Audio can only be recorded with the Live Recorder under these conditions:

- Audio transmission must be activated on the camera side.
- In the Live View of the MxManagementCenter, the audio connection must be activated by clicking on






Fig. 6: Manually recording live images

Starting And Stopping Recordings

To start recording, click on **Live Recorder**. Recording will stop automatically after the recording time set in the program settings has expired. Just before this time expires, a message will be displayed. You can stop the recording from within this message or extend the set period of time. To stop recording before the time expires, click on again.

Note

If you change the view, the recording is automatically stopped. However, a camera change within the Live view does not stop the recording.

Play Clip

The live image data is stored in a MXG file at the location specified in Program Settings during recording. The clip file is automatically imported into the current project when the recording stops and the Device bar shows it alongside the icon in the **Clips** section. You can click on the clip name to playback the MXG clip file via the Device bar.

Working With the Graphic View

You can define a **floor plan** (ground plan) in the Graphic view and place the cameras or camera groups according to their actual positions. The icon of the corresponding camera turns red in case of an alarm (or

green upon a bell event). A simple click is enough to show the current live image of the triggering camera, allowing you to quickly check the situation.

Temporarily showing the live image of a camera

To temporarily display the live image of a camera, move the mouse pointer over the camera icon. In addition, the live image of another camera group can also be displayed in the Graphic view. Drag & drop the desired camera from the Camera bar onto the floor plan. When changing the view, the live image disappears.

Automatically display all live images of a group

To keep track of all live images in the current group, you can activate the camera sequencer or the group sequencer. When the sequencer is activated, all live images of the camera group are displayed one after another in a small window. You can move this window to any location and enlarge it or make it smaller.

Camera Sequencer

If you want to see a different camera in the focus window, simply drag that camera to the focus window. Note that the camera sequencer can also switch cameras automatically.

Instructions:

- 1. Click on the camera sequencer icon = to activate the automatic switching.
- 2. Right-click on to change the following settings:
 - **Duration Slider:** Move the slider to the desired duration (1 sec to 60 sec) to show each camera.
 - **Autostart:** Once you switch to the Grid view, the sequencer starts automatically.
 - **Stop at event:** The sequencer stops when an event has occurred, allowing you to further investigate the situation. To start again, click on

 ...
 - **Restart after confirmation:** Activate this option if you want to avoid having to restart the sequencer over and over again.

Group Sequencer

If you want to display a different camera group in the focus window, drag and drop that camera group into the focus window. A grid with all cameras of the group will be displayed and each camera of the group will be shown sequentially in the grids focus window for a defined time. You can automate this camera group change with the group sequencer.

Instructions:

- 1. Click on the group sequencer icon
 to activate the group sequencer.
- 2. To change the sequencer settings right-click on:

- **Duration:** set the duration to show each group. You can set a value between 1 sec and 60. The "Combined Sequencer" activates the group sequencer together with the camera sequencer ("Autostart" on the camera sequencer is not needed). The group sequencer waits until all cameras on a grid or graphic have been cycled before switching to the next group. When the "Combined Sequencer" is active then the camera sequencers "Stop at Event" and "Restart after Confirmation" also apply to the group sequencer.
- **Autostart:** Once you switch to the Grid view, the group sequencer will start automatically.

Switching group functions

At the bottom of the program window is a Command bar with controls that change depending on the selected view. In the Graphic view, you can use the group buttons of the Command bar to control the functions of a camera group (Prerequisite: Group functions were assigned in the Group Functions dialog box). This means that you can switch on/off lights, open a door and make an announcement for a predefined camera of this group, regardless of the currently displayed camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors.

In addition, you can right-click on the group buttons to open the shortcut menu in order to control cameras that are not part of the current group. Before you can do this, the cameras have to be set up accordingly, that is, they need to be connected to door openers/light contacts and have to be configured properly.




Fig. 7: Switching group functions

Searching And Playing Back In Playback View

Recorded clips cannot only be played in the player, but they can also be searched. The way that you search depends on whether you want to search for specific events within the recorded clips or whether you want to

search for events at specific times.

General Playback View controls




Fig. 8: General playback view controls

To search and play back recordings, first activate **Playback** mode or select the date and time and then use the **Previous/Next Image** buttons , to browse the recordings; alternatively, you can start the playback using the **Forward/Backward Playback** buttons . Hold the **Forward/Backward Playback** to select a playback speed between 0.5 times and maximum.

MxManagementCenter- Function Overview

General operation of the Playback View for MOBOTIX MOVE and ONVIF cameras



Fig. 9: General operation of the Playback View for MOBOTIX MOVE and ONVIF cameras

Note

all playback capabilities are supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For these cameras, recordings can only be played forward.

Therefore, first select Date/Time \bigcirc , and then start playback using **Forward Playback** \triangleright \bigcirc .

Performing PTZ actions in recordings




Fig. 10: Performing PTZ actions in recordings

Note

On a secondary monitor, a single camera image can only be zoomed with the mouse wheel or panned with the mouse button pressed down. PTZ controls are only available on the MxMC main screen or on the secondary monitor in Grid View.

You can zoom and move the visible image area not only in live images but also in recorded images (PTZ). This enables you to examine specific image areas more closely while the recorded video stream is playing back. On Dual cameras, the program also shows the ____ slider. Use this slider to show the images of either the right, the left or both image sensors. When playing back the recordings of hemispheric cameras, you can set different display modes ____.

Zooming and moving image sections

You can zoom using the slider \bigoplus or the mouse wheel. To see other image areas, you can move the recorded image using the mouse.

Choosing a sensor

On Dual cameras, you can opt to see the recordings of the right, the left or both image sensors. To do so, move the slider to the right to (left sensor) or further to the right to (right sensor).

Subsequent distortion correction of hemispherical images

When showing recorded images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. Note that this type of correction only takes place locally. This means that the distortion correction of the recorded images only takes place on this computer. The stored recordings (from the camera or a file server) are not influenced in any way.

- **Full image:** Shows the entire (distorted) full image.
- **Normal:** Shows a distortion-corrected image and allows executing PTZ actions.
- Panorama: This option shows the distortion-corrected image of an entire room (corrected 180° panorama view) from the left to the right wall. The aspect ratio (width to height) is 8:3.
- Surround: This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This mode only makes sense for a hemispheric camera that is mounted to the ceiling.
- Panorama focus: This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.

Selecting The Distortion Correction Mode

Move the slider on to the right until you see the desired view. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined using the panorama correction. Move the slider to the right to and use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.

Browsing recordings for event images

When searching for event images, first select the image playback type:

- Event images: Only shows event images.
- Pre-event images: Shows only the first recorded image for each event.
- Highlighted images: Shows only the images, which had been marked as important before.

Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.




Fig. 11: Browsing recordings for event images

- 1. In the Playback view, select the Playback mode by right-clicking on ① 1 and selecting the desired mode ②.
- 2. Browse the recordings using the and buttons. Starting with the current event image, these buttons show the previous or next event image.

Browsing recordings for a specific date and time

If you have set up a continuous recording for certain times and you want to check for events during those times, for example, you can limit the search to these times. You can search for events at a given time by using time leaps or time-lapse playback.

Searching for a specific date and time



Fig. 12: Searching for a specific date and time

- 1. Click on Date/Time (1) and enter the date and time to search for.
- 2. The event image jumps to the event in the recordings that is closest to the specified date and time.
- Click on Playback ▷.

or

- 1. Click on the **Calendar** slider ②. The date and time will be shown above the slider.
- 2. Move the slider until you reach the date and time that is closest to the point in time you want to examine. The event image jumps to the event in the recordings with the specified date and time. If such a recording is not available, the event image jumps to the event that is closest to the specified point in time (in the direction of searching). In the latter case, the slider turns read the time difference to the specified point in time is shown above the slider.
- Click on Playback ▷.

Note

The farther away you move the mouse pointer from the slider, the more precise your setting will be.

Searching Several Cameras For Persons Or Objects

Scenario: Camera A is overlooking the gate and signals an event. The event image in the Alarm bar shows a delivery truck driving through the gate. You want to know if the truck has also passed the area monitored by camera B.

- 1. To do so, move the mouse pointer over the event image. Three icons are shown.
- 2. Open the Playback view mode by clicking on .
- 3. Play back the recording (end of recording) ①.




Fig. 13: Playback the recording

4. Drag&drop camera B from the camera bar into the Playback view.



5. The playback automatically selects the recording that follows the end of camera A's recording ②. You can continue this process for any number of cameras.

Investigating Multiple Cameras For A Specific Point In Time

You want to know if other cameras have recorded something at a specific point in time:




- 1. Set the reference time using the Pin button \bigcirc .
- 2. Drag the cameras from the Camera bar ② one by one.

3. The application shows the event images of each camera that are closest to the specified point in time.

Limiting The Search Range For An Incident

Scenario: Your camera monitors a parking lot from which a car had been stolen during the day. Follow these steps to locate the event as quickly as possible:


- 1. Start the Playback mode (right-click on) and select an interval (e.g., 1 day).
- 2. Keep clicking on **Previous Image** until the car can be seen again in the image.



- 4. Keep clicking on **Next Image** ⋈ until the car has left the frame.
- 5. Keep on using shorter intervals until you have found the exact point in time of the incident.

Note

You can also use the **Forward/Backward Playback** / D buttons to play back using the same time leaps.



Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.


Playing Back Recordings

Playing Clips

To play the clips, the play buttons $\triangleleft \bigcirc \triangleright \triangleright \bowtie$ and the playback mode are available in the Command bar of the Playback view. First set the desired mode for playing the recordings, such as event images only or with one hour time-lapse, in the **Playback mode**.

Next, use the **Playback Buttons** to browse and play back the images one-by-one or continuously in backward or forward direction.

Note: As mentioned in General Operation Of The Playback View For MOBOTIX MOVE And ONVIF Cameras, playback of recordings is limited when using MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. Recordings of these cameras can only be played forward. For an overview of how the camera functions differ, see Camera Feature Overview.




The following table summarizes the actions that you can perform with the playback buttons, depending on the playback mode:

	Playback Mode		Playback Buttons	
© Complete ings	Complete Record-	\bowtie	Jumps one image backward/forward.	
	ings	$\triangleleft \triangleright$	Plays back all recordings backward/forward.	
\$	Fvent Recording	\bowtie	Jumps to the end/the start of the recorded sequence.	
		$\triangleleft \triangleright$	Plays back until the start/the end of the recorded sequence has been reached.	
5	Event Images	\bowtie	Shows the previous/next image every time you click on the button.	
€57	Pre-alarm Images			
₽ <u>~</u>	Highlighted Images	The previous/next images are shown autonother.	The previous/next images are shown automatically one after the	
(*	1 day time lapse		other.	other.
60 :	1 hour time lapse			
(i):	10 minute time lapse			
(j:	1-minute time lapses			

Setting The Playback Speed

The **Playback Speed** option allows you to speed up or slow down the playback of a recording. This also applies if you play back a recording backward.



- 1. Click on **Playback Speed**. The background of the button turns dark gray.
- 2. To play the recording forward, left-click and hold the left mouse button and move the mouse pointer to the right. The further you move the mouse pointer down (to the right), the faster the playback speed.
- 3. To play the recording backward, left-click and hold the left mouse button and move the mouse pointer to the left. Again, the further you move the mouse pointer down (to the left), the faster the playback speed.

Precise Positioning by Image

Exporting Recordings

Using the Playback view, you can export recorded video data from one camera, while the Grid Playback allows exporting from several cameras at once. Use the Export bar to combine several clips to one export. You can save individual images with the **Snapshot** function.

Saving Snapshot Images

Snapshot images can be created in the Live and the Playback views for the displayed camera, and in the Grid view and Grid Playback for all displayed cameras.




Fig. 14: Saving Snapshot Images

To do so, click on the **Snapshot** button in the Command bar. By default, images are saved in the image folder of the user account. The destination path and the image settings for saved images can be selected via the **MxManagementCenter > Settings > Snapshot Images** (Mac) or **File > Settings > Snapshot Images** (Windows) menu item.

Exporting Camera Recordings

The Playback view allows setting a time range for a recording (event recording or continuous recording) in order to select it for exporting.

- 1. Open the Playback view.
- 2. Drag the desired camera from the Camera bar or the Device bar.
- 3. Find the start of the relevant recording.
- 4. Specify the export range. There are two possibilities for this export:

Select export range using visual markers:

- 1. Mark the start of the clip by clicking on the gray flag on the left .
- 2. Play the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right. Both flags are now green.
- 3. Click on **Export** and select the export profile.




4. The Export dialog box appears. Select a target folder and enter a file name.

Manually capture export range:

First, make sure that no export area has yet been set using the "export flag." If an export area has already been defined, you can delete it. Do so by right-clicking on a flag and selecting **Delete Time Range**.

1. Click on **Export** Then click on the desired export profile ①. The dialog box used for defining the export range appears.



- 2. Specify the export range ②.
- 3. Click on **OK** and then on **Save**.

Note

If you select the **Automatically Import After Export** checkbox in the Export dialog, the exported clip will be automatically added to the Camera bar and in the Device bar to the **Clips & Recordings** section.

Exporting Camera Group Recordings

The Grid Playback allows for setting a time range for a recording (event or continuous recording) in order to select it for exporting from multiple cameras.

- 1. Open the Grid Playback.
- 2. Drag & drop the desired camera group from the Group bar or the Device bar.
- 3. Find the start of the relevant recording for the camera in the focus window. At the same, the search is extended to the other cameras in the group, and the recordings with the closest relevance to those in the focus window recording will be displayed in the tiles.
- 4. Specify the export range. There are two possibilities for this export:

Select export range using visual markers:

- 1. Mark the start of the clip by clicking on the gray flag on the left .
- 2. Play the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right. Both flags are now green.
- 3. Instead of exporting all cameras of this group, you can also select one or more cameras for exporting. To do so, right-click on **Export**. A circle appears on the camera images in the top left corner. Select the desired cameras by clicking on the corresponding circles ①.
- 4. Then click on **Export** and select the export profile ②. The Export dialog box appears.



Fig. 15: Select export range using visual markers

5. Select a target folder and enter a file name.

Manually capture export range:

Make sure that no export area has yet been set using the "export flag." If an export area has already been set, you can delete it. Do so by right-clicking on a flag and selecting **Delete Time Range**.

- 1. Before you define the export range, you can limit the selection if you do not want to export all of the recordings that appear in the tiles. To do so, right-click on **Export** . A circle appears on the tiles in the top left corner. Select the desired cameras by clicking on the corresponding circles ①.
- 2. Click on **Export** and select the export profile ②. The dialog box used for defining the export range appears.



Fig. 16: Manually capture export range

- 3. Specify the export range ③.
- 4. Click on **OK** and then on **Save**.

Note: Automatic Import

If you activate the **Automatically Import After Export** option, the exported clips are automatically added to the Group bar.

Exporting Recordings From The Export Bar

The Export bar provides a quick and easy way to take camera recordings and MXG clips by dragging and dropping and create a list of recordings for subsequent exporting. From the bar, you can export recording time ranges as combined clips. You can add the clips in the Playback view, in Grid Playback, in the Research view and in the Retail view. After an export, the clips are not deleted automatically. It is deleted when the program is closed.

Adding Clips for Exporting in the Playback View

- 1. Drag the desired camera or the desired clip from the camera bar or from the Device bar.
- 2. Find the recording you are interested in.




Fig. 17: Adding Clips for Exporting in the Playback View

- 3. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green ①.
 - You can set the end marker first (gray flag on the right), then play the recording from the beginning so you can set the start marker (gray flag on the left) at the desired point.
- 4. Click on the image of the recording and maintain the position until you see a scaled-down image of the recording ②.
- 5. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there.

Adding Clips for Exporting in Grid Playback

The Export bar in Grid Playback is useful for combining **sequential time ranges** of different cameras.

- 1. Drag the desired camera to the focus window in the grid and find the relevant recording.
- 2. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green.
- 3. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there.

- 4. After you have set the end marker of the time range, the recordings of all other cameras will reposition to show the same time. Drag the camera with the next recording in the sequence of events into the focus window. Mark the start and the end of the clip as described above, then drag the recording into the Export bar.
- 5. Repeat these steps until you have added all recordings you want to export.

You can also add time ranges from several cameras in the Export bar.

- 1. Simply drag the desired camera group from the Group bar or from the Device bar and search for the relevant recording.
- 2. Mark the start and the end of the clip as described above. The recordings of the other cameras will reposition accordingly.
- 3. Right-click on **Export**. A selection box with a checkmark appears in the top left corner of the recordings. If you do not want to add the recording range of a specific camera to the list, uncheck the selection box for that camera.
- 4. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there. The selected clips will be copied to the Export bar.
- 5. Repeat these steps until you have added all time ranges you want to export.

Adding Clips for Exporting in the Research View

In the Research view, you can add recorded event sequences to the list. The length of the event sequences is currently 10 seconds.

- 1. Set filters by camera, by group or by event type as needed.
- 2. Right-click on **Export**. A selection box appears on the event images in the top left corner. Select the desired events by clicking on the corresponding selection boxes.
- 4. If needed, you can set new filters and add more event images to the Export bar.

Adding Clips for Exporting in the Smart Data View

You can add clips for the individual Smart Data transactions to the Export bar. The default clip length is ten seconds on either side of the transaction time stamp, that is, for a total of 20 seconds.

1. Right-click on **Export** . A selection box appears on the preview images in the top left corner. Select the desired transactions by clicking on the corresponding selection boxes.


2. Open the Export bar by clicking on the lower frame border of the open Alarm bar. Click on an preview image and maintain the position until you see a scaled-down preview image. Drag this image to the Export bar. The clips of all selected preview images are added to the Export bar. An alternative option is: In the Export bar, click on ____. The clips of all selected preview images are added to the Export bar.

You can also add clips for the individual preview images of the selected transaction to the Export bar:

1. Drag the transaction preview image in the **Preview Image** section and drop it on the Export bar.

Editing Clips


If you have added a recording to the Export bar for which you previously used distortion correction or zoom features during playback, you can choose to export the clip with or without zoom. Likewise, you can export the clip with or without audio. To do so, move the mouse pointer over the recording in the Export bar. Three icons appear:



- Clip is exported with zoom.

 Click on to export the clip without zoom. The icon is disabled.
- D: Note that you can play back the individual clips directly in the Export bar before exporting. Click on to do so.

Right-click on a clip to open a context menu with these functions: Manually adjust time range, activate/deactivate audio and zoom for all clips, duplicate a clip, delete one or all clips.



Exporting Clips

Click on **Export**; then select MOBOTIX to export an MXG clip. Select a different profile to create an AVI, MP4 or MKV file. However, depending on the data source (e.g. MOBOTIX NAS) not all export profiles are available.

Select a destination path in the Export dialog and enter a file name. Activate the **Automatically Import After Export** checkbox in the file selection dialog to automatically add the MXG clips to the Export bar after exporting.

Operate Door Stations

Door Stations can also be integrated and operated with the MxManagementCenter. For this purpose, Door Station-specific functions are provided in addition to the program functions for cameras.

Note

Door Station functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see:


- Camera Feature Overview, p. 13.
- Door Station Settings, p. 207

Bell Signaling

If someone rings the doorbell, it can be indicated in different places of the application.

Where? Explanation

Alarm bar and Alarm Info bar A bell event is indicated by coloring the Alarm and Alarm info bar green. The prerequisite for this is that the Door Station bell events have been configured as alarms in the **Camera Configuration** dialog. The Alarm bar ① is located at the bottom of the MxManagementCenter and the Alarm Info bar ② below the camera image of the corresponding door camera.



Where? Explanation

Doorbell notification

When the bell is rung, a ringing notification is displayed, no matter which view you are in. The prerequisite for this is that the Door Station bell events were configured as alarms in the **Cam**-

era Configuration dialog and that the **Notification** was not deactivated in the header.



Note


The notification can be temporarily disabled by an administrator by clicking on **Notification**



in the application header.

Counter on The counter next to the bell icon in the Live view is increased by one. the bell

icon



Setting Bell Signaling

Go to Door Station Settings, p. 207 to find out which signaling options can be combined and where they can be configured.

Open Door and Switch Lights

If the door camera has been set up properly, you can use MxMC to open the door and to switch the lights. To do this, use the and keys in the Live view Command bar and in the Command bar of the Grid view focus box.

Checking System Security


After completing the basic configuration of the system, you can check its security. The **Wizards & Tools, p. 256** view offers the **Secure System** wizard. It analyzes the security of the cameras and assesses their status based on common best practices. If test criteria are not met, possible measures to protect the cameras are provided.

Note

The system security check feature is not available for MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Verifying Settings for System Security

1. To open the **Wizards & Tools** view, right-click on the navigation key in the Command bar. Select the **Wizards & Extras** view.



2. Select the desired camera or camera group in the Device bar or the Camera/Group bar.



- 3. Click **Secure System**. The following criteria are checked:
 - Usage of the "meinsm" password with standard or ONVIF user accounts on MOBOTIX cameras. It is easy for cyber attackers to guess the standard "meinsm" password.
 - Enabled **Public Access**: If Public Access is enabled, a number of different camera functions can be used without a password.
 - Activated HTTP web server: It is possible for data, including user data such as passwords and images, to be transmitted via the network without encryption when HTTP is used.

The result of the check is displayed for each camera in the **Secure System** dialog. It will also show all cases in which cameras were not checked due to a connection error, for example.

Status	Explanation
⊗ Not secured	There was at least one criterion that was listed as not secure.
C Software too old	Please check the camera software and update it, if necessary.
O Connection error	Check your network connection to the camera and perform the security check again.
Not supported	The camera (s) cannot be analyzed or secured using the wizard.
	Camera is secure; no further action is necessary.

Secure System

4. In the **Secure System** dialog, click on **Next**. Cameras resulting in a **Not secure** status are displayed together with whichever of the three criteria that were fulfilled as well as the measures that need to be taken to properly secure the cameras:

Criterion	Explanation
Password	Changes the password of all user accounts on the cameras that use the standard "meinsm" password. It also include ONVIF users whose passwords have never been changed. Enter a new password and confirm it. A suitable password has at least eight characters. It can consist of lowercase and uppercase letters, digits and special characters (see). If you set a password that does not meet these criteria, a red frame appears around the text field. The frame turns green once you have entered a valid password. The new password is automatically entered in the MxMC project data.
SSL encryption	Disables camera connections via unencrypted HTTP and configures the cameras to accept HTTPs connections only. The TCP port and the SSL setting will be automatically updated in the MxMC project data, if necessary. The TCP port will not be updated for cameras that are connected via a remote URL. For remote URL connections, you may need to change port forwarding in the router to the appropriate setting. Please note that different services, such as network messaging etc., will no longer work when you disable HTTP.
Public Access	Disables access that does not require password entry to the web interface and the APIs of the cameras.

5. Click on **OK** in the dialog box. The selected security measures will be performed. The security status for the selected camera or camera group will be analyzed once again and the result for each camera is displayed.

Working With The Grid View

The Grid view consists of a grid of live images and one focus window. This grid (tile) structure is ideal for getting a quick overview of **all cameras of a group**. You can drag the camera image that is most interesting to you onto the focus window. Use the controls at the bottom to operate the camera.

Showing a group

To view another group, you can use the Device bar or the Group bar. To do this, either drag and drop the desired group from the Device bar into the display area or click on the desired group in the Group bar. The displayed group is indicated by a yellow bar in the Device bar as well as in the Group bar.



Fig. 18: Showing a group

Working With The Focus Window

At the bottom of the focus window is a Command bar with controls that allow you to operate the **camera in the focus window**. If you move the mouse pointer over the Command bar, further controls are displayed.



Fig. 19: Camera in a focus window

Zooming And Moving Image Sections

Use the slider • to zoom. The zoomed image sections can then be moved with the mouse. These actions take place in the application. This means that only the image section of the current live image is modified.

The camera will not move and therefore zooming will not affect the possible recording of the generated camera image.

- 1. Drag the slider to zoom in on or out of the live image.
- 2. Move the image with the mouse to focus on individual image sections.

Select predefined image sections.

To quickly focus on a specific image section, you can use one of the factory default image positions that are predefined in the camera.

- Overview
 on, point of interest
 on, preview
 and detail view
 on
- Top ①, bottom ①, left ②, right ③

Move the slider **Standard** to the next position or until you have found a suitable position.

Accept and end calls.

To talk to visitors at the door, click on . To end an audio connection, click on ...

Opening Doors And Switching Lights

If a camera is connected to a door station and has been configured accordingly, you can open the door by clicking on . If the camera is also connected to a light switch and configured accordingly, the light can be turned on and off by clicking on .

Show Temperature

MOBOTIX cameras have a built-in temperature sensor that measures the temperature inside the housing. If an ExtIO module or an MX-GPS-Box is connected to the camera, you can also measure the ambient temperature of the module or the box and view it by clicking on $\[Bar{a}\]$.

Executing Hyperlinks

If hyperlinks have been defined and configured, their function can be executed by clicking on \mathscr{S} .

Camera Sequencer

If you want to see a different camera in the focus window, simply drag that camera to the focus window. Note that the camera sequencer can also switch cameras automatically.

Instructions:

- 1. Click on the camera sequencer icon = to activate the automatic switching.
- 2. Right-click on 🔁 to change the following settings:
 - **Duration Slider:** Move the slider to the desired duration (1 sec to 60 sec) to show each camera.
 - Autostart: Once you switch to the Grid view, the sequencer starts automatically.
 - **Stop at event:** The sequencer stops when an event has occurred, allowing you to further investigate the situation. To start again, click on

 ...
 - **Restart after confirmation:** Activate this option if you want to avoid having to restart the sequencer over and over again.

Group Sequencer

If you want to display a different camera group in the focus window, drag and drop that camera group into the focus window. A grid with all cameras of the group will be displayed and each camera of the group will be shown sequentially in the grids focus window for a defined time. You can automate this camera group change with the group sequencer.

Instructions:

- 2. To change the sequencer settings right-click on:
 - **Duration:** set the duration to show each group. You can set a value between 1 sec and 60. The "Combined Sequencer" activates the group sequencer together with the camera sequencer ("Autostart" on the camera sequencer is not needed). The group sequencer waits until all cameras on a grid or graphic have been cycled before switching to the next group. When the "Combined Sequencer" is active then the camera sequencers "Stop at Event" and "Restart after Confirmation" also apply to the group sequencer.
 - **Autostart:** Once you switch to the Grid view, the group sequencer will start automatically.

Switching group functions

At the bottom of the program window is a Command bar with controls that change depending on the selected view. In the Grid view, you can use the group buttons of the Command bar to control the functions of a camera group (Prerequisite: Group functions were assigned in the Group Functions dialog box). This means that you can switch on/off lights, open a door and make an announcement for a predefined camera of this group, regardless of the currently displayed camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors.

In addition, you can right-click on the group buttons to open the shortcut menu in order to control cameras that are not part of the current group. Before you can do this, the cameras have to be set up accordingly, that is, they need to be connected to door openers/light contacts and have to be configured properly.




Fig. 20: Switching group functions

Manually recording live images

In the Grid view as well as in the Live view, you can start manual recording at any time, such as when you observe a suspicious situation that should be recorded. While you keep track of the situation in the live image, the images are recorded and saved as an MXG file. The camera's live image that is in the focus window is always recorded. For this reason, live recording can also only be used in the Grid view when there is a focus window.

Users with administrator rights can specify where the clips are saved and how long the recordings can be in the Program Settings, p. 230 (Mac: menu: MxManagementCenter > Preferences > Live Recorder, Windows menu: File > Settings > Live Recorder).

Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.




Fig. 21: Manually recording live images

Starting And Stopping Recordings

To start recording, click on **Live Recorder**. Recording will stop automatically after the recording time set in the program settings has expired. Just before this time expires, a message will be displayed. You can stop the recording from within this message or extend the set period of time. To stop recording before the time expires, click on again.

Note

The recording ends automatically when switching to another view. However, changing the group within the Grid view will not result in an early termination of the recording, unless that group has no focus window. In the latter case, the recording will end.

Play Clip

The live image data is stored in an MXG file at the location specified in Program Settings during recording. The clip file is automatically imported into the current project when the recording stops and the Device bar shows it alongside the icon in the **Clips** section. You can click on the clip name to playback the *MXG clip file via the Device bar.

About The MxManagementCenter Online Help

The online help introduces you to the **concept** and **features** of MxMC and helps you with any questions or issues that may arise while working with MxMC. The online help generally refers to the full range of functions

of the application, even if individual functions may not be available to all users. The online help is divided into various sections, so that both users and system administrators can find help on the topics that are relevant to them. The help texts can be called up via keyword search or by navigating the table of contents. In addition to the online help, the application also offers **local help**. You can access it by clicking on the question mark icon in the application's header. These help texts give you a short explanation of the respective function or field. If additional explanation is needed, further links are displayed in the online help.

Controls in the help pages

The help pages use the following controls:

Controls	Explanation
▶ ▼	Show and hide text
Q	Call up the search function (keyword search)
=	Show and hide the table of contents
MOBOTIX	Open the start page

Opening the Online Help

The online help can be accessed directly from the application. Do so by clicking on **Help** in the Menu bar.

You can access the local help by clicking on the question mark icon in the application's header. You can download the Online Help from the Download Center on the MOBOTIX website.

Support

Installation instructions are not included in this documentation. Please refer to the software download information available from the MOBOTIX website Download Center at Software Downloads: MxManagementCenter. For technical questions, please contact our support. See MOBOTIX Support for more information.

Program Structure and Operating Concept

Program Structure

MxManagementCenter provides functions for different user groups:

System administrators (installers):

This user group uses MxMC to build and configure a monitoring system that consists of the application itself, cameras, recorders and other components.

End users:

These use the application for their monitoring tasks, such as live video surveillance, searches in and playback of recordings, video exports etc.

Despite these different tasks performed by the two user groups, the program structure and operating concept are largely the same.

Operating Concept

Program window

There are multiple views that allow the user groups to complete their tasks. These consist of a **Menu bar**, a main area in which most of the task is executed, four **bars** that can be opened and closed, a **Header bar** at the top and a **Command bar** at the bottom of the program window.

The bars, consisting of a Device Bar, p. 57, a Camera Bar and Camera Group Bar, p. 61 and an Alarm Bar And Export Bar, p. 63, contain features for working with MxMC on a daily basis. The fourth bar contains the The Histogram: Graphical Representation Of The Frequency Distribution Of Events, p. 188 or the Smart Data-System, p. 190, which allows users to perform specific actions. In the Configuration view, this fourth bar also contains the Configuration bar. The Configuring Basic Camera Settings, p. 100 provides functions for changing the settings of multiple cameras in a group without having to change the camera or camera group. The Command bar at the bottom contains the icons and buttons relevant to the current view. The contents of the Header bar as well as the Menu bar are the same for all views.

Note

If the Menu bar is not visible under Windows, it can be displayed by pressing the Alt key.



Fig. 22: Program window

MxMC can be operated on Working With Multiple Monitors, p. 147. Double-click on a live image, for instance, to display it on a second monitor. If several monitors are connected, they are recognized and can be selected as required.

Controls and Buttons

Icons, sliders and buttons are available for working with the views.

Elements	Examples	Explanation
Icons	- -	Icons are mainly used in the Graphic view. They are either assigned predefined functions or can be freely defined (hyperlinks). Icons can be freely placed in the Graphic view. Clicking on these buttons directly performs a function, for example, open a door. Icons used to control camera functions indicate their status, if available, such as "Door is locked" at the door icon of a Door Station.
Buttons		Buttons appear in many places in the application, including the Command bar or Header bar. Similar to the icons, clicking on the button performs a function directly. Buttons with a small white triangle at the bottom of the button indicate shortcut menus that provide additional options. The shortcut menus can be opened by right-clicking, long-clicking or clicking on the triangle.
Slider		Sliders are also used in many places for operation. Clicking & dragging a slider performs actions, such as scrolling through the last records. Available setting options can be listed and selected by clicking on the slider.

The name of the controls and buttons is displayed by moving the mouse pointer over it. Explanations with links to quick help are displayed when clicking the question mark icon ? in the Header bar.

Note

In some places in MxMC, multiple cameras can be selected at once. Do so by using **CMD + click** (Mac) or **CTRL + click** (Windows).

Device Bar



Fig. 23: Device Bar

The Device bar at the **left margin** of the MxManagementCenter is the central place for creating camera groups and for adding and grouping cameras and clips. Its tree structure design provides a quick overview of the contents and the composition of the individual projects by allowing you to open and close the individual branches and view the hierarchical structure.

Adding Cameras, Creating Groups and Importing Clips

- 1. Open the edit mode at the bottom of the Device bar by clicking on 🛅.
- 2. Next, click on +. The Adding devices and sources, p. 92 dialog opens.

Adding Cameras to a Camera Group

- 1. Open the edit mode at the bottom of the Device bar by clicking on \Box .
- 2. Drag & drop the desired camera from the **Cameras** section to the appropriate group in the **Camera Group** section.

Note

If you have assigned a camera to one group, you can copy this assignment to other groups by dragging the assignment from the first group to other groups.

3. Once you have assigned the cameras to the desired groups, you can deactivate the edit mode by clicking on .

Setting Group Functions

- 1. Open the edit mode at the bottom of the Device bar by clicking on 🙃.
- 2. To do so, move the mouse pointer over the group name. Three icons appear. Click on ...
- 3. The **Group Functions** dialog opens.
- 4. Assign the desired functions to the cameras by activating the respective checkboxes.

Deleting Cameras, Removing Cameras from Groups, Deleting Groups

Deleting Cameras

- 1. Open the edit mode at the bottom of the Device bar by clicking on 📋 .
- 2. Drag the camera from the **Cameras** section to $\overline{\mathbf{m}}$.
- 3. Once you have deleted the cameras, you can deactivate the edit mode by clicking on ...

Note

Deleting a camera from the **Cameras** section will also delete the group assignments of that camera.

Removing Cameras from Groups

- 1. Open the edit mode at the bottom of the Device bar by clicking on 🛅.
- 3. Once you have deleted the cameras from the groups, you can deactivate the edit mode by clicking on

Deleting Groups

- 1. Open the edit mode at the bottom of the Device bar by clicking on 🙃.
- 2. Drag the camera group from the **Camera Groups** section to $\overline{\mathbf{w}}$.
- 3. Next, activate the edit mode by clicking on 🗊

Working With the Device Bar

Configure Screen

Various features support the customization of the Device bar or the arrangement of items in the Device bar.

Feature	Explanation
Opening/Closing Sections	Click on to close a section, click on to open it again.
Moving Sections	If you move the mouse over the upper part of the section, the 🛊 icon appears and the
‡	mouse pointer changes to the Move cursor. You can now click and drag the section up or down.
Setting Display Options	You can select how the cameras are listed, i.e., by camera name, IP address, factory IP address or reference image. Note that you can set different display options for the Cameras and Camera Groups sections. For clips, you can choose to list the clips by name or by path.
	Click on and select the desired display option.
Sorting The Cameras ↑↓	The Cameras section allows sorting the list. Click on and select the desired sorting mode.

Editing Project Data

Set favorites for display in the Camera/Group bar and change the names of cameras and groups.

Special Feature	Explanation
Selecting Favorites from Cameras and Groups ☆	You can filter the displayed cameras in the Camera Bar and Camera Group Bar, p. 61 using different filter criteria (by favorites, for example). Before you can use favorites, however, you need to label the desired cameras and groups in the device bar as favorites. Activate the Edit mode by clicking on . Move the mouse pointer over the camera or group name. Several icons are shown. Click on . Next, deactivate the edit mode by clicking on
Editing Names	Using the device bar, you can quickly modify the names of cameras and groups. Activate the Edit mode by clicking . Click on the camera or group name you want to change – it will turn yellow. Click again on the name and edit it as needed. Deactivate the edit mode by clicking on .

Navigation: Targeted Selection of Views

Special Feature Explanation

Selecting Views

The Device bar allows for selecting a specific view for a group of cameras or one camera. Move the mouse pointer over the camera or group name. Different icons will appear depending on whether you have moved the mouse over a camera or a group name. Click on the icon of the view you want to use.

Camera views

- Live view
- Playback view
- Research view

Group views

- **Grid view**
- Graphic view
- 🔐 Grid Playback
- further views (Research view, Info view)

Overview of the Different Camera Statuses

An icon next to the camera name or the camera IP address indicates the current status of the camera.

Icon Explanation

- Camera is not active.
- Camera is not reachable.
- Wrong camera password.
- Privacy mode is active.
- Limited functionality (only live image access) due to old firmware (<4.0), old camera model (M/D/V12, M/D/Q22M) or proxy issue.
- Camera password does not grant administrative access.
- No license for this camera.

Camera Bar and Camera Group Bar




Fig. 24: The camera- and camera group bar

The Group or Camera bar at the **upper margin** of MxManagementCenter provides the means for quickly selecting individual cameras/camera groups or for switching views.

In addition, icons in the camera images of the camera bar indicate the current status of the corresponding

The height of the bar and thus the size of the images can be increased to cover two lines. To do this, pull down the lower frame border until it locks into place.

Camera Bar

The Camera bar displays the cameras with the image that was transferred from the camera when the camera was added. The camera name that was captured when the camera was added is shown in the gray Info bar at the bottom of the camera image.

Sorting the Cameras

By default, the cameras are displayed according to the order in which they were added to the Device bar. In order to make it easier to locate single cameras, you can change this order and sort the cameras. Do so by moving the slider and on the lower frame border to the desired position:

- unchanged order
- abc alphabetical sorting
- P sorted by IP address

Showing Camera States

The following camera states can be displayed in the camera image:

- Camera is not active
- Camera is not reachable.
- Wrong camera password
- Privacy mode is active
- ☐ Limited functionality (only live image access) due to old firmware (<4.0), old camera model (M/D/V12, M/D/Q22M) or proxy issue.
- Camera password does not grant administrator rights.

Selecting Cameras

Select the desired camera either with a single click or drag and drop the camera into the display area. The Info bar of the selected camera turns yellow.

Switching To The Group Or Camera Bar

By clicking on the top frame border of the bar, you can switch from the Camera bar with individual cameras to the Group bar for managing camera groups.

Group or Camera Bar

The Group bar displays the camera groups with the reference image or icon configured in the camera management section (see Setting Up Camera Groups, p. 94). The name that was entered when creating the camera group is shown at the bottom of the reference image or icon.

Sorting The Camera Group Display

The camera groups are displayed according to the order in which they were added to the Device bar. You can change this order and sort the camera groups alphabetically.

To do this, move the slider 🖨 on the lower frame border until the slider indicates alphabetical sorting: 🐽.




Select a camera group

Click on the desired camera group. The Info bar of the selected camera group turns yellow.

Switching To The Camera Bar

Click on the **upper** frame border of the bar to change from the Group bar with camera groups to the Camera bar for managing individual cameras.

Alarm Bar And Export Bar



The bar at the **bottom** of the MxManagementCenter contains the Alarm and Export bar. The Alarm bar turns red when there is an unacknowledged alarm event. This happens only if the **Alarms** option has been activated in the Camera Configuration dialog box and if the event types responsible for triggering an alarm have been activated.

Clicking on the bottom frame border of the open Alarm bar will take you from the Alarm bar to the Export bar. Using drag & drop, the Export bar provides a quick and easy way to collect recordings for subsequent exporting.

Alarm Bar

Recognizing and Acknowledging New Alarms

If the bar is hidden, new alerts will be indicated by a red frame border . If the bar is open, the Info bar of the event image turns red. A ringing at the door bell will color the bar in green .

To acknowledge a new alarm, right-click on the event image and select **Confirm**. To acknowledge all new alarms at once, select **Confirm All**.

Filtering the Display of Alarm Images

The alarm images in the Alarm bar are sorted chronologically. You can filter the event images by camera, by group or by event type. There are two sliders for this purpose: the **group/camera slider** and the **event type slider**. To set the filter, move the sliders until you see the desired results:

- Group/Camera: Group 🚳 , camera 🔕
- Event Type: All , MxActivitySensor , Video Motion Sensor , Behavioral Detection , Shock Detector , Illumination , Microphone , PIR Sensor , Temperature , Internal Events , MxMessageSystem , Meta Events , Signal Input Events , Time Events , Bell Events , Voice Mailbox Messages , Door Station Events , RFID Rejected , PIN Rejected .

Playing Back Recordings

- You can play back the recording associated with an alarm directly from the Alarm bar (instant playback). To do so, move the mouse pointer over the alarm image. Three icons appear. Click on ...
- To play back the alarm in the Playback view, move the mouse pointer over the alarm image. Click on to switch to the Playback view.

Deactivating Alarms

You can use the Camera Configuration dialog box or the Alarm bar to deactivate alarms.

- Deactivating alarms for a specific camera and event type:
 Right-click on the desired alarm image and select **Deactivate As Alarm**.
- Disable alarms for all event types of a camera:
 Right-click on an alarm image and select **Deactivate All Alarms of This Camera**.

Export Bar

The Export bar can be opened in all views, and clips that have already been added can be edited in the bar. To do so, right-click on a clip. A shortcut menu with the following functions opens:

- ► ◀ ⊘: Manually adjusting the time range
- ☐ ☐: Turning audio and PTZ on or off for all clips
- Duplicating a clip
- 🖶 Deleting one or all clips

You can add the clips to be exported in the Playback view, in Grid Playback and in the Research view. Note that the Export bar will not be deleted automatically after exporting, but only when closing the application.

MxMC Views

The basic structure of the views is always the same. Each view, however, contains additional elements corresponding to the respective functional area. The following views are available:

- The Grid View, p. 65
- The Graphic View, p. 66
- The Live View, p. 66
- The Playback View, p. 67
- The Grid Playback, p. 68
- The Research View, p. 69
- The Smart Data View, p. 70
- The Components View, p. 70
- The Al Camera Apps View, p. 71
- The Info View, p. 72
- The Wizards & Tools view, p. 73
- Configuration: Overview, p. 285

The Grid View

The Grid view consists of a **grid** of live images and a **focus window**. This grid display is ideal for getting a quick overview of all cameras of a group. You can drag the camera image that is most interesting to you onto the focus window. Use the controls at the bottom to operate the camera.

You will always notice when a camera registers an event, regardless of whether or not the camera is in the current group. The alarm info bar at the bottom of the camera's live image signals an event within the group. The alarm info bar at the bottom of the Grid view shows the events of all attached cameras. To investigate the event, simply drag the live image from the Grid view, or the event image from the alarm bar, into the focus window.



Fig. 25: The Grid View

The Graphic View

You can define a floor plan (ground plan) in the Graphic view and place the cameras or camera groups according to their actual positions. The icon of the corresponding camera turns red in case of an alarm (or green upon a bell event). Move the mouse pointer over the camera icon to show the live image of the triggering camera, allowing you to quickly monitor the situation.

You can use the **group buttons** of the Command bar to switch on/off the lights of several cameras at once, to open several doors or to make an announcement over several speakers for one or more cameras of the group, regardless of the displayed camera. In addition, you can right-click on the group buttons and open the shortcut menu to control cameras that are not part of the current group.

To make work easier, you can drag elements from the Command bar onto the floor plan and operate them directly in the floor plan by clicking on them.

In case you want to monitor the live images of cameras of other camera groups in the Graphic view, you can temporarily drag these

live images onto the floor plan.



Fig. 26: The Graphic View

The Live View

The Live view allows you to control the live images of **individual** cameras. This includes switching various functions, e.g., opening doors or switching lights.

In order to better recognize objects in an image area, the live image in the Live view can be zoomed and image areas can be moved (PTZ). To facilitate quick loading of these image sections, several image positions are already configured for loading using the slider 🗥 in the Live view. On Dual cameras, the program also shows the figure of slider. Use this slider to show the live images of either the right, the left or both image sensors.

When showing the live images of hemispheric cameras, you can select different display modes (slider **(a)**).

You can also make settings for the Door Station cameras in the Live view (e.g., voice mailbox announcements).



Fig. 27: The Live View

The Playback View

The Playback view provides a quick and easy way to search for recordings and play back found sequences. There are various options available. The way that you search depends on whether you want to search the recordings for specific events, or if you want to search for events at specific times.

When searching **for events**, select a suitable playback mode (e.g. event images only) and start playback | (backward or forward) or use the | (previous/next image) buttons to jump through the sequences. When looking for incidents at specific **points in time**, you can search for a specific time or you can perform a search using "time leaps" and time-lapse playback. Furthermore, it is possible to play back any date and time and store that point in time so that the recordings of other cameras can be quickly searched for events at that time.

The recordings can be played back forward or backward at different speeds, which makes it easier to search for individual events.

MxMC Views

Fig. 28: Playback View

The Grid Playback

If a camera registers an event and you want to know if and what other cameras in that camera group were recording at that time, you can use Grid Playback to view the recordings of multiple cameras synchronously. The camera in the focus window is the lead camera. So, if you are browsing the recordings on this camera to find events or specific situations or if you are playing back recordings, the other cameras will follow the leading camera as soon as playback is paused. The program always shows the event images that are closest to the time stamp of the leading camera. If the time of the other cameras differs from the leading camera, the difference will be displayed at the lower border of the event images.



Fig. 29: The Grid Playback

The Research View

Use the Research view to search all recorded event images at once. You can filter the results by event type, that is, by bell events or by motion events to get a quick overview. Or you can reduce the results to the event you have marked as "important" in the Playback view. The search results are displayed as preview images with camera name, times tamp and type of event trigger. Note that you can play back the recording for an event directly from the event image (**Instant Playback**). Double-click on the event image to open the Playback view and to start playing back the recording. Recorded clips can be assembled in MxMC in the export list for export.



Fig. 30: The Research View

The Smart Data View

With the MOBOTIX Smart Data System, transaction data, for example from POS systems, can be linked to the video recordings of transactions in MxMC. This enables conspicuous activities to be found and checked quickly. The Smart Data Bar and the Smart Data View are available for searching and analyzing transactions. In the Smart Data View, you can perform a detailed search. Advanced search options and complete video documentation assist you in maintaining a comprehensive overview of, for example, POS systems, video-based license plate recognition or access control systems.



Fig. 31: The Smart Data View

The Components View

In the Component View, you can manage the following components:

- **File Servers** that are used to store video recordings.
- **Smart Data Sources** (license required) from which you can read transaction data, e.g. from MOBOTIX P7 Apps (no license required), POS systems or license plate recognition systems.
- MxThinClients, which allow you to display live images from MOBOTIX cameras on a monitor or TV set with HDMI connection.




Fig. 32: The Components View

- ① User Management, p. 227 / Notification, p. 340 / Bandwidth, p. 330
- 2 Header Bar
- 3 Camera Bar and Camera Group Bar, p. 61
- 4 Context Help / Refresh, p. 302 / Network Environments, p. 213 / Connection Monitoring, p. 308
- 5 Smart Data Bar, p. 297
- 6 Histogram Bar, p. 294
- ② Access and Save the Home View, p. 336 / Previous View / Next View / Select View, p. 336
- 8 Device Bar, p. 57
- 9 File Server Settings, p. 245
- 10 Smart Data Settings, p. 250
- 1 MxThinClient Settings, p. 254
- ① Settings Area for File Server Settings, p. 245, Smart Data Settings, p. 250 and MxThinClient Settings, p. 254

The AI Camera Apps View

The AI Camera Apps view you can display the AI Apps Web GUI within MxMC to configure the corresponding AI App or to open the Apps Dashboard for statistical and analytical purposes.




Fig. 33: The AI Camera Apps View

The Info View

You can add an information page to every camera group in order to show special instructions for operating this camera group or instructions for a notification chain in case of an alarm, for example. To show the information in the Info view, you can compile the information and save it in a PDF or JPG file and then load the file in the **Group Management** dialog box.

If you want to show up-to-date information that is presented on a web server, you also do this in the Info view. Simply activate the edit mode and pull the URL into the Info view.



Fig. 34: The Info View

The Wizards & Tools view

The **Wizards & Tools** view is only available to administrators. The options provided by this view can either be executed for individual cameras or camera groups. Select the camera or camera group in the Camera/Group bar or in the Device bar and then execute the desired feature.




Fig. 35: The Wizards & Tools view

- ① User Management, p. 227 / Notification, p. 340 / Bandwidth, p. 330
- 2 Header Bar

- 3 Camera Bar and Camera Group Bar, p. 61
- 4 Context Help / Refresh, p. 302 / Network Environments, p. 213 / Connection Monitoring, p. 308
- 5 Smart Data Bar, p. 297
- 6 Histogram Bar, p. 294
- ① Access and Save the Home View, p. 336 / Previous View / Next View / Select View, p. 336
- 8 Device Bar, p. 57
- Wizards & Tools, p. 256

Configuration: Overview

The Configuration view you to directly access and make settings for MOBOTIXcameras. In general, the view is divided into a **Basic Settings** section and an **Advanced Configuration** section containing **Configuration Groups**.

The controls at the bottom can be used for actions such as storing the changed settings permanently or resetting the parameter values to their factory settings.

The settings are made for one camera at a time. The Configuration bar on the right margin also offers the possibility to change the settings of several cameras of a group simultaneously without having to change the camera or the camera group.

Note

The Configuration view is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Structure of the camera configuration view




Fig. 36: Structure of the camera configuration view

Basic Settings

The Basic Settings ① contain basic configuration settings that are important for the setup of cameras and camera system. The Basic Settings include the following areas:

- General Settings,
- Network,
- Time,
- Image Settings,
- MxActivitySensor and Recording.

The parameters of the respective topic areas are grouped in tabs. For information about each tab, see Configuring Basic Camera Settings, p. 100.






Fig. 37: Basic settings

Advanced Configuration (license required)

The available configuration parameters are thematically grouped in tiles. The Advanced Configuration tiles ② are only visible if the required license key has been installed, otherwise only the basic settings are available. Clicking on a tile opens the topic area and tabs for the associated sub-topics.

Some of the topics contain graphical configuration items, such as those for defining exposure windows or detection areas. For more information on how to operate these configuration items (see Graphical operation, p. 292).

Extensive information on the setting options and parameters of the individual subject areas are currently available only via the help pages of the camera. You can access the camera help table of contents directly from MxMC by pressing **CMD+Shift+H** (Mac) / **CTRL+Shift+H** (Windows).





Fig. 38: Advanced Configuration



Advanced Configuration - Users and Groups

Configuring Advanced Settings

Caution

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!

- 1. Click on the respective tab to open the corresponding topic area.
- 2. Make your settings as required by topic.

Note

Clicking on the relevant topic area in the table opens an information page for the individual topic areas of the Advanced Configuration settings.




Fig. 39: Advanced Configuration - Users and Groups

Applying and saving changed settings

Warning

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!




Fig. 40: Applying and saving changed settings

You can use the controls at the bottom of the view to permanently save changed settings or to reset the parameter values to factory settings, among other things:

Resetting To Factory Settings

Click on to reset all parameters for the current camera tab to the factory settings.

Undo/Redo Last Change

Click on to undo the last change. Click on to redo the change you previously undid.

Apply Changes

You can make changes by pressing Enter or selecting the new value in the Configuration view. The changes made here are not automatically adopted because it could potentially cause problems with the network settings.

When a value is changed, the checkmark in the Command bar turns red, indicating that the change has not been implemented yet. Click to make this change.

Saving Configurations

If parameter values are changed, the **Store Configuration** icon turns red in the Command bar. Initially, changes are always temporarily stored in the camera. To ensure that the current settings are also used after

the next restart, the changes must be saved permanently.

- 1. To do so, click on **Store configuration**. The program opens a system prompt. In the prompt, click on **Store**.
- 2. If you do not want to keep the changes, click on **Discard**. This discards the changes and restores the last permanently saved overall configuration.

Expert Settings

Various sections of the configuration provide additional settings that can be used to change parameters that are not necessary for the daily work with MxMC. Note that these settings have been combined as expert settings in the different sections. Click on to open the expert settings.


Changing Parameter Values For Multiple Cameras In The Configuration Bar

Warning

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!

You can enter parameters for a **single** camera in the Configuration view. You can use the Configuration bar to check which parameter values are available for the other cameras in the group. There you can also change the settings of one or **multiple** cameras in the group without having to switch to a different camera or camera group.

Checking parameter values of other cameras in the group



MxMC Views

Fig. 41: Checking parameter values of other cameras in the group

Example: Check arming for multiple cameras

- 1. Click on the relevant parameter name ①.
- 2. It turns yellow and the Configuration bar shows all values associated with this parameter that were defined for cameras in this group ②.

Changing a value for one camera or for multiple cameras




Fig. 42: Changing a value for one camera or for multiple cameras

Example: Change a value using the Configuration bar

- 1. Click the appropriate parameter name in the Configuration view ①. It turns yellow and the Configuration bar shows all values associated with this parameter for this group ②. The cameras for which this value is set are assigned to the individual values.
- 2. Highlight the desired camera and drag it onto the parameter value you want to set. The destination area turns yellow.
- 3. If the same value is set for several cameras and you want to change this value, click on the parameter selection field in the Configuration bar ③. Then select the desired value.



Setup

Setting up a MxManagementCenter-based video surveillance system can be costly and will usually be done by an administrator / system installer. This section addresses **administrators** and **system installers** and provides an overview of the tasks that must be performed to efficiently set up a system.

However, not all of these tasks are mandatory for a basic installation(See Basic Installation: Overview, p. 82).

Step	Explanation
Adding Cameras, p. 83	Integrate cameras with the Welcome wizard or in the Device bar Set alarm filters Set up recording paths
Setting Up Camera Groups, p. 94	Create camera groups Add cameras to groups Define group functions
Adding Users, p. 98	Create users Assign permissions
Configuring Basic Camera Settings, p. 100	General settings Network Time Image settings MxActivitySensor Recording
Checking System Security, p. 258	Verify system security settings Secure the system
Backing Up System Settings, p. 122	Save the settings made
Import Existing Project, p. 124	Import an MxControlCenter file (INI file) Import an MxEasy file (NDB file)

Basic Installation: Overview

The **Setup** section describes the steps required to set up a system. For a basic installation, however, not all the steps shown are mandatory. The following list gives an overview of the most important steps of a basic installation.

Step	Explanation
Adding Cameras, p. 83	When starting MxMC for the first time, the Welcome Wizard opens and automatically starts searching for MOBOTIX cameras. Cameras in the local network are automatically detected and listed. Cameras can also be added in the Device bar . Cameras that are in the local network
	are Adding devices and sources, p. 92.
Setting Up Camera Groups, p. 94	Create camera groups to group your cameras. By organizing in groups, entire surveillance areas are always recognizable at a glance Assign the cameras to the desired groups. Set the layout for the Grid view and Graphic view.
Adding Users, p. 98	After you have added the cameras and organized them into groups, create the users and any other administrators and set their access permissions.
MxMC Licensing, p. 276	Industry-specific solutions and special functions, such as the integration of cash point systems, are subject to licensing. To be able to use them, the purchased licenses must be activated.
Configuring Basic Camera Settings, p. 100	Make sure that the main arming option has been activated (see Basic Camera Settings: General Settings, p. 105. Synchronize the time (see Basic Camera Settings: Time, p. 107), arm the recording (see Basic Camera Settings: Recordings, p. 112) and specify a recording destination if necessary (see Adding Cameras, p. 83).
Checking System Security, p. 258	After completing the basic configuration of the system, you can check its security.
Backing Up System Settings, p. 122	Finally, you should save your settings. You can save the settings locally as a project file). The Device Backup function can be used to save the settings across the entire system.

Adding cameras, devices and sources

This section describes the necessary steps to add and configure cameras, devices and other sources.

Adding Cameras

The cameras and Door Stations can either be integrated with the Welcome wizard or added to the Device bar. These cameras also include MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF Scompatible interface.

Integrating cameras with the Welcome Wizard

When starting MxMC for the first time, the Welcome wizard opens and automatically starts searching for cameras. The number of found cameras is shown next to the Add button . This number is updated automatically if the number of MOBOTIX cameras on the network has changed (i.e., by connecting new/disconnecting existing cameras).



Fig. 43: Integrating cameras with the Welcome Wizard

1. Click on Add Devices .

All found cameras are displayed either in a list or as tiles. Whether the cameras are displayed in a list or as tiles is determined by clicking on either the

tiles or list button.

- 2. The respective camera status is automatically tested and displayed:
 - S = The camera cannot be interacted with under the found or entered IP address.
 - ☐ = The camera is in a different network than the computer.
 - **5** = The camera firmware is not up to date.
 - ☐ = The camera is password protected.
 - 🚓 = Incorrect user data was entered.
 - = Preview image not available.
- 3. Select the cameras you would like to integrate.
 - If some of the selected cameras are password protected, click on **Change Camera Access** ♀ and enter the user name and password.
 - If some of the selected cameras are not in the correct network, click on **Edit Network Settings**.

 Here you can choose whether the IP address is automatically determined or whether a fixed IP address is used.

- Determining an IP Address Automatically: If your computer automatically gets its IP address from a DHCP server (e.g., DSL router), then it also makes sense to have the system determine the camera's IP address automatically. To do so, enable the Get IP Address Automatically option.
- **Using a Fixed IP Address:** If you have assigned a fixed IP address to your computer, you will probably prefer to assign a fixed IP address to the camera as well. To do so, enter the IP address and the subnet mask.
- 4. Click on **Apply** and wait for the cameras to be reconfigured.

Note

If the icon is displayed instead of the preview image, the camera could not be reconfigured due to incorrect user data. In this case, correct the user data and try again.

- 5. The number of selected cameras is shown near the **Next Page** button. Go to the next page.
- 6. Click on **Done**. The selected cameras are now integrated.

Note: Clicking on **Start New Project** opens the application directly, and you can add the cameras using the Device bar.

Adding cameras via the Device Bar





Fig. 44: Adding cameras via the Device Bar

The first time you start MxMC, the Welcome wizard automatically opens, allowing you to add your cameras and Door Stations. These can also be added using the Device bar. If you prefer to use the Device bar instead of the Welcome wizard, click on **Start New Project** in the dialog. This opens MxMC directly in live view, and the Device bar is open.

- 1. Open the edit mode at the bottom of the Device bar by clicking on

 ...
- 2. Next, click on . The **Add and Import** dialog opens.



■ Madding Cameras In The Local Network

All cameras and Door Stations in the local network can be detected and displayed automatically.

■ Padding Cameras Manually

Cameras outside of the local network (for example, on the Internet) need to be added manually.

Capturing the data of many cameras

The authentication data used by MxMC as well as the environment settings can be changed in one step for many cameras in the **Multi-Camera Configuration** dialog.

- 1. To do this, open the edit mode in the Device bar by clicking on

 ...
- 2. Select the cameras as needed.

Mac: CMD + click, Windows: CTRL + click

3. Right-click on one of the selected cameras. The Multi-Camera Configuration dialog opens (see Multi-Camera Configuration, p. 226).

Setting Alarm Filters

Note

For MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-compatible interface, there is no alarm function available and you can thus neither activate background monitoring nor set alarm filters. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Events that lead to an alarm will change the background color of the Alarm bar, Alarm Info bar (see Alarm Bar And Export Bar, p. 63 and Alarm Processing, p. 151) and other UI items to red. You can set the event types that trigger a signal for specific cameras in the **Camera Configuration** dialog.

- 1. To open the Device bar, click on 🛅 at the bottom of the bar.
- 2. Then either right-click on individual cameras or click on the ition, which is shown when you position the mouse pointer over the camera name.
- 3. Click on **Alarms** to adjust the settings to your needs. The **Alarm Events** dialog opens.




Fig. 45: Setting Alarm Filters

- 4. Make sure that the **Alarms** option has been activated.
- 5. Select the event types that should create an alarm.

- 6. In addition, you can select a weekly profile for every event type that should trigger an alarm. As long as no other weekly profile has been selected, the setting is valid from Monday 00:00 to Sunday 24:00.
 - Click on Edit weekly profiles to create new weekly profiles. The Weekly Profiles dialog opens. Several predefined profiles are available, such as the Weekend profile (Saturday 00:00 to Sunday 24:00).
 - To add a profile, click on ____. Enter a description. Next, highlight the desired active times in the table using the mouse. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, click on ※.




Fig. 46: Alarm Filter profiles

- 7. You can change the description of an existing profile. Right-click on the name and overwrite it.
- 8. To select a weekly profile, click on the **Weekly Profile** drop down list next to the event type and select the desired profile.
- 9. Click on the calendar icon to easily invert the settings of the weekly profile. For example, if you have created a profile with opening hours and would like to activate the alarms for the closing times, click on the **Invert weekly profile** checkbox and the profile is used in inverted fashion.

Setting Up Recording Paths

The program can access the stored recordings using the following methods: Access to recordings via the camera (remote playback) or to a local directory where the recordings are stored or directly to a file server. When accessing via the camera (MOBOTIX camera), no further settings are required. If you want to access the recordings directly (**file server** or **local directory**), you need to define recordings paths and assign these to the cameras. Direct access offers the advantage of an extremely fast playback speed (up to 60x).

Note

Recordings of MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface can only be saved on MOBOTIX NAS. To do this, first configure the MOBOTIX NAS and then set up the recording path in MxMC.

Defining the Recording Path




Fig. 47: Defining the Recording Path

- Open Settings in the MxManagementCenter > Settings > Recording Paths (Mac) or File > Settings > Recording Paths (Windows) menu.
- 2. Click on "+" and enter the desired name. Under this name, the path can be selected as the recording path in the **Camera Configuration** dialog.

3. Select the type:

Local

Contains a local folder on this computer or on a connected network drive. You can either enter the folder path manually, drag & drop a folder to the input field or select the local or linked folder.

Path: You must select the path that contains the recording folders created by the camera.

Network Share

The program directly accesses a shared folder on a file server. In this case, you need to enter the computer, the folder and the access data.

File Server (IP): IP address or DNS name of the file server with the share.

Directory: Name of the share on the file server.

Important: Make sure that the path ends before the folder containing the factory IP address of the camera.

User Name/Password: Access data for the network share.

MOBOTIX NAS

Data is accessed directly on a shared folder on a MOBOTIX NAS.

File Server (IP): IP address or DNS name and port of the MOBOTIX NAS.

Directory: Name of the share on the MOBOTIX NAS.

Important: Make sure that the path ends before the folder containing the factory IP address of the camera.

User Name/Password: Access data for the MOBOTIX NAS.

■ MOBOTIX NAS (ONVIF)

The ONVIF recordings are accessed on a MOBOTIX NAS.

File Server (IP): IP address or DNS name of the file server.

User Name/Password: Access data for the file server.

Assigning recording paths to the cameras



Fig. 48: Assigning recording paths to the cameras

- 1. Open the **Camera Configuration** dialog in the Device bar. To do so, click on at the bottom of the bar.
- 2. Then either right-click on individual cameras or click on the icon, which is shown when you position the mouse pointer over the camera name.
- 3. Select the appropriate **recording path** in the recording settings. The following options are available:
 - Via camera: When accessing via the camera (MOBOTIX camera), no further settings are required.
 - **Local Path:** Set the appropriate recording format: Use **MxFFS**, if the recordings have been stored in an MxFFS archive. Use **MxFileServer**, if the recordings have been stored in the classic MOBOTIX folder/file structure. Then enter the local directory in the **Device Directory** text box.

Note:

Click on the pen icon in the text field to open a file selection dialog.

- **File Server:** If file server access is used, MxMC searches the specified file server path for sub folders with the corresponding recordings. Once the search has been completed, you can select the folder for this camera in the **Device Directory** selection box.
- MOBOTIX NAS: When accessing a MOBOTIX NAS, select the appropriate camera IP in the **Device Directory** selection box.

Adding devices and sources




Fig. 49: Adding devices and sources

Select the desired action:

Adding Cameras in the Local Network

All cameras and door stations in the local network are detected automatically.

- 1. Click on The Welcome wizard opens and lists all cameras that were found on the local network.
- 2. Select the camera you want to add (use **CMD-click** on a Mac or **CTRL-click** on Windows to select several cameras).
- 3. Specify a user name and a password. Click on to do so. When multiple cameras have been selected, all of these cameras will get this user name and password.
- 4. Click on and then on **Finish**. All new cameras are shown in the device bar in the **Cameras** section and you can already see the live images of the cameras.
- 5. You should now complete the data for the individual cameras. Open the **Camera Configuration** dialog for this purpose. To open the dialog box, you can either right-click onto individual cameras or you click on the oicon, which is shown if you position the mouse pointer over the camera name. The Camera Configuration dialog opens (see Camera Configuration, p. 219).
- 6. Close the dialog once you have completely filled in the camera data in the **Camera Configuration** dialog. Then deactivate the edit mode of the device bar by clicking on ...

Adding Cameras Manually

Cameras outside of the local network (for example, on the Internet) need to be added manually.

- 1. Click on . The **Camera Configuration** dialog opens.
- 2. Enter the camera access data:

Name: Enter a descriptive camera name.

URL: IP address of the camera.

Remote URL: To access the camera from outside of the local network, you can enter the corresponding external address of the camera (such as a DynDNS name). Make sure that you also activate the **Remote** option.

User name, password: Enter the user name and password of the camera.

- 3. Complete the network data and set up alarm notification as described in Camera Configuration, p. 219.
- 4. Close the dialog once you have completely filled in the data in the **Camera Configuration** dialog. Then deactivate the edit mode of the device bar by clicking on ...

Creating Camera Groups

- 1. To create a camera group, click on . The **Group Configuration** dialog opens.
- 2. Fill in the data as described in Setting Up Camera Groups, p. 94.
- 3. Close the dialog once you have completely filled in the data in the **Group Configuration** dialog. Then deactivate the edit mode of the device bar by clicking on ...

Importing Clips

You can use MxMC to play back exported MxPEG clips. Click on to do so. The **Load Clips** dialog opens: Select the desired MXG file and click on **Open**. The clip appears in the device bar in the **Clips** section.

Importing recordings

This function allows you to add storage paths generated by MOBOTIX cameras.

- 1. Click Recordings.
- 2. Select the desired directory with the camera's recording structure and click **Open**.

The recordings are displayed in the Device Bar in the Clips & Recordings section.

MxFFS Medium

This function allows you to access a MOBOTIX storage device connected to the USB port with recordings in MxFFS format

Note: o be able to read MxFFS media, you must start MxManagementCenter with administrator rights (see Integrating MOBOTIX storage device, p. 193). Without administrator rights, the storage medium will not be recognized.

- 1. Click MxFFS Medium.
- 2. Select the desired directory and click **Open**.

The recordings in MxFFS-Format are displayed in the Device Bar in the Clips & Recordings section.

Creating Clips-/ Recording groups

Clips and recordings can be organized into groups.

- 1. Click Create Clips / Recording Group.
- 2. Specify a name for the group.
- 3. Move the desired clips and recordings into the group.

Connecting MxThinClients

Edit the MxThinClient setting here. The MxThinClient is a compact solution for displaying the live image of a MOBOTIX camera on a monitor or TV set with HDMI connection.

Name

Enter the name for the MxThinClient here.

URI

Enter the URL or IP address of the ThinClient.

User Name

Enter the user name of the MxThinClient user here.

Password

Enter the password of the ThinClient user here.

Display resolution

Select the resolution of the camera image to be displayed on the monitor of the MxThinClient.

Camera display

Select here how long the assigned camera image should be displayed on the monitor of the ThinClient. After the selected time period the ThinClient will display the configured setting (e. g. sequences, still images etc.). MxThinClients can also be added via the Component view (see The Components View, p. 70).

Setting Up Camera Groups

You can combine individual cameras into camera groups. For example, you can combine all cameras situated on the same floor in one group. This allows checking on entire surveillance areas at one glance and – in case of an alarm, you are quicker to access the relevant cameras.

Creating camera groups




Fig. 50: Creating camera groups

- 1. Open the edit mode in the Device bar by clicking on at the bottom of the bar. Next, click on +. The **Add and Import** dialog opens.
- 2. Click on **III**. The **Group Configuration** dialog opens.
- 3. Enter a group name and if desired add an image or an icon that will be used to represent the group in the group bar later on. To do so, click on the gray field and select one of the predefined icons. If you want to use one of your own images, click on **Custom**.
- 4. Add a **background image**: Move the slider to the right until you reach the position. Click on the arrow in the gray field and select the file with the background image (for example, ground or floor plan).
- 5. You can add an **information page** to a camera group in order to show special instructions for this camera group, for example. Move the slider to the right until you reach the position. Click on the arrow in the gray field and select the file you want to use.
- 6. Grid Tiles Bandwidth Limits If a very large number of cameras is displayed in the Grid view, the performance may decline. To avoid this, you can limit the frame rate of the live images within the grid frames. Note that this limit does not apply to the camera displayed in the focus window.
 Use ONVIF Lores Profile: Use this checkbox to limit the frame rate for MOBOTIX MOVE cameras and for
 - third-party cameras that provide an ONVIF S-compatible interface. If the checkbox is enabled, the settings for the live images in the tiles captured in the **Bandwidth Settings** as the LoRes profile for these cameras will be used.
- 7. Close the dialog once you have completely filled in the data in the dialog. Then deactivate the edit mode of the device bar by clicking on .

Adding Cameras to a Camera Group

After you have added cameras and created camera groups, you now should assign cameras to the proper groups.

- 1. Open the edit mode in the Device bar by clicking on at the bottom of the bar.
- 2. Drag and drop the corresponding camera to the desired group.
- 3. Once you have assigned the cameras to the desired groups, you can deactivate the edit mode by clicking on ...

Setting the Group View layout

To view and work with camera groups, there are two views available: the Grid view (grouping the cameras by any criteria in raster form) and the Graphics view (realistic arrangement of the cameras on a graphic background). For each camera group you have the option of defining the Grid view grid layout and positioning the cameras on the background image (e.g., building plan) in the Graphics view as desired.

Note

If you have created a group and have not added any cameras yet, the application will show the icon **/** in the Group and Device bar.

Setting the layout for the Grid View

When you first open the Grid view after you have created a camera group, the cameras belonging to the group are displayed in the following grid layout by default:

- The aspect ratio of the camera images is 4:3.
- The Grid view is in auto grid mode. In auto grid mode, MxMC always tries to distribute the available space as well as possible according to the specified camera image format, the size of the focus window and the number of cameras. If you change the size of the window, the grid layout adapts automatically.
- The focus box displays the camera that is in the Device bar at the top of the group.
- The focus window size is twice as large as that of the camera images.




Fig. 51: Setting the layout for the Grid View

- 1. To change the format of the camera images or the size of the focus window, open the edit mode by clicking on in the Command bar. The following sliders for adjusting the grid layout appear at the bottom of the bar:
 - 8:3 = Format of the camera images and the focus window (4:3, 16:9, 8:3)
 - 3x =Size of the focus window (1x, 2x, ..., 8xthe size of the camera images)
 - 16 = Maximum number of cameras

See also: Group Views, p. 200

Configuring the Graph View layout

When you open the Graphic view for the first time after creating a camera group, all the cameras in that group are listed at the right margin of the previously defined background image with a camera icon 3.




Fig. 52: Configuring the Graph View layout

- 1. To arrange the cameras according to their actual positions on the background image, open the edit mode by clicking on \bigcap .
- 2. To do so, move the mouse pointer over the camera icon. Two icons are shown.
- 3. Click on 🚱 and drag the camera icon to the desired location.
- 4. Click on to save the changes.

See also: Group Views, p. 200

Adding Users

After you have added the cameras and organized them into groups, set up users and any other administrators, if required. Users and administrators are set up in the User Management. You set up access permissions at the same time. You can assign rights for users depending on the specific functions they need, whereas an administrator possesses all rights.

See also: User Management, p. 227

Creating Users or Administrators

Open the **User Management** by clicking on **[2]** in the Header bar. Next, click on **Add .**




Fig. 53: Creating Users or Administrators

User type and user name

- 1. Enter the corresponding user name.
- 2. Select the desired user type: user or administrator.

The user type is set to **User** by default. The sections **Weekly profiles** and **User rights** are available for users, in contrast to administrators. All other settings apply to both user types and will be used in the following description; however, reference will only be made to **User**.

3. Use the **Active** option to enable the new user immediately or later on.

Password

- 1. Enter a password and confirm it.
- 2. Use the **Expires** option if you want to require the user to change the password at regular intervals.
- 3. If the user is to change the original password upon the next legion, select the **Force change on next log in** option.

Note: Activating this option automatically gives the user the "Change Password" right, even if it had been disabled before.

4. The **Force Complex Password** option ensures that users can only set secure passwords.

A secure password has at least eight characters, consists of lowercase and uppercase letters, including at least one special character, one digit and one character. Furthermore, it cannot be one of the last thirteen passwords used on this user account. If you are trying to set a password that does not meet the criteria, a red frame around the text field will appear.

Log in

- 1. You can establish a specific setting for time ranges in a weekly profile for users who can only access MxMC at specific times. This section is not displayed when creating an administrator because the administrator always has all rights and access to MxMC.
 - Click on **Edit weekly profiles** to create a weekly profile. The **Weekly Profiles** dialog opens with the options **Weekly profiles** and **Holidays**.

Weekly profiles

There are two predefined profiles available from the beginning: the **Weekend profile** (Saturday 00:00 to Sunday 24:00) and the **Working days** profile (Monday 00:00 to Friday 24:00).

- To add a profile, click on . Enter a description. Highlight the desired active times in the table. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, select one first and then click on .
- You can change the description of an existing profile. Double-click on the name and overwrite it.

Holidays

- To add a holiday, select the date, check "Repeat annually" if required and click on
- To delete a holiday, select it and click . existing profile.
- 2. Close the dialog box to finish editing the weekly profiles. You can then use the new (or modified) weekly profile in user management. To do so, click on the Weekly Profile box and select the desired profile.

Note

24 hours is set by default. In this example, the user always has access to MxMC.

3. Click on the calendar icon to easily invert the settings of the weekly profile. For example, if you have created a profile with access on the weekend and would like to activate the alarms for working days, click on the Invert checkbox and the profile is used in inverted fashion.

Log out

In addition, you can specify after how many minutes of inactivity this user will be automatically logged out.

Setting Up Access Rights

Every user has all user rights initially. Deactivate the rights that should not be available for a specific user in the **User Rights** section. This section is not displayed when creating an administrator because the administrator always has all rights.

Configuring Basic Camera Settings

MxMC offers the possibility to adjust settings directly on the cameras. Some of the configuration options are summarized in the Configuration view under the green **Basic Settings** tile. This area includes all topics that are important or necessary for commissioning. Unlike "Advanced Features," the basic camera settings do not require a license and are therefore always available.

Note


MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compliant interface cannot be configured using MxMC. For an overview of how the camera functions differ (see Camera Feature Overview, p. 13.

Opening Basic Settings


1. Open the Configuration view by right-clicking on the navigation key in the Command bar. Select the Configuration view.

Note


When opening this view, the system always loads the configuration of a camera group.



2. If you did not purchase a license to use "Advanced Features," the **Basic Settings** section is opened by default.




3. If you have purchased an "Advanced Features" license, the Configuration view entry page will open. Click on the **Basic Settings** tile.



Configuring Basic Settings


- 1. Click on the respective tab to open the corresponding topic area.
- Make your settings as required by topic.
 More detailed information on editing the settings can be found in the table below. Clicking on the relevant topic area in the table opens an information page for the individual topic areas of the basic settings.



Default setting	Associated Parameters
Basic Camera Settings: General Settings, p. 105	Arming, Frequency of power supply, Audio source
Basic Camera Settings: Network, p. 117	Internal host name, BOOTP/DHCP, Second IP address
Basic Camera Settings: Time, p. 107	Automatically synchronize using a time server, Do not adjust automatically
Basic Camera Settings: Image settings, p. 108	Image size, JPEG quality, Camera selection, Display mode, Installation, Exposure window, Exposure program, Max. exposure time
Basic Camera Settings: MxActivitySensor, p. 116	Active, Profile name, Event dead time, Edit detection area
Basic Camera Settings: Recordings, p. 112	Arming, Recording mode

Applying And Saving Changed Settings

The controls at the bottom of the configuration view can be used to perform actions such as permanently storing the changed settings or to reset the parameter values to their factory settings.



Applying Changes

Normally, the changes in the Configuration view take effect when you type or select the new value. The changes made here are not automatically adopted because they could potentially cause problems with the **Network Settings**. Instead, the **Apply Changes** icon in the Command bar turns red, indicating that the change is not yet in effect. To apply your changes, click on

Storing the Configuration

If parameter values are changed, the **Store Configuration** icon turns red in the Command bar. Changes to the configuration are always stored in the camera temporarily. To ensure that the current settings are also used after the next restart, the changes must be saved permanently.

- 1. Click on **Store Configuration**. The program opens a system prompt. In the prompt, click on **Store**.
- 2. If you do not want to keep the changes, click on Discard. This discards the changes and restores the last permanently saved overall configuration.

Resetting to Factory Settings


The parameter values of the opened tab can be reset to the factory default settings. Click on 👩 to do so.

Undoing or Repeating Changes

Click on to undo the last change. Click on to repeat the last change.

Changing Parameter Values for Multiple Cameras in the Configuration Bar

The Configuration bar on the right margin offers the possibility to change the settings of several cameras of a group without having to change the camera or the camera group.



Changing the Value for a Camera

- 1. If the Configuration bar is not already open, open it by clicking on the right margin in the application.
- 2. Click on the desired parameter name in the Basic Settings. It turns yellow and the Configuration bar shows all values associated with this parameter for this group. The cameras for which this value is set are assigned to the individual values.
- 3. Highlight the desired camera and drag it onto the parameter value you want to set. The destination area turns yellow.

Changing a Value for Multiple Cameras

If the same value is set for several cameras and you want to change this value, click on the parameter selection field in the Configuration bar. Then change the parameter value for the cameras configured the same way at once.

Basic Camera Settings: General Settings

The general topics on operating the cameras are found in the general settings.




Fig. 54: Camera Settings: General Settings

Arming

The main arming feature needs to be activated in order to process events, execute actions and notifications and record images and audio data.

Parameter	Explanation
Activated	The camera is always armed.
Off	The camera is not armed: no image storage, actions or messages.
CS	Arming is controlled via a custom signal that needs to be previously configured on the camera. The camera can use a signal input, for example, as the main switch for arming by using the custom signal.
From master The camera is armed only when the master camera is armed.	
See also:	Recording, p. 364MxActivitySensor, p. 361

Frequency of Power Supply

If the camera's exposure control is not matched to the frequency of the power supply, sources of artificial lighting may lead to image interference. This parameter sets the camera to the power supply frequency of the respective country to prevent interference.

Parameter	Explanation
No artificial light	If the camera is used in daylight conditions (rather than with artificial lighting), you can also use the No artificial light setting.
50 Hz	The factory default setting for Europe is 50 Hz.
60 Hz	Set the power supply frequency to 60 Hz for Canada, the U.S. and Japan.

Audio Source

Select the desired audio source. It is also possible to integrate an external audio source in addition to using the camera's microphone. The audio source is used for two-way communication and recording audio data, for example.

Basic Camera Settings: Time

The date and time can be manually set, adopted from the computer, or continuously synchronized through a time server. If you use a time server, the clock can be synchronized using a time server over the Internet, a time server service in the local network or another MOBOTIX camera. In this case, the camera's time server must first be set in the camera web UI Admin menu (Admin Menu > Camera Administration > Time & Date > Use Camera as Time Server).




Fig. 55: Basic Camera Settings: Time

Automatically Synchronize Using a Time Server

Two protocols are available for synchronizing the camera using a time server: NTP and Time Protocol.

Parameter Explanation	
Time Server and Time Server Address	 NTP: With this protocol, the camera continuously synchronizes with one or more NTP time servers. If the NTP protocol has been selected, you can enter up to five time servers under Time server address. Theses servers must support the protocol specified in RFC 1305. A green dot to the right of the time server address indicates that the time server is accessible and offers an NTP service. It can take a moment for the camera to connect to the time server and the dot to turn green. Time Protocol: With this protocol, the camera synchronizes every six hours (and when it is rebooted). If Time Protocol (RFC 868) is selected, enter the Time server address in this box. The server must support the protocol specified in RFC 868.
Current Time	Display time of the current camera
Time Zone	Select the correct time zone for the camera location.

Do not adjust automatically

Deactivate automatic synchronization if the date and time are set automatically or if they are adopted from the computer.

Parameter	Explanation	
Current Time	If the camera's time deviates from the computer's time, click on Use PC time to adopt th computer's time.	
Set time manu- Capture the desired data to manually set the date and time and click on Set time to conally firm the entry.		
Time Zone	Select the correct time zone for the camera location.	

Basic Camera Settings: Image settings

To display the camera live images, you can set camera views, image and exposure settings in this tab and create and edit custom exposure windows directly in the live image.




Fig. 56: Image settings

JPEG quality

The JPEG quality influences both the image quality as well as the file size of the JPEG and MxPEG files generated by the camera.

Using a compression of 60% (default) will usually deliver good-quality images that are suitable for most purposes. If the value is lower than 20%, you can see pixelation within the image. For values higher than 70%, differences to the uncompressed original image are hardly visible. The file size, however, may increase to more than 100 kB (for a 640x480 pixel image).

Camera selection

On Dual cameras, select the image sensor to use when displaying the images: right image sensor, left image sensor, both image sensors or automatic day/night switching. When configuring the image settings for both sensors, first select the sensor you want to configure using the left or right checkbox in the live image preview window and enter the settings you want.

Display mode

There are various display modes available depending on the camera model.

All Cameras Except Hemispheric Models

- **Full image:** The entire live image from the camera is displayed.
- **Lens correction:** This option displays a portion of the live camera image (with lens correction). This option is only available for L22 lenses, provided that the camera configuration is adjusted accordingly.
- **Picture-in-Picture:** This option displays a small image from one camera sensor inset in the large image of the other. This setting is available on MOBOTIX Dual models only.

- Picture in Zoom: This option displays a small version of the entire live camera image in the lower right corner of the large live camera image. This way, the entire image is visible even when the live image is zoomed.
- **Event in Picture:** This option displays a small version of the latest event image in the lower right corner of the large live camera image.

Hemispheric Models

- Full image: The entire (distorted) full image of the image sensor is displayed.
- **Normal:** A corrected image is displayed. This image can be panned and tilted. This is the factory default setting for hemispheric cameras.
- **Surround:** This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Panorama:** This option shows the distortion-corrected image of an entire room (corrected 180° panorama view) from the left to the right wall. The aspect ratio (width to height) is 8:3.
- **Panorama focus:** This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This view only makes sense for the ceiling-mounted MOBOTIX Hemispheric model. Both partial views (North and South) can be changed independently of each other using PTZ commands.

Installation

You can set the mounting position of a MOBOTIX Hemispheric camera: wall, ceiling or floor. The mounting positions are set separately for the left and right lenses for cameras with two active image sensors.

Exposure window

It is set to ensure the proper exposure/brightness for the live camera image.

Custom

Creating And Editing Custom Exposure Windows Select the **Custom** option and then click on the window in the live image preview.

Action Explanation

Create expos- Draw a window using the mouse pointer.

ure windows

Move expos- Left-click on the exposure window and move it to the desired position.

ure windows

Modify	Move the mouse pointer over one of the white "handles" until the icon is displayed. Left-
exposure windows	click with the mouse and drag the window making it larger or smaller.
Delete expos- ure windows	Click .
Exclude areas from	Pull open a window of the appropriate size at the position that should be excluded from

exposure metering Pull open a window of the appropriate size at the position that should be excluded from exposure metering. Click in the window and keep the mouse button depressed until two icons appear. Click on to determine the exclusion window. The window turns red.

Visible image area

This setting enables you to use the current visible image section as the exposure window.

Predefined

You can use a number of predefined exposure windows: When you select the corresponding window, it will be displayed in the live image for review. A predefined exposure window is always applied to the full-image area, that is, the entire image of the sensor.

- 1. Full image: Entire area of the image.
- 2. Quarter: An exposure window at the image center that covers a quarter of the viewable image area.
- 3. **Center:** One exposure window at the image center.
- 4. **Spot:** One small exposure window at the image center.
- 5. **Top:** One horizontal exposure window at the top of the image.
- 6. **Center:** One horizontal exposure window at the image center.
- 7. **Bottom:** One horizontal exposure window at the bottom of the image.
- 8. **Right:** One vertical exposure window at the right border of the image.
- 9. **Vertical:** One vertical exposure window at the image center.
- 10. **Left:** One vertical exposure window at the left border of the image.
- 11. **Right AND left:** Two vertical exposure windows at the left and right borders of the image.

Exposure program

These parameters influence the balance between an exposure time that is as short as possible and hardware aperture that is as small as possible. The objective is to reach a fair compromise between clear images of moving objects (short exposure time, high amplification) and as little image noise as possible (long exposure time, low amplification).


- 0: Default program.
- Negative: The programs will reduce exposure times to decrease motion blurring; could increase image noise.
- **Positive:** The programs will increase exposure times to reduce image noise; exposure in very bright environments is not impacted.

Maximum exposure time

This parameter determines the longest exposure time used by the camera. This setting enables you to either avoid motion blurring as lighting conditions decrease, or even specifically allow it. Select shorter maximum exposure times if you do not want motion blurring. You can use a longer maximum exposure time (max. of 1/1 = 1 second, for example) if you want the camera to produce images with good exposure (with motion blurring), even in low light situations.

Basic Camera Settings: Recordings

In this tab, the most important recording settings can be made, such as selecting the recording mode or setting the recording speed.



Arming

The arming feature for event control handles camera recording. However, the main arming of the camera needs to be activated in order to make the recordings in the first place.

Parameter	Explanation
Off	The recording feature is deactivated. No further parameters will be displayed.
Activated	The recording features of the camera are activated (default setting).
CS	The recording is activated by a custom signal (CS).
From maste	The recording feature of the camera will only be enabled if recording has also been activated on the master camera.

Recording mode

You can select the type of recording for events and story images. The availability of the parameters will depend on the recording mode you select.

Recording Type	Parameter
Snapshot Recording	This option will save individual pre- and post-alarm images (JPEG images), but without sound.
	Snap shot interval
	This option determines the amount of time between the individual pre-alarm and post-alarm images. You can set values from zero to ten minutes (max.).
	Pre-alarm images
	Number of the image that are recorded before the event.
	Post-alarm images
	Number of the image that are recorded after the event.
	Unlimited time to keep
	The time to keep is set to unlimited by default. You can select a maximum time to keep , expressed in hours and days, if you deactivate this option. The maximum value for time to keep indicates how long images and video clips need to be stored.

Recording	Parameter
Туре	
Event	This option stores clip files for every event using the MxPEG codec with variable frame rate and
recording	optional audio data.

Record audio data

If available in the camera, audio data can also be recorded. Set this option to **active** to enable audio recording.

Event frame rate

Recording speed in frames per second (fps).

Recording time before event

Time (in seconds) to include in recorded stream before an event has occurred.

Recording time after event

Time (in seconds or minutes) to include in recorded stream after an event has occurred.

Unlimited time to keep

The time to keep is set to **unlimited** by default. You can select a **maximum time to keep**, expressed in hours and days, if you deactivate this option.

The maximum value for time to keep indicates how long images and video clips need to be stored.

Continuous Continually saves video and (optionally) audio data as MxPEG clips. Recording

Record audio data

Similar to Event Recording, audio data from the camera be recorded with the same quality, regardless of the frame rate. Set this option to **active** to activate the microphone.

Frame rate

Recording speed for continuous recording.

Recording Type	Parameter
	Unlimited time to keep
	The time to keep is set to unlimited by default. You can select a maximum time to keep , expressed in hours and days, if you deactivate this option. The maximum value for time to keep indicates how long images and video clips need to be stored.

Basic Camera Settings: MxActivitySensor

The MxActivitySensor is a camera-internal video motion detector that can identify direction of motion detection and object size while blocking out any undesired interference (such as trees swaying in the wind) when detecting motion. By default, a MOBOTIX camera ships with a predefined MxActivitySensor profile.

You can activate and deactivate this profile in this tab, change the name of the profile, adjust the event dead.

You can activate and deactivate this profile in this tab, change the name of the profile, adjust the event dead time, change the detection range and define new areas.




Fig. 57: The MxActivitySensor

Active

The MxActivitySensor profile is also activated when the Arming feature is enabled in the general settings.

Profile name

You can change the preset profile name.

Event Dead Time

The event dead time defines a period of time (0–3600 sec.) after an event during which no new events from the same profile are detected. By defining an event dead time you can avoid, for example, that a complex

action (person walks through the active image area) triggers multiple events. You can adjust the preset event dead time (5 sec.).

Edit detection area


Proceed as follows to adjust the default detection area or to define additional image areas: Click on the green detection area in the live image preview.

Action	Explanation
Change	Position the mouse pointer on one of the white "handles" until the icon is displayed. Click
shape of detection area	and hold the left mouse button and drag the frame to make the detection area larger or smaller.
Move detection area	Left-click on the detection area and move it to the desired position.
Rotate detection area	Click on and, while holding the mouse button down, rotate the detection area clockwise or counterclockwise.
Change	Switch to polygon mode by clicking on . You will see white corner points on the corners.
shape of detection area	Drag the corner points to the desired position. You can insert new corner points by right-clicking on the white line or in the detection area. Right-click on a dot to delete a corner point. Then click on
Deleting a Detec- tion Win- dow	Click on .
Create a detection window	Use the mouse to pull open a new window in an area that is not yet covered by another window.
Exclude area from analysis	Pull open a window of the appropriate size at the position that should be excluded from the analysis. Click in the window and keep the mouse button depressed until two icons appear. Click on to determine the exclusion window. The window turns red.

Basic Camera Settings: Network

Your network interface settings determine how the camera can communicate with the "outside" world and how the camera can be accessed from outside of the local network. When changing parameter values, please

note that the changed values are not automatically applied as in the other tabs of the Configuration view. For changes to take effect, you must click on in the Command bar.



Internal host name

The host name is the unique camera name in the network under which it is accessible.

BOOTP/DHCP

BOOTP and DHCP are protocols with which IP addresses can be managed in a network and automatically assigned. The camera can use them to automatically obtain its network configuration.

Parameter Explanation

Off

The camera's network configuration is manually established. Enter the appropriate information in the **IP address** and **subnet mask** boxes and, if necessary, change the standard route or gateway and the DNS server.

IP Address: You can access the camera in the network via its IP address. Ask your network administrator which IP address is available.

Subnet Mask: A matching subnet mask needs to be entered for the IP address in order for computers to be able to communicate in a network. Again, it is your network administrator who will tell you which subnet mask to use.

Default Gateway:

The gateway acts a relay between individual networks and it coordinates the data traffic between these networks. Enter the IP address of the gateway that should be used.

DNS Server:

A Domain Name Service (DNS) resolves computer names to IP addresses. If you have a DNS on your network, you can specify up to three IP addresses of DNS servers. This is only necessary if you want to address computers using their name instead of their IP address for other configurations (FTP, email).

On client mode Use BOOTP/DHCP to set the IP address and network configuration automatically. The gateways

and the default route are automatically determined via ${\tt BOOTP/DHCP}$ and configured.

On server

mode

This camera provides DHCP service to clients on the local network. The IP address of the camera will be **192.168.0.19** with subnet mask **255.255.255.0** by default.

Default Gateway:

Enter the IP address of the gateway that should be used.

DNS Server:

A Domain Name Service (DNS) resolves computer names to IP addresses. If you have a DNS on your network, you can specify up to three IP addresses of DNS servers. This is only necessary if you want to address computers using their name instead of their IP address for other configurations (FTP, email).

Additional IP address

The camera can manage two different network configurations. If you enable this checkbox, the factory default IP address and the subnet mask will also be used, ensuring that the camera remains accessible at all times.

Checking System Security

After completing the basic configuration of the system, you can check its security. The **Wizards & Tools, p. 256** view offers the **Secure System** wizard. It analyzes the security of the cameras and assesses their status


based on common best practices. If test criteria are not met, possible measures to protect the cameras are provided.

Note

The system security check feature is not available for MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Verifying Settings for System Security

1. To open the **Wizards & Tools** view, right-click on the navigation key in the Command bar. Select the **Wizards & Extras** view.



2. Select the desired camera or camera group in the Device bar or the Camera/Group bar.



- 3. Click **Secure System**. The following criteria are checked:
 - Usage of the "meinsm" password with standard or ONVIF user accounts on MOBOTIX cameras. It is easy for cyber attackers to guess the standard "meinsm" password.
 - Enabled **Public Access**: If Public Access is enabled, a number of different camera functions can be used without a password.
 - Activated HTTP web server: It is possible for data, including user data such as passwords and images, to be transmitted via the network without encryption when HTTP is used.

The result of the check is displayed for each camera in the **Secure System** dialog. It will also show all cases in which cameras were not checked due to a connection error, for example.

Status	Explanation
⊗ Not secured	There was at least one criterion that was listed as not secure.
C Software too old	Please check the camera software and update it, if necessary.
○ Connection error	Check your network connection to the camera and perform the security check again.
Not supported	The camera (s) cannot be analyzed or secured using the wizard.
	Camera is secure; no further action is necessary.

Secure System

4. In the **Secure System** dialog, click on **Next**. Cameras resulting in a **Not secure** status are displayed together with whichever of the three criteria that were fulfilled as well as the measures that need to be taken to properly secure the cameras:

Criterion	Explanation
Password	Changes the password of all user accounts on the cameras that use the standard "meinsm" password. It also include ONVIF users whose passwords have never been changed. Enter a new password and confirm it. A suitable password has at least eight characters. It can consist of lowercase and uppercase letters, digits and special characters (see). If you set a password that does not meet these criteria, a red frame appears around the text field. The frame turns green once you have entered a valid password. The new password is automatically entered in the MxMC project data.
SSL encryption	Disables camera connections via unencrypted HTTP and configures the cameras to accept HTTPs connections only. The TCP port and the SSL setting will be automatically updated in the MxMC project data, if necessary. The TCP port will not be updated for cameras that are connected via a remote URL. For remote URL connections, you may need to change port forwarding in the router to the appropriate setting. Please note that different services, such as network messaging etc., will no longer work when you disable HTTP.
Public Access	Disables access that does not require password entry to the web interface and the APIs of the cameras.

5. Click on **OK** in the dialog box. The selected security measures will be performed. The security status for the selected camera or camera group will be analyzed once again and the result for each camera is displayed.

Backing Up System Settings


Once the system has been set up to add all the cameras, organize the cameras into groups, create the users, set their access permissions and verify system security, you should save the settings as a project. Everything is saved, except for settings that are only relevant for the local installation, such as the Remote Control port. Secured system settings can be e-mailed directly from the application to other people. You can also include the encrypted access data for each camera (user name and password). When opening the project in MxMC,

this access data will be used automatically. If you do not supply the access data, the user name and password will have to be entered manually for each camera.

Furthermore, you can quickly export a tabular overview of all cameras and camera groups from MxMC and save it in the usual way. The table lists the cameras with their IP addresses and the camera groups with the associated cameras.

Saving projects

- 1. Click on in the Header bar. The **Projects and Network Environments** dialog opens.
- 2. Click on **Save As** $\ lacktriangledown$ and complete the dialog.



Providing projects via email

In the header bar, click on **Projects and Environments** and then on **Email to**. This will generate a project file which will be transferred to the mail program as an attachment within a new e-mail.

Note

a properly configured email client is required for this purpose.

Export MXU File

You can conveniently add large numbers of cameras, camera groups, devices and recordings/clips in MxMC using a list in MXU format. To create an MXU file based on the current project data, proceed as follows:

- 1. Select **File > Export MXU...** from the Menu bar.
- 2. Click on **Save**. The table is saved as an MXU file.

Import Existing Project

If you have already used MxControlCenter or MxEasy, you can import an existing **MxControlCenter.ini** file from the MxControlCenter or the **MxEasy.ndb** camera list from an MxEasy installation. In both cases, the cameras already integrated in the MxControlCenter (MxCC) or MxEasy are automatically transferred to the MxManagementCenter with their access data.

Furthermore, it is possible to quickly integrate a large number of cameras and camera groups into MxMC using a manually created list inMXU format. You need to adhere to specific rules for the format when creating the list in order to correctly export the contents of the MXU file.

Importing configurations from MxControlCenter

When importing an MxCC file, the following is taken into account:

- The layouts defined in MxCC are created as groups in MxMC.
- The background layouts from MxCC, including the background graphics and definitions of the camera symbols, are transferred to the Graphic view of the associated group.
- If a global password has been assigned, this will be entered for all cameras that do not have a user name.
- For each hyperlink used, a softbutton is created in MxMC.
- Furthermore, the tree structure from MxCC is shown in the Device bar and file servers configured in MxCC are created in the MxMC settings.




Fig. 58: Importing configurations from MxControlCenter

- 1. Open the **Welcome Wizard** from the **File > Welcome** menu.
- 2. Click on **Import MxCC**. Decide if the current project should be saved.
- 3. Import the desired INI file.

Importing Configurations From MxEasy




Fig. 59: Importing Configurations From MxEasy


- 1. Open the **Welcome Wizard** from the **File > Welcome** menu.
- 2. Click on **Import MxEasy**. Decide if the current project should be saved.
- 3. Import the desired NDB file.

Importing MXU Files

Using a manually created list in .MXU format, you can quickly add a large number of cameras and camera groups. You need to adhere to various formatting rules when creating the list in order to correctly export the contents of the MXU file (see Creating MXU Files for Imports, p. 126).

Important

This list does not replace the project import, during which program settings, such as settings for the cameras and camera groups with assigned layouts, are imported.



- 1. Click on **Import MXU** to import cameras and camera groups in the Welcome wizard. You can save the existing project, if necessary.
- 2. Open the MXU file.
- 3. Decide whether the cameras and groups from the MXU file should replace the entire configuration or they should be only added.

Creating MXU Files for Imports

You can quickly add a large number of cameras and camera groups to the MxMC using an MXU file. There are several format specifications that need to be followed when generating such an MXU file.

Format for Simple Imports

It needs to adhere to the following format for a simple import of cameras:

- Unformatted UTF-8 text
- One or more camera lines with the following structure:
 Name<TAB>IP<TAB>Username<TAB>Password<CR LF/LF>
- Elements in a camera line need to use **TAB**s as separators.
- Line breaks are either **CR LF** (Windows) or **LF** (UNIX).
- Comment lines are preceded by a //.
- Camera names need to be unique and cameras using the same name will not be added more than once.

Example:

```
Main Entrance 10.6.37.25 admin meinsm Side Entrance 10.6.15.206 admin meinsm Entrance Gate 10.6.23.132 admin meinsm
```

Format for Advanced Imports

Expanded Format

The file needs to use the following format for the advanced import of cameras, groups, clips and settings for graphics and grid view:

- First line always #EXTMXU
- Any additional commands must start with #EXT. Parameters use ":" as separators. Example:#EXTGROUP:Doorstations

Commands for advanced imports

#EXTMXU	Marker to indicate the beginning of the file
#EXTGROUP:name:f:r:icon:map:info	Group "name" is created and all further cameras will be added to this group.
	f: Large focus window (0=0x, 1=1x, 2=2x)
	r: Tile ratio (0=4:3, 1=HD, 2=8:3)
	icon: If numeric, index of the internal group icons; otherwise, file name corresponding to the *.mxu file.
	map: File name of the background image
	info: File name of the information page
#EXTGROUP:	All further cameras will not be added to a group if no name is specified (unless "All cameras").
#EXTCLIP:clipMXG	Camera demo clip is added. Clips need to be stored in the same directory as the *.mxu file.
#EXTMXPEG:name:clipMXG	MxPEG clip with "name" is added. This references the absolute path of the MXG file.
#EXTCURRENTCAMERA:name	Select camera.
#EXTCURRENTGROUP:name	Select group.
#EXTSUBGROUPS:name	The following groups (each with the name in a line) are added to the group "name" as a subgroup.
#EXTINFO:Comment	Comment line.
#EXTEND	End of file, all further lines are ignored.

Example:



#EXTMXU #EXTGROUP: Doorstations: Main Entrance Side Entrance	2:2:2 10.6.37.25 10.6.15.206	admi
#EXTGROUP:Indoor:2:2:3 Building East Building West Staircase Canteen	10.3.31.251 10.7.25.186 10.6.115.57 10.12.32.65	admi admi admi admi
#EXTGROUP:Outdoor:2:2:4 Parking Visitors Parking Employees	10.5.46.39	admi admi
#EXTGROUP:Dual Cams:2:2 Checkout1 Checkout2 Checkout3	:10 10.10.106.26 10.10.152.225 10.13.242.195	admi admi admi
#EXTGROUP: Faststreams: 2 Ground Floor First Floor Second Floor Elevator	:0:11 10.2.2.169 10.2.104.130 10.3.11.51 10.3.209.198	admi admi admi
<pre>#EXTGROUP:Clips:2:2:group #EXTCLIP:FiremanMXG #EXTCLIP:PoleMXG</pre>	upIcon.png:groupMa	p.jpg

#EXTCURRENTCAMERA:Main Entrance
#EXTCURRENTGROUP:Doorstations

Using The Application

This section is for **users**. It provides assistance with daily MxMC operation, from monitoring one or more cameras to searching records.

Areas	Topics
Live Surveillance	Working with the Live view
	Working with the Grid view
	Working with the Graphic view
	Using Door Stations
	Working with multiple monitors
	Working in different network environments
Alarm Processing	Alarm notification
	Setting up alarm notification
	Filtering alarm images
	Playing back alarm recordings
Searching in MxMC	Searching and playing back in the research view
	Searching and playing back in the grid playback
	Searching and playing back in the search view
	Searching and playing back door events
	Exporting recordings
	Special search features

Live surveillance

The section describes basic scenarios and options of live surveillance.

Working With The Live View

The Live view allows you to control the live images of individual cameras. This also includes switching various functions, e.g, opening doors or switching lights.

Showing Cameras




Fig. 60: Showing cameras

To view a camera, you can use the Device or Camera bar. To do this, either drag and drop the desired camera from the Device bar into the display area or click on the desired camera in the Camera bar. The displayed camera is marked with a yellow bar in the Device bar as well as in the Camera bar.

Customizing Image Settings




Fig. 61: Customizing image settings

Use the **Brightness** and **Contrast** controls to adjust the image display of the displayed camera to the current environment.

Move the corresponding slider upwards or downwards. The new settings are stored automatically for the current camera. The default values can be restored by double-clicking on the corresponding slider.

Note:

Adjusting the image settings does not have any effect on the camera settings. These will not be changed

Performing PTZ Actions




Fig. 62: Performing PTZ actions

Note

On a secondary monitor, a single camera image can only be zoomed with the mouse wheel or panned with the mouse button pressed down. PTZ controls are only available on the MxMC main screen or on the secondary monitor in Grid View.

To better identify objects in an image section, you can zoom the live image and move the resulting image area around (PTZ). To facilitate quick loading of these image sections, several image positions are already pre-configured for loading using the slider ...

The program also shows the

slider on Dual cameras. Use this slider to show the live images of either the right, the left or both image sensors.

When showing the live images of hemispheric cameras, you can configure different display modes (slider)



Zooming and Moving Image Sections

You can zoom using the slider lacktriangle or the mouse wheel. Zooming with the slider takes place only on the computer. This means that only the image section of the current live image is modified.

To see other image sections, you can move the live image using the mouse.

If you want to execute the PTZ actions on the camera, you can also switch to camera PTZ. In this case, the PTZ actions are applied to the camera's live image and also influence the recordings (but only if the camera does not record the full image). To use this feature, click on the slider 🛖 and keep it pressed until it starts

flashing. You can now adjust the zoom level as needed. To store the setting, click again on the slider and keep it pressed until the slider stops flashing.

Selecting and Adjusting Image Sections

Selecting Image Sections

To quickly focus on a specific image section, you can use one of the factory default image positions that are predefined in the camera.

- Preview ♠, detail ♠, overview ♠ and point of interest♠
- Top ①, bottom ①, left ②, right

The camera will then move to the selected position. Note that the PTZ actions are executed on the camera and also influence the recordings (only if the camera does not record the full image). Move the \(\text{\text{N}} \) slider to the next position or until you have found a suitable position.

Adjusting Image Sections

You can adjust the pre-defined image positions of the factory default. Select a position and modify it as needed. Keep the slider on this position until it flashes once. The new image section has been stored.

Choosing a Sensor

If you want to show the live images of only the right or the left image sensor, you can move the slider to the right to (left sensor) or further to the right to

Correcting The Distortion Of Hemispherical Images

When showing the live images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. This requires that you enabled **OpenGL** in the settings (Mac: **MxManagementCenter > Settings > General** menu; Windows: **File > Settings > General** menu). In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. The selection of a display mode is always done locally and thus does not influence the camera settings. However, the selection is also applied to the other program views. When selecting a display mode in the live view for a specific camera, this mode is also applied if the camera shows up in the focus window of the Grid view as well as in the live images of the Graphic view. Consequently, the alarm images in the Alarm bar and in the Research view are also shown in the selected display mode.

Selecting The Distortion Correction Mode

- **Full image:** Shows the entire (distorted) full image.
- **Normal:** Shows a distortion-corrected image and allows executing PTZ actions.
- Panorama: Shows the entire distortion-corrected image (corrected 180° panorama) from the left to the right border. The aspect ratio (width to height) is 8:3.
- **Surround:** This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This mode makes sense for a hemispheric camera that is mounted to the ceiling. It can be customized subsequently using local PTZ.
- Panorama focus: This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.

To select a mode, move the slider **()** to the right until you reach the desired position. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined. For example, if the image in Panorama mode is not centered, you may see a trapezoidal distortion. The panorama correction allows adjusting the skewed (vertical) lines of the image to produce a more naturally-looking image. To do so, move the slider to the right to and use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.

Status Display

The Status bar displays different states by means of icons. The status displays always refer to the displayed camera. This gives you an up-to-date overview, e.g., showing you at a glance whether a door has been closed again or is still open.



Fig. 63: Status display

Door Status Dis- play	= door is closed. = door is open. = door is locked. = door lock switch is locked, but the door is open!
Light Status Dis- play	= light is off. = icon is lit: Lights are on, need to be switched off manually.
Microphone Status Display	 ∑ = microphone is switched off, no announcement possible. ∑ = microphone is on, announcements are possible. ∑ = microphone connection is blocked, possibly because a connection has been established to a different remote station.

Switching additional devices via hyperlink

Hyperlinks can be used to switch additional devices or to send HTTP requests. When defining hyperlinks, you can select an individual button icon for the hyperlink (there are several pre-defined icons to choose from) or set one button from which to run all hyperlinks.




Fig. 64: Switching additional devices via hyperlink

To define a hyperlink, right-click on and then on .

In case you did not assign an icon for the individual hyperlinks, they will be combined under one button.

To execute such a hyperlink, click on and then on the name of the desired hyperlink.

Manually recording live images

In the Live view as well as in the Grid view, you can start manual recording at any time, such as when you observe a suspicious situation that should be recorded. While you keep track of the situation in the live image, the images are recorded and saved as a MXG file.

Users with administrator rights can specify where the clips are saved and how long the recordings can be in the Program Settings (Mac: menu: MxManagementCenter > Preferences > Live Recorder, Windows menu: File > Settings > Live Recorder).

Notes:

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview. Audio can only be recorded with the Live Recorder under these conditions:

- Audio transmission must be activated on the camera side.
- In the Live View of the MxManagementCenter, the audio connection must be activated by clicking on






Fig. 65: Manually recording live images

Starting And Stopping Recordings

To start recording, click on **Live Recorder**. Recording will stop automatically after the recording time set in the program settings has expired. Just before this time expires, a message will be displayed. You can stop the recording from within this message or extend the set period of time. To stop recording before the time expires, click on again.

Note

If you change the view, the recording is automatically stopped. However, a camera change within the Live view does not stop the recording.

Play Clip

The live image data is stored in a MXG file at the location specified in Program Settings during recording. The clip file is automatically imported into the current project when the recording stops and the Device bar shows it alongside the icon in the **Clips** section. You can click on the clip name to playback the MXG clip file via the Device bar.

Working With The Grid View

The Grid view consists of a grid of live images and one focus window. This grid (tile) structure is ideal for getting a quick overview of **all cameras of a group**. You can drag the camera image that is most interesting to you onto the focus window. Use the controls at the bottom to operate the camera.

Showing a group

To view another group, you can use the Device bar or the Group bar. To do this, either drag and drop the desired group from the Device bar into the display area or click on the desired group in the Group bar. The displayed group is indicated by a yellow bar in the Device bar as well as in the Group bar.



Fig. 66: Showing a group

Working With The Focus Window

At the bottom of the focus window is a Command bar with controls that allow you to operate the **camera in the focus window**. If you move the mouse pointer over the Command bar, further controls are displayed.




Fig. 67: Camera in a focus window

Zooming And Moving Image Sections

Use the slider \bigoplus to zoom. The zoomed image sections can then be moved with the mouse. These actions take place in the application. This means that only the image section of the current live image is modified. The camera will not move and therefore zooming will not affect the possible recording of the generated camera image.

- 1. Drag the slider to zoom in on or out of the live image.
- 2. Move the image with the mouse to focus on individual image sections.

Select predefined image sections.

To quickly focus on a specific image section, you can use one of the factory default image positions that are predefined in the camera.

- Overview , point of interest , preview and detail view
- Top ①, bottom ①, left ②, right ③

Move the slider **Standard** to the next position or until you have found a suitable position.

Accept and end calls.

To talk to visitors at the door, click on . To end an audio connection, click on ...

Opening Doors And Switching Lights

If a camera is connected to a door station and has been configured accordingly, you can open the door by clicking on . If the camera is also connected to a light switch and configured accordingly, the light can be turned on and off by clicking on .

Show Temperature

MOBOTIX cameras have a built-in temperature sensor that measures the temperature inside the housing. If an ExtIO module or an MX-GPS-Box is connected to the camera, you can also measure the ambient temperature of the module or the box and view it by clicking on §.

Executing Hyperlinks

If hyperlinks have been defined and configured, their function can be executed by clicking on \varnothing .

Camera Sequencer

If you want to see a different camera in the focus window, simply drag that camera to the focus window. Note that the camera sequencer can also switch cameras automatically.

Instructions:

- 1. Click on the camera sequencer icon = to activate the automatic switching.
- 2. Right-click on stochange the following settings:
 - **Duration Slider:** Move the slider to the desired duration (1 sec to 60 sec) to show each camera.
 - **Autostart:** Once you switch to the Grid view, the sequencer starts automatically.
 - **Stop at event:** The sequencer stops when an event has occurred, allowing you to further investigate the situation. To start again, click on ➡.
 - **Restart after confirmation:** Activate this option if you want to avoid having to restart the sequencer over and over again.

Group Sequencer

If you want to display a different camera group in the focus window, drag and drop that camera group into the focus window. A grid with all cameras of the group will be displayed and each camera of the group will be shown sequentially in the grids focus window for a defined time. You can automate this camera group change with the group sequencer.

Instructions:

- 1. Click on the group sequencer icon

 to activate the group sequencer.
- 2. To change the sequencer settings right-click on:
 - **Duration:** set the duration to show each group. You can set a value between 1 sec and 60. The "Combined Sequencer" activates the group sequencer together with the camera sequencer ("Autostart" on the camera sequencer is not needed). The group sequencer waits until all cameras on a grid or graphic have been cycled before switching to the next group. When the "Combined Sequencer" is active then the camera sequencers "Stop at Event" and "Restart after Confirmation" also apply to the group sequencer.
 - **Autostart:** Once you switch to the Grid view, the group sequencer will start automatically.

Switching group functions

At the bottom of the program window is a Command bar with controls that change depending on the selected view. In the Grid view, you can use the group buttons of the Command bar to control the functions of a camera group (Prerequisite: Group functions were assigned in the Group Functions dialog box). This means that you can switch on/off lights, open a door and make an announcement for a predefined camera of this group, regardless of the currently displayed camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors.

In addition, you can right-click on the group buttons to open the shortcut menu in order to control cameras

that are not part of the current group. Before you can do this, the cameras have to be set up accordingly, that is, they need to be connected to door openers/light contacts and have to be configured properly.



Fig. 68: Switching group functions

Manually recording live images

In the Grid view as well as in the Live view, you can start manual recording at any time, such as when you observe a suspicious situation that should be recorded. While you keep track of the situation in the live image, the images are recorded and saved as an MXG file. The camera's live image that is in the focus window is always recorded. For this reason, live recording can also only be used in the Grid view when there is a focus window.

Users with administrator rights can specify where the clips are saved and how long the recordings can be in the Program Settings, p. 230 (Mac: menu: MxManagementCenter > Preferences > Live Recorder, Windows menu: File > Settings > Live Recorder).

Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.




Fig. 69: Manually recording live images

Starting And Stopping Recordings

To start recording, click on **Live Recorder**. Recording will stop automatically after the recording time set in the program settings has expired. Just before this time expires, a message will be displayed. You can stop the recording from within this message or extend the set period of time. To stop recording before the time expires, click on again.

Note

The recording ends automatically when switching to another view. However, changing the group within the Grid view will not result in an early termination of the recording, unless that group has no focus window. In the latter case, the recording will end.

Play Clip

The live image data is stored in an MXG file at the location specified in Program Settings during recording. The clip file is automatically imported into the current project when the recording stops and the Device bar shows it alongside the icon in the **Clips** section. You can click on the clip name to playback the *MXG clip file via the Device bar.

Working With the Graphic View

You can define a **floor plan** (ground plan) in the Graphic view and place the cameras or camera groups according to their actual positions. The icon of the corresponding camera turns red in case of an alarm (or

green upon a bell event). A simple click is enough to show the current live image of the triggering camera, allowing you to quickly check the situation.

Temporarily showing the live image of a camera

To temporarily display the live image of a camera, move the mouse pointer over the camera icon. In addition, the live image of another camera group can also be displayed in the Graphic view. Drag & drop the desired camera from the Camera bar onto the floor plan. When changing the view, the live image disappears.

Automatically display all live images of a group

To keep track of all live images in the current group, you can activate the camera sequencer or the group sequencer. When the sequencer is activated, all live images of the camera group are displayed one after another in a small window. You can move this window to any location and enlarge it or make it smaller.

Camera Sequencer

If you want to see a different camera in the focus window, simply drag that camera to the focus window. Note that the camera sequencer can also switch cameras automatically.

Instructions:

- 1. Click on the camera sequencer icon = to activate the automatic switching.
- 2. Right-click on to change the following settings:
 - **Duration Slider:** Move the slider to the desired duration (1 sec to 60 sec) to show each camera.
 - **Autostart:** Once you switch to the Grid view, the sequencer starts automatically.
 - **Stop at event:** The sequencer stops when an event has occurred, allowing you to further investigate the situation. To start again, click on ...
 - **Restart after confirmation:** Activate this option if you want to avoid having to restart the sequencer over and over again.

Group Sequencer

If you want to display a different camera group in the focus window, drag and drop that camera group into the focus window. A grid with all cameras of the group will be displayed and each camera of the group will be shown sequentially in the grids focus window for a defined time. You can automate this camera group change with the group sequencer.

Instructions:

- 1. Click on the group sequencer icon

 to activate the group sequencer.
- 2. To change the sequencer settings right-click on:

- **Duration:** set the duration to show each group. You can set a value between 1 sec and 60. The "Combined Sequencer" activates the group sequencer together with the camera sequencer ("Autostart" on the camera sequencer is not needed). The group sequencer waits until all cameras on a grid or graphic have been cycled before switching to the next group. When the "Combined Sequencer" is active then the camera sequencers "Stop at Event" and "Restart after Confirmation" also apply to the group sequencer.
- **Autostart:** Once you switch to the Grid view, the group sequencer will start automatically.

Switching group functions

At the bottom of the program window is a Command bar with controls that change depending on the selected view. In the Graphic view, you can use the group buttons of the Command bar to control the functions of a camera group (Prerequisite: Group functions were assigned in the Group Functions dialog box). This means that you can switch on/off lights, open a door and make an announcement for a predefined camera of this group, regardless of the currently displayed camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors.

In addition, you can right-click on the group buttons to open the shortcut menu in order to control cameras that are not part of the current group. Before you can do this, the cameras have to be set up accordingly, that is, they need to be connected to door openers/light contacts and have to be configured properly.




Fig. 70: Switching group functions

Operate Door Stations

Door Stations can also be integrated and operated with the MxManagementCenter. For this purpose, Door Station-specific functions are provided in addition to the program functions for cameras.

Note

Door Station functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see:


- Camera Feature Overview, p. 13.
- Door Station Settings, p. 207

Bell Signaling

If someone rings the doorbell, it can be indicated in different places of the application.

Where? Explanation


Alarm bar and Alarm Info bar A bell event is indicated by coloring the Alarm and Alarm info bar green. The prerequisite for this is that the Door Station bell events have been configured as alarms in the **Camera Configuration** dialog. The Alarm bar ① is located at the bottom of the MxManagementCenter and the Alarm Info bar ② below the camera image of the corresponding door camera.



Where? Explanation

Doorbell notification

When the bell is rung, a ringing notification is displayed, no matter which view you are in. The prerequisite for this is that the Door Station bell events were configured as alarms in the **Cam**-



Note


The notification can be temporarily disabled by an administrator by clicking on **Notification**



in the application header.

Counter on The counter next to the bell icon in the Live view is increased by one. the bell

icon



Setting Bell Signaling

Go to Door Station Settings, p. 207 to find out which signaling options can be combined and where they can be configured.

Open Door and Switch Lights

If the door camera has been set up properly, you can use MxMC to open the door and to switch the lights. To do this, use the and keys in the Live view Command bar and in the Command bar of the Grid view focus box.

Working With Multiple Monitors

MxManagementCenter supports the use of multiple monitors. Camera live images can be displayed on monitors directly connected to the computer running MxMC. Camera live images can also be switched to additional display devices using an MxThinClient.

Displaying Live Images On Monitors Connected To The Computer

If several monitors are connected to the computer running MxMC, the live images of individual cameras can be displayed by double-clicking on the different monitors. To do so, double-click either:

- on a camera image in the Camera bar
- on an event image in the Alarm bar

- on a camera image in the Grid view
- or on a camera icon in the Graphic view

and select the monitor on which you want to view the live image.




Fig. 71: Displaying Live Images On Monitors Connected To The Computer

Using MxThinClient To Display Live Images On Additional Monitors

As far as MxMC is concerned, any number of monitors can be connected and operated. However, the number is limited by the graphics card installed in the computer. By using one or more MxThinClient devices, you can increase the number of display devices available for MxMC. This allows you, for example, to switch to additional display devices (monitors or TV sets) by double-clicking on the camera live images from MxMC.

Note

MxThinClient devices are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Adding a MxThinClient

The MxMessageSystem needs to be activated in the Program Settings, p. 230 because the camera live images are connected via this system (Mac: MxManagementCenter > Settings > MxMessageSystem; Windows: File > Settings > MxMessageSystem). Also, make sure that the same parameters are set as in the MxThinClient.

Furthermore, you must make sure that MxThinClient and the computer running MxMC use the same time server.

2. Open the edit mode in the Device bar by clicking on at the bottom of the bar. Next, click on . The **Add and Import** dialog opens.




Fig. 72: Adding a MxThinClient

- 3. Click on . The **MxThinClient Configuration** dialog box opens.
- 4. Enter a name for the MxThinClient that will be shown in the Device bar. You can freely select the name.
- 5. Use the **URL** option to enter the current IP address or DNS domain name.
- 6. Under **Serial Number** you need to enter the factory IP address printed on the MxThinClient housing. Remember that you need to enter the number correctly because it represents the address at which the MxThinClient is accessed in the MxMessageSystem.
- 7. Enter the user name and password you used when installing the MxThinClient.
- 8. Select the resolution that the camera's live image uses when data is sent to the additional display unit. If you select a resolution that is not supported by the display device, the message **Resolution Not Supported** is shown on the display of the display device. In this case, select a lower display resolution.
- 9. Select how long the live camera image will be displayed before the MxThinClient will continue to run in the configured mode.
 - If you select **Unlimited** for the display length, the camera's live image is displayed until the MxTh-inClient receives a new command, such as when an event is triggered based on an event-controlled setting.
 - If you want to stop the display of the camera's live image before the set display length elapses, click on the contact in the

Using MxThinClient

To switch a live camera image to an additional display device, either double-click on the desired camera image or drag and drop the camera image to the appropriate MxThinClient in the **MxThinClient** section of the Device bar.

Notes

The MxThinClient section is only visible in the Device bar if a MxThinClient has been integrated.

You need to possess administrator rights to add, manage or delete an MxThinClient.

Working In Different Network Environments

Using MxManagementCenter, you can access cameras from different locations. For example, you can monitor the cameras at home over the local area network (LAN) or while on the move via a pre-configured DynDNS access over the Internet.

See also: Network Environments

Selecting an Environment

If you want to access the cameras from a different location (different network), select the corresponding previously created environment. Switching to a different environment causes the network address data for connecting to the cameras to be switched automatically.




Fig. 73: Selecting an Environment

- 1. Right-click on in the Header bar. The **Projects and Network Environments** dialog opens.
- 2. Click on **Environment**.

3. Select the desired environment.

Temporarily Adjusting the Bandwidth

By assigning a bandwidth to an environment, you can specify how the images are pulled from the cameras given different connection speeds. This basically controls how the images can be displayed for live viewing and event research. Selecting a bandwidth thus also controls the image quality. Note that you can temporarily overwrite the bandwidth setting without actually changing the camera setting.

- 1. Click on I in the Header bar. The Bandwidth Mode dialog opens.
- 2. Select the desired setting:
 - HiRes: The images are transferred using the settings made in the camera.
 - LoRes: Images are delivered at the frame rate, resolution and image quality as defined in the Program Settings for LoRes.
 - Unchanged: Use this to return to the original setting of the camera.

Alarm Processing


An important component of a video management system is the alarm function. It allows you to specify which events lead to alarms and how you are notified in the event of an alarm. In addition, you can define the alerting behavior for individual time periods in weekly profiles.

Note: Alarm processing functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.

Alarm Notification

Alarm-triggering events can be signaled at various points in the application.

Where?	Explanation
Alarm bar	If alarm notification has been activated in the Camera Configuration, the Alarm and Alarm
and Alarm	Info bars will turn red and will inform you about the events that triggered the alert (green
Info bar	when a bell is rung). The Alarm bar ① is located at the bottom of the MxManagementCenter
	and the Alarm Info bar ② below the camera image of the corresponding camera.




Alarm Notification

In addition, you can choose to receive an alarm message and an alarm sound.

This requires the alarm notification option to be enabled in the Camera Configuration dialog and the **Alarms** checkbox to be set in the **Notifications** section (Mac:


MxManagementCenter > Settings menu, Windows: File > Settings) menu.



and group icon in the Graphic


Camera icon When a camera detects an alarm, the corresponding camera icon turns red ② or green (bell event). You can take a quick glance at the situation observed by the camera by showing a small live image (move mouse pointer over the icon) or by showing a live image on a second monitor, if available (double-click on the camera icon).

If you positioned an additional camera group on the background image (floor plan), the cam-



Setting Up Alarm Notification


The following table describes where and how the notification options can be set.



- 1. To do so, open the Camera Configuration dialog box by right-clicking on the corresponding camera in the Camera bar. Another option is to open the dialog box in the Device bar by clicking on and then
- right-clicking on the corresponding camera. 2. Click on **Alarms**, enable alarm notification and set the events that should trigger an
- alarm.

Alarm Notification

In addition to signaling in the Alarm bar and Alarm Info bar, you can set up a visual and audible alert. Do so by navigating to the notifications (Mac: MxManagementCenter > Settings menu, Windows: File > Settings menu), selecting the Alarms option and then selecting the alarm sound, alarm duration and volume.



Camera icon and group icon in the Graphic view In order for the camera icon and group icon to turn red or green in the Graphics view when an alarm event occurs, the same settings must be made as for notification in the Alarm bar and Alarm Info bar.

Setting time ranges for alarms



In addition, you can select a weekly profile for every event type that should trigger an alarm.

- To do so, open the Camera Configuration dialog box by right-clicking on the corresponding camera in the Camera bar.
 Another option is to open the dialog box in the Device bar by clicking on and then right-clicking on the corresponding camera.
- 2. Make sure that the **Alarms** option has been activated.
- 3. As long as no other weekly profile has been selected, the setting is valid from Monday 00:00 to Sunday 24:00.
- 4. Click on **Edit weekly profiles** to create a weekly profile for an event type. See also Setting Alarm Filters for information on how to create and select a weekly profile.

Filtering Alarm Images

All Alarm images are displayed in the Alarm bar and in the Research view. To get a quick overview, you can filter the display of images according to different criteria.

Filtering Alarm Images In The Alarm Bar ("Filtering The Display Of Alarm Images" section):

The alarm images in the Alarm bar are sorted chronologically. You can filter the display of alarm images by camera, group, event type, and confirmation status.

Filtering the Research view by event types:

All event images of the selected cameras are shown in chronological order. You can filter the view according to event types.

Playing Back Alarm Recordings

You can play the recording of an alarm directly in the Alarm bar ("Playing Back Recordings" section) or directly in the Research view.

Researching in MxMC

This section describes basic research functions of MxMC

Searching And Playing Back In Playback View

Recorded clips cannot only be played in the player, but they can also be searched. The way that you search depends on whether you want to search for specific events within the recorded clips or whether you want to search for events at specific times.

General Playback View controls




Fig. 74: General playback view controls

To search and play back recordings, first activate **Playback** mode or select the date and time and then use the **Previous/Next Image** buttons , to browse the recordings; alternatively, you can start the playback using the **Forward/Backward Playback** buttons . Hold the **Forward/Backward Playback** to select a playback speed between 0.5 times and maximum.

General operation of the Playback View for MOBOTIX MOVE and ONVIF cameras




Fig. 75: General operation of the Playback View for MOBOTIX MOVE and ONVIF cameras

Note

all playback capabilities are supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For these cameras, recordings can only be played forward.

Therefore, first select Date/Time \bigcirc , and then start playback using **Forward Playback** \triangleright \bigcirc .

Performing PTZ actions in recordings



Researching in MxMC

Fig. 76: Performing PTZ actions in recordings

Note

On a secondary monitor, a single camera image can only be zoomed with the mouse wheel or panned with the mouse button pressed down. PTZ controls are only available on the MxMC main screen or on the secondary monitor in Grid View.

You can zoom and move the visible image area not only in live images but also in recorded images (PTZ). This enables you to examine specific image areas more closely while the recorded video stream is playing back. On Dual cameras, the program also shows the ____ slider. Use this slider to show the images of either the right, the left or both image sensors. When playing back the recordings of hemispheric cameras, you can set different display modes ____.

Zooming and moving image sections

You can zoom using the slider or the mouse wheel. To see other image areas, you can move the recorded image using the mouse.

Choosing a sensor

On Dual cameras, you can opt to see the recordings of the right, the left or both image sensors. To do so, move the \bigcirc slider to the right to \bigcirc (left sensor) or further to the right to \bigcirc (right sensor).

Subsequent distortion correction of hemispherical images

When showing recorded images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. Note that this type of correction only takes place locally. This means that the distortion correction of the recorded images only takes place on this computer. The stored recordings (from the camera or a file server) are not influenced in any way.

- **Full image:** Shows the entire (distorted) full image.
- **Normal:** Shows a distortion-corrected image and allows executing PTZ actions.
- Panorama: This option shows the distortion-corrected image of an entire room (corrected 180° panorama view) from the left to the right wall. The aspect ratio (width to height) is 8:3.
- **Surround:** This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This mode only makes sense for a hemispheric camera that is mounted to the ceiling.
- Panorama focus: This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.

Selecting The Distortion Correction Mode

Move the slider o to the right until you see the desired view. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined using the panorama correction. Move the slider to the right to and use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.

Browsing recordings for event images

When searching for event images, first select the image playback type:

- Event images: Only shows event images.
- Pre-event images: Shows only the first recorded image for each event.
- Highlighted images: Shows only the images, which had been marked as important before.

Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.




Fig. 77: Browsing recordings for event images

- 1. In the Playback view, select the Playback mode by right-clicking on (1) and selecting the desired mode (2).
- 2. Browse the recordings using the \square and \square buttons. Starting with the current event image, these buttons show the previous or next event image.

Browsing recordings for a specific date and time

If you have set up a continuous recording for certain times and you want to check for events during those times, for example, you can limit the search to these times. You can search for events at a given time by using time leaps or time-lapse playback.

Searching for a specific date and time




Fig. 78: Searching for a specific date and time

- 1. Click on Date/Time ① and enter the date and time to search for.
- 2. The event image jumps to the event in the recordings that is closest to the specified date and time.
- 3. Click on Playback ⊳.

or

- 1. Click on the **Calendar** slider ②. The date and time will be shown above the slider.
- 2. Move the slider until you reach the date and time that is closest to the point in time you want to examine. The event image jumps to the event in the recordings with the specified date and time. If such a recording is not available, the event image jumps to the event that is closest to the specified point in time (in the direction of searching). In the latter case, the slider turns read the time difference to the specified point in time is shown above the slider.
- 3. Click on Playback ▷.

Note

The farther away you move the mouse pointer from the slider, the more precise your setting will be.

Searching Several Cameras For Persons Or Objects

Scenario: Camera A is overlooking the gate and signals an event. The event image in the Alarm bar shows a delivery truck driving through the gate. You want to know if the truck has also passed the area monitored by camera B.

- 1. To do so, move the mouse pointer over the event image. Three icons are shown.
- 2. Open the Playback view mode by clicking on .
- 3. Play back the recording (end of recording) ①.




Fig. 79: Playback the recording

4. Drag&drop camera B from the camera bar into the Playback view.



5. The playback automatically selects the recording that follows the end of camera A's recording ②. You can continue this process for any number of cameras.

Investigating Multiple Cameras For A Specific Point In Time

You want to know if other cameras have recorded something at a specific point in time:




- 1. Set the reference time using the Pin button ①.
- 2. Drag the cameras from the Camera bar ② one by one.

3. The application shows the event images of each camera that are closest to the specified point in time.

Limiting The Search Range For An Incident

Scenario: Your camera monitors a parking lot from which a car had been stolen during the day. Follow these steps to locate the event as quickly as possible:


- 1. Start the Playback mode (right-click on) and select an interval (e.g., 1 day).
- 2. Keep clicking on **Previous Image** until the car can be seen again in the image.



- 3. Now select a shorter interval (e.g., 1 hour ...).
- 4. Keep clicking on **Next Image** ⋈ until the car has left the frame.
- 5. Keep on using shorter intervals until you have found the exact point in time of the incident.

Note

You can also use the **Forward/Backward Playback** / buttons to play back using the same time leaps.



Note

This feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.


Playing Back Recordings

Playing Clips

To play the clips, the play buttons $\triangleleft \triangleleft \bigcirc \triangleright \triangleright$ and the playback mode are available in the Command bar of the Playback view. First set the desired mode for playing the recordings, such as event images only or with one hour time-lapse, in the **Playback mode**.

Next, use the **Playback Buttons** to browse and play back the images one-by-one or continuously in backward or forward direction.

Note: As mentioned in General Operation Of The Playback View For MOBOTIX MOVE And ONVIF Cameras, playback of recordings is limited when using MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. Recordings of these cameras can only be played forward. For an overview of how the camera functions differ, see Camera Feature Overview.




The following table summarizes the actions that you can perform with the playback buttons, depending on the playback mode:

	Playback Mode		Playback Buttons
	Complete Record-	\bowtie	Jumps one image backward/forward.
	ings	$\triangleleft \triangleright$	Plays back all recordings backward/forward.
5	Event Recording	\bowtie	Jumps to the end/the start of the recorded sequence.
		$\triangleleft \triangleright$	Plays back until the start/the end of the recorded sequence has been reached.
4	Event Images	\bowtie	Shows the previous/next image every time you click on the button.
€\$	Pre-alarm Images		
₽ <u>~</u>	Highlighted Images	$\triangleleft \triangleright$	The previous/next images are shown automatically one after the other.
(*	1 day time lapse		
(60 <u>:</u>	1 hour time lapse		
(10):	10 minute time lapse		
(j:	1-minute time lapses	-	

Setting The Playback Speed

The **Playback Speed** option allows you to speed up or slow down the playback of a recording. This also applies if you play back a recording backward.



- 1. Click on **Playback Speed**. The background of the button turns dark gray.
- 2. To play the recording forward, left-click and hold the left mouse button and move the mouse pointer to the right. The further you move the mouse pointer down (to the right), the faster the playback speed.
- 3. To play the recording backward, left-click and hold the left mouse button and move the mouse pointer to the left. Again, the further you move the mouse pointer down (to the left), the faster the playback speed.

Precise Positioning by Image

Searching And Playing Back In The Grid Playback

If a camera registers an event and you want to know if and what other cameras in that camera group were recording at that time, you can use Grid Playback to view the recordings of multiple cameras synchronously. The camera in the focus window is the lead camera. So, if you are browsing the recordings on this camera to find events or specific situations or if you are playing back recordings, the other cameras will follow the leading camera as soon as playback is paused. The program always shows the event images that are closest to the time stamp of the leading camera. If the time of the other cameras differs from the leading camera, the difference will be displayed at the lower border of the event images.




Fig. 80: Grid Playback

- 1. Open Grid Playback by right-clicking on the Navigation button and selecting Grid Playback.
- 2. Drag the desired camera group from the group bar.



- 3. Use the time stamp in the focus window \bigcirc or the calendar slider \bigcirc to set the time.
- 4. All cameras jump to the event image that is closest to the specified point in time. The time stamp beneath each camera image shows the time and date of the image. The difference to the reference time is shown at the right.

Note

You can also use the Grid Playback by dragging a group onto the Playback view. The original camera will be shown in the focus window.

Searching And Playing Back In The Research View

Use the Research view to search all recorded event images at once. You can filter the results by event type, that is, by bell events or by motion events to get a quick overview. Or you can reduce the results to the event you have marked as "important" in the Playback view. The search results are displayed as preview images including camera name, time stamp and type of event trigger. Note that you can play back the recording to an event directly from the event image. Double-click on the event image to open the Playback view and to start playing back the recording.

Note:

The Research view is not available for MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Displaying Camera Event Images



Fig. 81: Displaying camera event images

Open the Camera bar by clicking on the upper gray frame border. Drag and drop the camera image of the desired camera into the image area of the view. The event images of this camera are displayed. Another option is to: You can also drag and drop the desired camera image from the Device bar.

Loading Additional Event Images

Sometimes, the number of recordings of a camera is quite large. In such a case, loading all event images would take very long. To avoid this, only the latest events are loaded by default. However, you can manually load the remaining images. Click on **Load More** to do so.

Displaying Camera Group Event Images



Fig. 82: Displaying camera group event images

Open the Group or Camera bar by clicking on the upper gray frame border. Click on the frame border again to switch to the camera Group view. Drag&drop the icon image of the desired camera group into the display area of the view. The event images of the individual cameras in the camera group are displayed. Another option is to drag and drop the desired camera group from the Device bar.

Filtering By Event Types

Initially, the event images of the selected cameras are sorted by time. You can filter the view according to event types.




Fig. 83: Filtering by event types

Open the dialog for the respective event type by right-clicking on the corresponding icon in the Command bar. Then select one or more events. The display of events is filtered according to the selection.

Event Types	Subcategories	Explanation
Image Ana- lysis Events	MxActivitySensor	Triggered by continuous movement of people or objects in certain image areas.
	Video Motion Sensor	Triggered by movements in predefined motion windows.
	Behavioral Detection	The sensor reacts to different behavior profiles of the tracked objects in the image. Triggered by deviations from the recorded behavioral profiles.
Environment Events	Shock Detector	Triggered by shocks on the camera (e.g., vandalism).
	Illumination	Triggered by exceeding or falling below the specified illumination.
	Microphone	Triggered by exceeding the set volume of the sounds picked up by the microphone.
	PIR Sensor	The passive infrared sensor registers objects with a heat signature moving within the sensor area. Triggered by exceeding the set threshold.
	Temperature	Triggered by exceeding or falling below certain temperature thresholds.
Internal Events	Action Group Ter- mination	Triggered by the completed execution of an action group.
	Custom Signal State	Triggered by state changes of user-defined signals.
	Recording	Triggered by state changes of the recording (start, end, etc.).
News Events	IP Receive	Triggered by receiving a network message via TCP/IP.
	MxMessageSystem	Triggered by receiving a message from the MxMessageSystem via the MxBus or from the network.
Meta Events	Event Counter	Triggered by the quantitative evaluation of other events.

<u>@</u>		
	Logical AND Event	Triggered by the simultaneous occurrence of multiple events.
	Event Logic	Triggered by the order of occurrence of events.
Signal Events	Signal Input	The camera's signal inputs can trigger events. For example, you can connect the door bell with the signal input so that an event is triggered when the bell is rung.
	User Click	Triggered by clicking on the User Click softbutton.
Time Events	Periodic Event	Triggered by periodically recurring events.
	Random Event	Triggered by a random time with a predefined expected frequency.
	Time Task Event	Triggers at fixed points in time.
Door Station Events	Ringing event	Triggered by activation of the door bell.
	Mailbox Message	Triggered by leaving a voice mailbox message.
	Door Station Events	Triggered by opening the door.
	RFID Card Rejec- ted	Triggered by the use of an invalid RFID card.
	PIN denied	Triggered by entering a wrong PIN.

Marking Events

When browsing event images, you can right-click on an image to mark the event as "important." The same applies to events that you have marked as "important" in the Playback view or in the Alarm bar: You can view them as a collection in the Research view.

Playing Back Events

Instant Playback:

You can watch the recording of an event directly in the event image (instant playback). To do so, move the mouse pointer over the image. Three icons appear. Click on to start the playback.

Note:

A click into the image after starting the playback opens the recording in full screen mode in the current program window.

Playback View:

You can also play back the recording in the Playback view. To do so, move the mouse pointer over the event image. Click on to switch to the Playback view.

Searching And Playing Back Door Events

Door Station-specific events and recordings can be searched for and played back with MxMC, just like all other events and recordings. However, there are some small differences, which are discussed in more detail below.

Note

Door Station functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.


Watching and Playing Doorbell Recordings

Bell Settings

If there were visitors ringing in your absence, you will see this by checking the counter near the Bell Settings ① in Live view.

Note

The number displayed in the counter depends on the filter settings configured in the Alarm bar.



- 1. Click on to see who has rung. Instead of the live image, the event image for the last bell activation is displayed, and a red slider with the number "1" is displayed on the right side of the multislider ②.
- 2. If there are several doorbell recordings, click on the red slider and drag it to the left until the next higher number is displayed in the slider. At the same time, the event image also changes to the image of the previous bell activation.
- 3. To play the respective doorbell recording, click on ☐ again. The view switches to the Playback view.

 Click on ☐. The recording is played back.

Alarm Bar

A missed bell activation is also indicated by a green Alarm bar. This only happens if the **Alarms** option has been enabled for the corresponding cameras in the **Camera Configuration** dialog and if the bell event has been selected as an alarm triggering event. When the Alarm bar is opened, a green bar below the event image indicates a missed bell activation. You can watch the recording of the missed bell activation directly in the Alarm bar using the **Instant Playback** function.




- 1. To do so, move the mouse pointer over the event image. Three icons appear. Click on . The recording is played back directly in the Alarm bar.
- 2. You can also jump from the Alarm bar directly to the recording in the Playback view and play it back without having to search for it there. To do this, move the mouse pointer over the event image once again and click on .

Viewing and Listening to Voice Mailbox Messages

Voice Mailbox Messages

If visitors have left messages in your absence, this is indicated by the counter next to the voice mailbox messages (1) in the Live view.



- 1. Click on to see who left a message. Instead of the live image, the event image for the last message is displayed, and a red slider with the number "1" is displayed on the right side of the multislider ②.
- 2. If there are several messages, click on the red slider and drag it to the left until the next higher number is displayed in the slider. At the same time, the event image also changes to the image of the previous message.
- 3. To play and listen to the respective message, click on ☑ again. The view switches to the Playback view. Click on ☑. The recording is played back.

Alarm Bar

A voice mailbox message is also signaled to you in the Alarm bar by turning red, and the new event image is marked with the icon. This only happens if the **Alarms** option has been enabled for the corresponding cameras in the **Camera Configuration** dialog and if the voice mailbox message has been selected as an alarm triggering event. To play back the message, move the mouse pointer over the event image. Three icons appear. Click on . The message is played directly in the Alarm bar.



Searching and Playing Back Door Events

Like all events, door-specific events (e.g., attempts to open a door with an invalid PIN) can also be searched and played back. Various options are available: Playback View, Grid Playback and Research View.

Exporting Recordings

Using the Playback view, you can export recorded video data from one camera, while the Grid Playback allows exporting from several cameras at once. Use the Export bar to combine several clips to one export. You can save individual images with the **Snapshot** function.

Saving Snapshot Images

Snapshot images can be created in the Live and the Playback views for the displayed camera, and in the Grid view and Grid Playback for all displayed cameras.




Fig. 84: Saving Snapshot Images

To do so, click on the **Snapshot** button in the Command bar. By default, images are saved in the image folder of the user account. The destination path and the image settings for saved images can be selected via the **MxManagementCenter > Settings > Snapshot Images** (Mac) or **File > Settings > Snapshot Images** (Windows) menu item.


Exporting Camera Recordings

The Playback view allows setting a time range for a recording (event recording or continuous recording) in order to select it for exporting.

- 1. Open the Playback view.
- 2. Drag the desired camera from the Camera bar or the Device bar.
- 3. Find the start of the relevant recording.
- 4. Specify the export range. There are two possibilities for this export:

Select export range using visual markers:

- 1. Mark the start of the clip by clicking on the gray flag on the left .
- 2. Play the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right. Both flags are now green.
- 3. Click on **Export** and select the export profile.




4. The Export dialog box appears. Select a target folder and enter a file name.

Manually capture export range:

First, make sure that no export area has yet been set using the "export flag." If an export area has already been defined, you can delete it. Do so by right-clicking on a flag and selecting **Delete Time Range**.

1. Click on **Export** . Then click on the desired export profile ①. The dialog box used for defining the export range appears.



- 2. Specify the export range ②.
- 3. Click on **OK** and then on **Save**.

Note

If you select the **Automatically Import After Export** checkbox in the Export dialog, the exported clip will be automatically added to the Camera bar and in the Device bar to the **Clips & Recordings** section.

Exporting Camera Group Recordings

The Grid Playback allows for setting a time range for a recording (event or continuous recording) in order to select it for exporting from multiple cameras.

- 1. Open the Grid Playback.
- 2. Drag & drop the desired camera group from the Group bar or the Device bar.
- 3. Find the start of the relevant recording for the camera in the focus window. At the same, the search is extended to the other cameras in the group, and the recordings with the closest relevance to those in the focus window recording will be displayed in the tiles.
- 4. Specify the export range. There are two possibilities for this export:

Select export range using visual markers:

- 1. Mark the start of the clip by clicking on the gray flag on the left .
- 2. Play the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right. Both flags are now green.

- 3. Instead of exporting all cameras of this group, you can also select one or more cameras for exporting. To do so, right-click on **Export**. A circle appears on the camera images in the top left corner. Select the desired cameras by clicking on the corresponding circles ①.
- 4. Then click on **Export** and select the export profile ②. The Export dialog box appears.



Fig. 85: Select export range using visual markers

5. Select a target folder and enter a file name.

Manually capture export range:

Make sure that no export area has yet been set using the "export flag." If an export area has already been set, you can delete it. Do so by right-clicking on a flag and selecting **Delete Time Range**.

- 1. Before you define the export range, you can limit the selection if you do not want to export all of the recordings that appear in the tiles. To do so, right-click on **Export** . A circle appears on the tiles in the top left corner. Select the desired cameras by clicking on the corresponding circles ①.
- 2. Click on **Export** and select the export profile ②. The dialog box used for defining the export range appears.



Fig. 86: Manually capture export range

- 3. Specify the export range ③.
- 4. Click on **OK** and then on **Save**.

Note: Automatic Import

If you activate the **Automatically Import After Export** option, the exported clips are automatically added to the Group bar.

Exporting Recordings From The Export Bar

The Export bar provides a quick and easy way to take camera recordings and MXG clips by dragging and dropping and create a list of recordings for subsequent exporting. From the bar, you can export recording time ranges as combined clips. You can add the clips in the Playback view, in Grid Playback, in the Research view and in the Retail view. After an export, the clips are not deleted automatically. It is deleted when the program is closed.

Adding Clips for Exporting in the Playback View

- 1. Drag the desired camera or the desired clip from the camera bar or from the Device bar.
- 2. Find the recording you are interested in.




Fig. 87: Adding Clips for Exporting in the Playback View

- 3. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green ①.

 You can set the end marker first (gray flag on the right), then play the recording from the beginning so
 - you can set the start marker (gray flag on the left) at the desired point.
- 4. Click on the image of the recording and maintain the position until you see a scaled-down image of the recording ②.
- 5. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there.

Adding Clips for Exporting in Grid Playback

The Export bar in Grid Playback is useful for combining **sequential time ranges** of different cameras.

- 1. Drag the desired camera to the focus window in the grid and find the relevant recording.
- 2. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green.
- 3. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there.

- 4. After you have set the end marker of the time range, the recordings of all other cameras will reposition to show the same time. Drag the camera with the next recording in the sequence of events into the focus window. Mark the start and the end of the clip as described above, then drag the recording into the Export bar.
- 5. Repeat these steps until you have added all recordings you want to export.

You can also add time ranges from several cameras in the Export bar.

- 1. Simply drag the desired camera group from the Group bar or from the Device bar and search for the relevant recording.
- 2. Mark the start and the end of the clip as described above. The recordings of the other cameras will reposition accordingly.
- 3. Right-click on **Export**. A selection box with a checkmark appears in the top left corner of the recordings. If you do not want to add the recording range of a specific camera to the list, uncheck the selection box for that camera.
- 4. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Export bar will open automatically, allowing you to save the image there. The selected clips will be copied to the Export bar.
- 5. Repeat these steps until you have added all time ranges you want to export.

Adding Clips for Exporting in the Research View

In the Research view, you can add recorded event sequences to the list. The length of the event sequences is currently 10 seconds.

- 1. Set filters by camera, by group or by event type as needed.
- 2. Right-click on **Export**. A selection box appears on the event images in the top left corner. Select the desired events by clicking on the corresponding selection boxes.
- 4. If needed, you can set new filters and add more event images to the Export bar.

Adding Clips for Exporting in the Smart Data View

You can add clips for the individual Smart Data transactions to the Export bar. The default clip length is ten seconds on either side of the transaction time stamp, that is, for a total of 20 seconds.

1. Right-click on **Export** . A selection box appears on the preview images in the top left corner. Select the desired transactions by clicking on the corresponding selection boxes.


2. Open the Export bar by clicking on the lower frame border of the open Alarm bar. Click on an preview image and maintain the position until you see a scaled-down preview image. Drag this image to the Export bar. The clips of all selected preview images are added to the Export bar. An alternative option is: In the Export bar, click on ____. The clips of all selected preview images are added to the Export bar.

You can also add clips for the individual preview images of the selected transaction to the Export bar:

1. Drag the transaction preview image in the **Preview Image** section and drop it on the Export bar.


Editing Clips

If you have added a recording to the Export bar for which you previously used distortion correction or zoom features during playback, you can choose to export the clip with or without zoom. Likewise, you can export the clip with or without audio. To do so, move the mouse pointer over the recording in the Export bar. Three icons appear:



- Clip is exported with zoom.Click on to export the clip without zoom. The icon is disabled.
- O: Note that you can play back the individual clips directly in the Export bar before exporting. Click on to do so.

Right-click on a clip to open a context menu with these functions: Manually adjust time range, activate/deactivate audio and zoom for all clips, duplicate a clip, delete one or all clips.



Exporting Clips

Click on **Export**, then select MOBOTIX to export an MXG clip. Select a different profile to create an AVI, MP4 or MKV file. However, depending on the data source (e.g. MOBOTIX NAS) not all export profiles are available.

Select a destination path in the Export dialog and enter a file name. Activate the **Automatically Import After Export** checkbox in the file selection dialog to automatically add the MXG clips to the Export bar after exporting.

Special Search Functions

There are several special functions available for searching records.

Note:

These special features are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.

Searching With Post Video Motion Detection (Post VM)

Post video motion detection (Post VM) is added to MxMC by default as a plug in. Searching With Post Video Motion Detection (Post VM), p. 185 allows searching recordings for changes in one or more image areas of a camera. To open the function, right-click in the Playback view or in the Grid Playback on the plug in button in the Command bar and then select **Post Video Motion Detection**




Fig. 88: Post video motion detection

Histogram: Graphical Representation Of The Frequency Distribution Of Events

The histogram in the Histogram bar illustrates the distribution of the event frequency and thus provides a quick overview of the events of one or more cameras. Open the Histogram bar by clicking on the dark gray border on the **right margin** of the MxMC (see The Histogram: Graphical Representation Of The Frequency Distribution Of Events, p. 188).




Fig. 89: Histogram bar

Smart Data-System: Transaction data in combination with video surveillance

With the MOBOTIX Smart Data System, transactions in MxMC can be linked to the video recordings made at the time of the transactions. It enables you to quickly find and review any suspicious activities. This makes it easy to find and review suspicious activity (see Smart Data-System, p. 190).

Note:

In order to use the MOBOTIX Smart Data System, you must purchase a Smart Data License.



Fig. 90: Smart Data System

Searching With Post Video Motion Detection (Post VM)

The post video motion detection allows searching recordings for changes in one or more image areas of a camera. This is done with the help of "motion windows."

Creating motion windows

1. Open the context menu of the plug in by right-clicking on . Select **Post Video Motion detection**. The dialog for setting up the post VM settings opens.




Fig. 91: Creating motion windows

- 2. Click on in the image area on the right-hand side of the settings dialog. A new window with a predefined video motion window opens.
- 3. You can execute the following commands:
 - Modify the size of the video motion window: By moving the sides or the corners of the window.
 - Create additional video motion windows: Draw a new window with the mouse.
 - Duplicate a video motion window: Click on ♠.
 - Delete a video motion window: Click on 💫.
 - Deactivate a video motion window: Click on

To close the editor window, click on in the top right corner of the window.

Setting the trigger conditions

The Post VM window provides options for setting different parameters that influence the motion detection results.



Fig. 92: Setting the trigger conditions

■ **Trigger level:** (White bar in diagram)

Controls the trigger threshold of the video motion windows. Move the bar to the bottom to recognize a movement if only a few pixels change from one image to the next. Move the bar to the top to recognize a movement only if many pixels change.

Sensitivity:

This setting controls how large the change of each pixel in a video motion window must be to count as movement. Together with a low threshold value, this setting can be used to fine-tune video motion detection. If you move the slider to the right, the detection sensitivity increases, i.e., even smaller changes will trigger the detection.

Correct Changes in Illumination:

Activate this option to avoid false alarms, such as when lighting conditions change rapidly (for example, from sun to a cloudy sky).

Deadtime:

This sets the amount of time after the last detected post video motion event, during which pixel changes in a video motion window are ignored.

■ Ø Median Value:

Enter a long duration (2.0 sec., for example) to improve the detection of slow movements. **Note:** Setting a value that is too high can lead to smears in the preview window.

Color Filter:

Select a color to limit the motion detection to a specific range or colors. The Post VM event will trigger if this color changes during post video motion detection.

Searching for changes in Video Motion Windows

Once you have defined the video motion windows and have set the trigger conditions, you can search the recordings for changes in the video motion windows. Use the playback buttons in the command bar at the bottom.

It is best to use the **Backward/Forward playback** buttons when searching continuous recordings. For searching in event images, use the **Previous/Next image** buttons. If MxMC detects a change within a video motion window, the frame of that window turns red and the search stops.

The Histogram: Graphical Representation Of The Frequency Distribution Of Events

The histogram illustrates the **distribution of event frequency** and thus provides a quick overview of the events of one or more cameras.

Opening The Histogram Bar

To open the Histogram bar, click on the dark gray ribbon on the right margin of the MxMC. To begin with, the histogram always shows the entire range of the events logged by the camera.



Fig. 93: Opening the histogram bar

Working With The Histogram

Structure Of The Histogram

The histogram is split into the overview area on the top and the zoomed area of the selected range below.

The yellow scroll bar in the overview area shows the range that is displayed in the zoomed area. Click on 🕙



to set the displayed time range in the zoomed area (for example, six hours or one day). If you have set the zoomed area to \bigcirc "Custom," you can modify the displayed time range by dragging the edges of the scroll bar.

If you want to see only events in the zoomed area that have triggered recordings, click on \mathcal{F} . The pink area indicates the time range for which recordings exist for the logged events.

Note

The range of logged events may reach farther back than the recordings.




Fig. 94: Histogram bar in details

User interface elements in the histogram

- 1: Resolution of zoomed area (high / low), S set zoom range (custom or pre-defined), \cancel{F}
- 2: Zoomed area
- ③: Overview area
- 4: Current time marker
- (5): Event type and camera / camera group
- 6: Time range with recordings
- ①: Time range in zoomed area

Displayed Time Range

The timestamps at the top and bottom of the histogram show the first and the last of the available events logged by the camera, respectively. You can change this range manually. A small cross at the left of the time range indicates that it has been changed manually. Click on the cross to reset the timestamps to their original values.

Filter Feature

You can filter the display by camera, by group or by event type. There two sliders for this purpose: the group/camera slider and the event type slider . To set the filters, move the sliders until you see the desired results. The following filters are available:

■ Camera filter

- all cameras
- en cameras from the current group
- current camera

Event filter

- MxActivitySensor event
- R video motion events
- PIR events
- microphone events
- signal input events
- temperature events
- illumination events
- bell events
- voice mailbox messages
- Door Station events
- (C) RFID rejected
- PIN rejected
- all event types

Distribution Of Frequency

The length of the bars indicates the frequency of logged events per time unit. Click on to examine the distribution of frequency for a specific point in time in more detail. The display switches to a higher resolution. For more detailed information on a specific point in time with a high event frequency, click on the related spot in the zoomed area or the overview area.

In the Playback view, a red marker is also displayed to indicate the current position.

Smart Data-System

With the MOBOTIX Smart Data System, transaction data can be linked to the video recordings made at the time of the transactions. Smart Data source can be e.g. MOBOTIX P7 Apps (no license required) or general Smart Data sources (license required) like POS systems or license plate recognition systems.

The Smart Data System enables you to quickly find and review any suspicious activities. The Smart Data Bar and the The Smart Data View, p. 70 are available for searching and analyzing transactions. The **Smart Data Bar** provides a direct overview of the most recent transactions (from the last 24 hours) and for this reason it is convenient to use it for reviews and searches.


Smart Data Sources can be added and configured in the The Components View, p. 70.

Overview of recent transactions in the Smart Data Bar

The Smart Data Bar provides a direct overview of the most recent transactions (from the last 24 hours) and for this reason it is convenient to use it for reviews and searches.

Opening the Smart Data Bar

The Smart Data Bar is available in all views. To open the Smart Data Bar, click on the right frame border of the application. The Histogram bar will appear. Click on the frame border again to switch to the Smart Data



Bar. You can also open it from the menu (View > Smart Data Bar).

Fig. 95: Smart Data view

Using the Smart Data Bar

If a Smart Data Source, e.g. a cashpoint is transmitting new data to the camera, the Smart Data Bar is automatically updated. It enables live surveillance of the cash point and of the retail data of a camera. You can group transactions that belong together and display them.

- **Displayed time range:** The Smart Data Bar only contains the data from the last 24 hours. You can search data that is older than 24 hours in the Smart Data-System, p. 190.
- **Search feature/Filter feature:** You can filter the entries for each cash point's camera by search term. The hits are highlighted in yellow. You can jump to the next/previous search result using the two arrows on the lower edge.
- **Do not show system transactions:** By default, the Smart Data Bar shows all transaction that are stored on the corresponding camera. Some of the transactions, e.g. from a cash point, show purchases and events that are directly associated with the purchases, such as the "Total sum." Other transactions show only administrative events, such as when the cashier logs on. Click on to enable/disable display of system transactions.
- **Do not group receipts (for VECTRON cashpoints only):** Transactions are grouped by receipt number or purchase by default. Individual sales can be grouped if the cash point signals the conclusion of the transactions by creating a receipt number. Counter sales can be grouped by counter if the counter is settled in the cash point system. Click on to disable display by groups. The data will be reloaded.
- **Playback transactions:** Open the Playback view by double-clicking on a transaction line. The transaction will be played back.

Detailed search and analysis in the Smart Data View

You can search and filter data of one or more Smart Data cameras in the Smart Data View.



Fig. 96: Searching in Smart Data view

Defining Search Queries

You can define and store several search queries. Enter a name for each search. The search query will be automatically saved every time the search criteria are changed. This also happens when individual search parameters and terms are changed.

- 1. By default there is one search query already. Click on the tab and enter the desired name.
- 2. Select the desired Smart Data Source. You can select more than one or even all Smart Data Sources for a search query.
- 3. Specify the period of time for the search. You can also enter a period of time that allows you to enter any start and end time stamp, in addition to a series of preset time windows (including "today").
- 4. You define the search criteria to limit the scope of the search once you have selected the Smart Data Sources and defined the period of time for the search. Click on to do so. A new line will be inserted. The individual criteria can be linked using AND or OR. The logical search operators can only be applied to all search criteria at the same time. Select to link the search criteria using AND and to link them using OR.

Note that the search criteria apply only at the level of individual line items, such as a search for a total of > 100 and < 150. For the time being, it is not possible to apply the search to all the line items of a report, for example, finding a specific item linked to a total amount of > 100.

- 5. Click on 🗑 to delete a search criterion.
- 6. Click on + to define further search queries, in addition to the most recent search query. Enter a name and repeat steps 1–5.

Deleting Search Queries

Click on to the left of the name for the search query to delete a search query.

Reloading Searches

A new search is performed on the transaction data on the camera with the filter when the search query is reloaded. The search results are displayed again. Click on to reload a search query.

Displaying Search Results

The search results are displayed with preview images in a list with a detailed display of the cash point data or in tiles, depending on the selected display format from the Command bar (List view).

Integrating MOBOTIX storage device

With the MxManagementCenter, you can access a MOBOTIX storage device connected to the USB port with recordings in MxFFS format (see Adding Devices and Sources). To do this, MxManagementCenter must be started with administrator rights. Without administrator rights, the storage medium will not be recognized.

Note: To remove an SD card from a MOBOTIX camera, refer to the camera manual.

MAC

The following procedure assumes that the logged on user is allowed to manage the computer or has the required administrator privileges. Otherwise, contact your system administrator.

- 1. Connect the MOBOTIX storage device with a USB port to your MAC.
- 2. Start the **Terminal App** (e.g. via the spotlight search with CMD+space key).





Fig. 97: Starting the Terminal App


- 3. Enter the following command line: **sudo "/Ap- plications/MxManagementCenter.app/Contents/MacOS/MxManagementCenter"**. Confirm with ENTER.
- 4. Enter the password for the current user. Confirm with ENTER.



Terminal

MxManagementCenter starts with the administrator profile and is not yet configured, as with a new installation.

4. Start a new project.



MxMC in administrator profile

5. Open the editing mode by clicking on
at the bottom of the device bar.

6. Click . The Add and Import menu opens.




Fig. 98: Add / Import menu

7. Click **MxFFS Medium**. The USB ports are searched for storage media that contain recordings in MxFFS format.

Note:

This process can take several minutes for data carriers with large storage volumes.

Windows

The following procedure assumes that the logged on user is allowed to manage the computer or has the required administrator privileges. Otherwise, contact your system administrator.

- 1. Connect the MOBOTIX storage device with a USB port to your MAC.
- 2. Right-click the executable file or a shortcut of the MxManagementCenter.




Fig. 99: Windows start menu

3. If necessary, activate the User Account Control query with Yes.




Fig. 100: Windows User Account control


MxManagementCenter starts with the administrator profile and is not yet configured, as with a new installation.

4. Start a new project.



MxMC in administrator profile

6. Click . The **Add and Import** menu opens.



Add / Import menu

7. Click **MxFFS Medium**. The USB ports are searched for storage media that contain recordings in MxFFS format.

Note

This process can take several minutes for data carriers with large storage volumes.



Management

This section addresses **administrators** who manage a system using MxMC.

Topics	Explanation
Group Views, p. 200	Editing the layout of the Grid view, editing the layout of the Graphic view, assigning group functions, storing information for a camera group, limiting the frame rate of live images
Door Station Settings, p. 207	Bell settings, voice mailbox settings
Network Environments, p. 213	Create and manage environments, customize network data for each environment
Cameras And Camera Groups, p. 215	Manage cameras, manage camera groups, integrate and manage third-party cameras
User Management, p. 227	General user rights, manage user rights
Program Settings, p. 230	General settings, network, software update, notifications, monitoring, audio, data volume, caches, snapshot images, live recorders, remote control, joystick PTZ, MxMessageSystem
Checking System Security, p. 258	Maintenance functions, security functions
License Management, p. 366	Activate licenses, manage licenses

Group Views

After the initial installation, adjustments of the group views may be necessary. This section contains information about more detailed Grid and Graphic view configurations as well as general group parameters.

Editing the Grid View layout

When creating the camera groups, the Grid layout - the grid in which the cameras are arranged - is created based on default values that can be customized. To do so, click in the Command bar or in the Device bar. The Command bar then displays several controls for configuring the grid layout.



Fig. 101: Editing the Grid View layout

As a first step, before you change the format of the camera images or the size of the focus window, decide whether the grid layout should automatically adjust when you resize the window, or whether you want to manually define the size of the tiles and their position.

Using Auto Grid Mode

The auto grid mode is used by default. In auto grid mode, MxMC always tries to distribute the available space as well as possible according to the specified aspect ratio of cameras images (4:3, 16:9, 8:3), the size of the focus window and the number of cameras. This causes the grid layout to **automatically** adapt to any changes. In auto grid mode, the following sliders are available for changing the grid layout:

- 8:3 = Format of the camera images and the focus window (4:3, 16:9, 8:3)
- 3x =Size of the focus window (1x, 2x, ..., 8x the size of the camera images)
- 16 = Maximum number of cameras

Move the sliders to the desired settings. To close the edit mode, click on

Selecting manual mode

In manual mode , you set the size of the individual tiles and their position based on the selected format of the camera images (4:3, 16:9, 8:3). In contrast to auto grid mode, the layout is not adjusted automatically in manual mode. To switch from auto grid mode to manual mode, move the slider to the right until you reach the position . The following sliders are available in manual mode:

- 8:3 = Format of the camera images and the focus window (4:3, 16:9, 8:3)
- 16 = Maximum number of cameras
- 1. Move the sliders to the desired settings.
- 2. To move a tile to a different position, move the mouse pointer over the tile. Click on
 and drag the tile onto the desired position. For better orientation, a blue frame indicates the target position.
- 3. To set the size of a tile based on the selected format, move the mouse pointer over the border of the tile until a double arrow is shown. Drag the tile to the desired size.
- 4. To close the edit mode, click on .

Editing the Graphic View layout

Changing the camera position on the background image

In the Graphic view, you can define background images such as a floor plan or a plan layout. You can then arrange the cameras of the group on these according to their actual position. When opening the Graphic view of a camera group for the first time, all cameras of the group are shown as an icon 3 at the right-hand margin of the background image ①.

To adjust the position of the cameras, open the edit mode ② by clicking on . Move the mouse pointer over the camera image. Two icons are shown ③. Click on ③ and drag the camera icon to the desired location. To close the edit mode, click on . When you exit the edit mode, the changed settings are saved automatically.




Fig. 102: Changing the camera position on the background image

Editing camera icons

You can change the icon size and rotate the icons to reflect the viewing direction and the angle of view of the cameras.

Open the edit mode ① by clicking on 👸. Move the mouse pointer over the camera image. A dotted line in

the shape of a square is shown around the camera icon. To make the camera icon larger or smaller, click on the right or bottom left corner of the square and pull it inwards or outwards ②. To change the orientation of the camera icon, hover the mouse pointer over the icon until a hand is displayed. Hold down the mouse button and turn the camera icon around its own axis until you are satisfied with the orientation. To close the edit mode, click on Men you exit the edit mode, the changed settings are saved automatically.




Fig. 103: Editing camera icons

Dragging additional camera group onto the background image

You can position additional camera groups on the background image (floor plan) of a camera group. If a camera of an added camera group detects an event and the Background Alarm has been enabled for this camera, the camera group icon turns red or green (bell event). Click on the group icon to open the Grid view of the camera group.



Fig. 104: Dragging additional camera group onto the background image

Open the edit mode and drag the desired camera group(s) from the Group or Camera bar onto the floor plan. To close the edit mode, click on . When you exit the edit mode, the changed settings are saved automatically.

Positioning controls on the background image

The Command bar at the bottom of the Graphic view contains several controls. If a camera has been set up to control a light, for example, you can switch the lights of this camera in the Graphic view. You can drag these controls onto the background image (floor plan) and simply click on them to execute the corresponding function for easier operation later on.




Fig. 105: Positioning controls on the background image

Open the edit mode . To open the shortcut menu, right-click on the desired operating function. Then drag the control to the floor plan with the mouse pointer. To close the edit mode, click on . When you exit the edit mode, the changed settings are saved automatically.

Assigning group functions

Note

Group functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

In the Grid, Graphic and Info view, you can use group functions to turn on a light, open a door, or make an announcement for one camera in the currently selected group.

In addition, the **Switch Light** and **Open Door** group functions can be assigned to multiple cameras, so you can switch multiple lights or open multiple doors at once with a single click.




Fig. 106: Assigning group functions

Proceed as follows to assign group functions:

- 1. Open the edit mode in the Device bar by clicking on at the bottom of the bar.
- 2. To do so, move the mouse pointer over the group name. Three icons appear. Click on . The **Group Functions** dialog opens.
- 3. Assign the desired functions to the cameras by activating the respective checkboxes.
- 4. Once you have defined all group functions, you can deactivate the edit mode by clicking on .

Adding Information For A Camera Group

You can assign an information page to a camera group in order to show special instructions for this camera group, for example.

- 1. Open the edit mode in the Device bar by clicking on at the bottom of the bar. Next, click on and then on . The **Group Configuration** dialog opens.
- 2. Move the slider (a) to the right until you reach the (f) position.
- 3. Click on the arrow in the gray field and select the file you want to use.

Limiting the frame rate of live images

If a very large number of cameras is displayed in the Grid view, the performance may decline. To avoid this, you can limit the frame rate of the live images within the tiles. Note that this limit does not apply to the camera displayed in the focus window.




Fig. 107: Limiting the frame rate of live images

- 1. Open the Group or Camera bar by clicking on the upper gray frame border. Click on the frame border again to switch to the camera Group view.
- 2. Right-click on the group icon and select the maximum number of frames per second and the maximum image size.
- 3. **Use ONVIF LoRes Profile:** Use this checkbox to limit the frame rate for MOBOTIX MOVE cameras and for third-party cameras that provide an ONVIF S-compatible interface. If the checkbox is enabled, the settings for the live images in the tiles captured in the **Bandwidth Settings** as the LoRes profile for these cameras will be used.

Door Station Settings

There are several ways that MxMC can respond to ringing and mailbox notifications. Here you will find information on how to set these notification options.

Note

Door Station functions are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ (see Camera Feature Overview, p. 13.

See also:

- Operate Door Stations, p. 143
- Door Station Wizard, p. 272

Bell Settings

Setting the ring tone




Fig. 108: Setting the ring tone

- Open Settings in the MxManagementCenter > Settings (Mac) or File > Settings (Windows) menu and click on Notifications.
- 2. Select the desired ring tone and adjust the volume.

Setting bell signaling

When a bell is rung, this can be indicated in different locations in MxManagementCenter. Consult the following table to learn which signaling options can be combined and where they can be configured.

Note

The alarm signaling must be activated in the camera settings, a bell profile must be set up and the correct bell profile must be selected in MxMC for bell notification to work.

Notifications

Settings

Alarm bar, Alarm info bar, doorbell notification, counter on the bell icon

in the Live view

You need to configure the alarm notification for the doorbell ringing to be indicated at these places.



- 1. To do so, open the **Camera Configuration** dialog box by right-clicking on the corresponding camera in the Camera bar.
 - Another option is to open the dialog box in the Device bar by clicking on and then right-clicking on the corresponding camera.
- 2. Click **Alarms** and activate the Alarm notification and the doorbell ringing.

Ring tone off

You can switch off the ring tone of the signaling by setting its volume to "0"(See Setting The Ring Tone).

Counter on the bell icon only

Deactivate doorbell ringing in the **Alarms** dialog box and only the counter on the bell icon will increase by one each time.

- 1. To do so, open the **Camera Configuration** dialog box by right-clicking on the corresponding camera in the Camera bar.
 - Another option is to open the dialog box in the Device bar by clicking on and then right-clicking on the corresponding camera.
- 2. Click **Alarms** and deactivate doorbell ringing.

Completely off

Disable the **Bell** checkbox in the **Bell Settings** to switch off the bell completely (See Turning Off The Bell Completely).

Selecting a bell profile

A bell profile basically controls the reaction if someone is ringing at the door station. The camera provides several predefined bell profiles.

Profile	Explanation
No phone ring	MxMC and all other remote stations will not react, i.e., you will not notice if someone is ringing (neither visually nor by sound).
Ringing	You will hear if someone rings the doorbell. The visitor cannot leave a message.
Ring and Mailbox	You will hear if someone rings the doorbell. If no configured remote station reacts within a given period of time, the Door Station plays back a previously recorded announcement and the visitor can leave a message.
Voice Mailbox	After ringing, the Door Station immediately plays back an announcement and the visitor can leave a message.
Announcement only	After ringing, the Door Station immediately plays back an announcement. The visitor cannot leave a message.




Fig. 109: Selecting a bell profile

- 1. Switch to the Live view of the Door Station.
- 2. In the Live view, right-click on the **Bell** icon \triangle to open the **Bell Settings**.
- 3. Click on **Bell Profile** and select the profile you want from the list.

Resetting the ringing counter

The counter next to the bell icon in the Live view is incremented each time the doorbell is rung, regardless of whether or not you react to the ringing. Resetting the counter will help in recognizing if you have missed a ringing, which is why you are encouraged to regularly reset the counter. Once you have reset the counter, you will be informed how long ago the last reset took place.

- 1. Switch to the Live view of the Door Station.
- 2. In the Live view, right-click on the **Bell** icon to open the **Bell Settings**.
- 3. Click on **Reset Counter**.
- 4. The counter has been reset and is no longer shown next to the **Bell Settings** button.

Turn bell off completely

If you do not want to be disturbed by the doorbell, you can deactivate a specific bell or contact number. This means that ringing is neither signaled at any of the remote stations, nor is the "ringing counter" increased. In this case, you will not be informed about missed visitors and visitors will not be able to leave any messages.




Fig. 110: Turn bell off completely

- 1. In the Live view, right-click on the **Bell** icon to open the **Bell Settings**.
- 2. Disable the **Bell** checkbox.

Mailbox settings

Selecting a voice mailbox

Depending on the installed options and the configuration of the Door Station, you may have several bell buttons or – in case a MOBOTIX Keypad module has been installed – several contact numbers. Each of these bells or contact numbers has its own mailbox. The corresponding mailboxes are presented in the list (below the name of the bell).

Note

All settings made in the **Mailbox** function always apply to the selected mailbox. This also means that the new messages counter only applies to this mailbox. To get the messages and recordings of a different mailbox, select that mailbox first.




Fig. 111: Selecting a voice mailbox

- 1. In the Live view, right-click on the **Voice Mailbox** icon to open the **Mailbox Settings**.
- 2. Click on Voice Mailbox to select the desired mailbox from the list.

You can select a bell profile for each voice mailbox. For instructions on how to do this, see Selecting A Bell Profile.

Activating The Voice Mailbox And Selecting A Welcome Message

- 1. Enable the **Active** checkbox.
- 2. Click on the **Announcement** button. Select the announcement to be played to the visitor.

Enabling the Message

If visitors should be allowed to leave a message, activate the **Leave Message** option.

Network Environments

Using MxManagementCenter, you can access cameras from different locations. For example, you can monitor the cameras at home over the local area network (LAN) or while on the move via a pre-configured DynDNS access over the Internet. These two methods require the use of different network access data. To avoid having to change the network access data every time, you can set up different network environments for the corresponding network access data in MxManagementCenter. Switching to a different environment causes the network address data for connecting to the cameras to be switched automatically (see Working In Different Network Environments, p. 150).

Creating and Managing Environments

Creating environments

- 1. Click on on in the Header bar. The **Projects and Network Environments** dialog opens.
- 2. Click on **Environment** and then on ___. This adds an environment with the name "New Environment". Assign a suitable name.




Fig. 112: Creating environments

Changing names and deleting environments

- 1. Open the **Network Environments** dialog box.
- 2. Editing names: Click on . Highlight the name and overwrite it.
- 3. Deleting environments: Click on next to the environment you want to delete. Click on the red **Delete** box to the right of the environment.

Configuring network data for each environment

- 1. To set network data, open the **Camera Configuration** dialog. To do this, either right-click on the individual cameras in the Camera bar or open the Edit mode in the Device bar and right-click on the individual cameras. The **Camera Configuration** dialog opens.
- 2. Environment: Shows the current network environment. After starting the program for the first time, it shows the standard environment. All existing network environments are shown in the blue bar. Click on the environment you want to use. Next, perform the required network settings for this environment.
 - Background alarm calls: Specify whether a permanent event stream connection to the camera should be established in the selected environment or not. You can deactivate this option if a permanent event stream connection is not required or even unwanted (when using MxMC in low-bandwidth networks, for example). If this option has been **deactivated**, the application will only open an event stream connection if necessary, such as for showing the live stream of the camera or recordings via the camera. In this case, alarms will only show for this camera, while the connection has been established.
 - Remote: Only activate this option if you want to access the camera from a remote location (e.g., via DynDNS).
 - *SSL*: If you rather want to use an encrypted connection for the selected environment, activate this option (recommended setting). Note that HTTPS needs to be activated on the camera (in the browser in **Admin Menu > Network Configuration > Web Server > HTTPS Settings**).
 - Bandwidth: Select the bandwidth to use for this environment:
 HiRes: The images are transferred using the settings made in the camera.
 LoRes: Images are delivered at the frame rate, resolution and image quality as defined in the Program Settings, p. 230 for LoRes.

Camera configuration

This section describes basic options to configure cameras.

Cameras And Camera Groups

Here you will find information on the administration of cameras and camera groups. This includes topics such as changing the network data of a camera or exchanging cameras between camera groups.

Note

Administrator rights are required to perform these administrative functions.

Managing cameras

Editing camera data

To change a camera's access data and network data, open the Camera Configuration, p. 219 dialog.




Fig. 113: Editing camera data

- 1. To do this, either right-click on the desired camera in the Camera bar ① or open the edit mode in the Device bar and right-click on the corresponding camera ②. The **Camera Configuration** dialog opens.
- 2. Edit the data as desired.

Editing Camera Data Of Multiple Cameras

In the **Multi-Camera Configuration** dialog, you can change the authentication data used by MxMC as well as the environment settings of multiple cameras in one step.

- 1. To do this, open the edit mode in the Device bar by clicking on 🙃.
- 2. Select the cameras as needed.
 - Mac: CMD + click, Windows: CTRL + click
- 3. Right-click on one of the selected cameras. The Multi-Camera Configuration, p. 226 dialog opens.


Activating / Deactivating camera background alarms

Note

Background alarms are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ (see Camera Feature Overview, p. 13).

An activated option means that the application maintains an active event stream connection to the camera, regardless of whether or not MxMC is showing the live stream. Using the event stream connection, the cameras will send event information to MxMC, which will show them as alarms depending on the settings (see Adding Cameras, p. 83). You can deactivate this option if a permanent event stream connection is not required or even unwanted (due to high system loads on systems with very many cameras or when using MxMC in low-bandwidth networks, for example).

If this option has been deactivated, the application will only open an event stream connection if necessary, such as when MxMC shows the live stream of the camera or recordings via the camera. In this case, alarms will only show for this camera, while the connection has been established. This option is deactivated by factory default.



- 1. To open the **Camera Configuration** dialog, either right-click on the corresponding camera in the Camera bar ① or open the edit mode in the Device bar and right-click on the corresponding camera ②. The **Camera Configuration** dialog opens.
- 2. De-/activate the **Background Alarms** function.

Deleting cameras




Fig. 114: Deleting cameras

- Open the Camera Configuration dialog by right-clicking on the corresponding camera in the Camera bar
 or open the edit mode in the Device bar and right-click on the corresponding camera ②. The Camera Configuration dialog opens.
- 2. Click on Remove.

Managing Camera Groups

Moving cameras between Camera Groups

The Device bar lets you quickly drag and drop cameras from one group to another.

- 1. In the Device bar, open the edit mode by clicking on 🗊 and then drag and drop the cameras as desired.
- 2. Close the Edit mode by clicking ...

Removing cameras from a Camera Group




Fig. 115: Removing cameras from a Camera Group

- 1. Open the edit mode in the Device bar by clicking on 🙃.
- 2. Drag and drop the camera from the appropriate group to ...
- 3. Once you have deleted the cameras from the groups, you can deactivate the edit mode by clicking on

Deleting Camera Groups

Deleting a camera group will not delete the cameras that are assigned to the group.




Fig. 116: Deleting Camera Groups

- 1. Activate the Edit mode by clicking 🙃.
- 2. Drag a group from the corresponding section to .
- 3. Next, activate the edit mode by clicking on ...

Camera Configuration



Fig. 117: Camera Configuration

After you have added the cameras, you should enter the remaining camera data. Even when the system is up an running, you may have to make some changes. Open the **Camera Configuration** dialog to enter and edit the camera data.

Entering and Editing Camera Access Data

Name: The camera name is displayed automatically. If required, you can enter an individual name for each camera.

Connection Protocol: In order for MxMC to be able to establish a connection to the camera, a suitable connection protocol must be selected depending on the available interface of the camera manufacturer. If you have integrated the camera with the Welcome wizard, the corresponding protocol is used automatically. When manually adding the camera, select the appropriate protocol. The following protocols are available:

- MOBOTIX: Select this protocol to establish a connection to a MOBOTIX IoT camera.
- MOBOTIX with Pelco-D: The requirements to use Pelco-D protocol are:
 - MOBOTIX IoT Camera with MxBus orMxBus Module RS232
 - A PT Head with Pelco-D support
 - The serial interface must be activated and configured in the camera software (for the parameter settings see the cameras reference manual the documentation of the pan and tilt head)
- MOBOTIX MOVE: Select this protocol to establish a connection to a MOBOTIX MOVE camera.
- **ONVIF:** Select this protocol to connect to an ONVIF compatible camera.
- **Axis PTZ:** Select this protocol to connect to a camera with Axis PTZ control.

URL: The IP address is either discovered automatically via Bonjour or it has been entered manually.

Remote URL: You can enter the corresponding external address of the camera (such as a DynDNS name) when adding it to access the camera from outside the local network. Please note: Before you can access the camera from outside of the local network, you need to activate the **Remote** option.

User name, password: Access data that had been entered when adding the camera.

Entering and Editing Network Data

1. *Environment:* Shows the current network environment. After starting the program for the first time, it shows the standard environment. All existing network environments are shown in the blue bar. Click on the environment you want to use. Next, enter the network settings you want to use for this environment.

2. Background alarm calls: An activated option means that the application maintains an active event stream connection to the camera, regardless of whether or not MxMC is showing the live stream.
Using the event stream connection, the cameras will send event information to MxMC, which will show them as alarms depending on the settings (see Adding Cameras, p. 83). You can deactivate this option if a permanent event stream connection is not required or even unwanted (due to high system loads on systems with very many cameras or when using MxMC in low-bandwidth networks, for example).
If this option has been deactivated, the application will only open an event stream connection if necessary, such as when MxMC shows the live stream of the camera or recordings via the camera. In this case, alarms will only show for this camera, while the connection has been established. This option is deactivated by factory default.

Note

This option is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF-S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.

- 3. *Remote*: When adding the camera in the local network, you do not change this setting. Only activate this option if you want to access the camera from a remote location (via DynDNS).
- 4. *SSL*: By default, the connection between MxMC and the camera is not encrypted. If you rather want to use an encrypted connection, activate this option. Note that HTTPS needs to be activated on the camera (in the browser in **Admin Menu > Network Configuration > Web Server > HTTPS Settings**).


Note: This option is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.

5. Bandwidth and Bandwidth Settings:


Bandwidth and Bandwidth Settings (MOBOTIX Cameras):
 Use the Bandwidth to specify whether you want to get the images from the camera in HiRes or

LoRes by default. The values (frame rate, image size and image quality) used for HiRes and LoRes

connections are set in **Bandwidth Settings**.



Bandwidth and Connection Data (MOBOTIX MOVE / ONVIF Cameras):
 Use the Bandwidth to specify whether you want to get the images from the MOBOTIX
 MOVE / ONVIF camera in HiRes or LoRes by default. The Connection Data option allows you to set the frame rate, image size and image quality for receiving images from the camera using a HiRes or LoRes connection.



Click on **Connection Data** to open the dialog for assigning and changing the HiRes and LoRes profile of the camera.

By default, adding a MOBOTIX MOVE / ONVIF camera creates two profiles (MxHiQuality for HiRes and MxLoQuality for LoRes). To create profiles manually, click on **Create MxProfiles**.

To change the settings of a selected profile, select the desired profile parameters in the respective selection boxes and transfer the changes by clicking on **Transfer Changes**.

Note

In contrast to bandwidth settings of MOBOTIX cameras, changes to the media profiles of MOBOTIX MOVE / ONVIF cameras are made directly on the cameras. Therefore, these changes affect all applications that use these profiles.

Determining recording settings

Saved recordings can be accessed in a variety of ways, depending on the connection protocol.

With MOBOTIX cameras:

- Via camera (MOBOTIX cameras): The camera is handling access to the recordings.
- Via recording path: The camera is handling access to the recordings via a previously defined recording path. Recording paths can be defined in the program settings (Mac: MxManagementCenter > Settings > Recording Paths; Windows: File > Settings > Recording Paths).
- Via a local directory: Local path (recordings are accessed on the local computer).

With MOBOTIX MOVE / ONVIF cameras:

■ Via MOBOTIX NAS: Access to recordings via a previously defined MOBOTIX NAS. Access data can be defined in the program settings (Mac: MxManagementCenter > Settings > Recording Paths; Windows: File > Settings > Recording Paths).

Click on **Recording settings** to adjust the settings to your needs. This opens another dialog box.

1. Choose the desired recording path:

Access via the camera:

No further settings are necessary.

Access via recording path:

- Select the corresponding recording path and set the corresponding recording format: Use
 MxFFS if the recordings have been stored in an MxFFS archive. Use
 MxFileServer if the recordings have been stored in the classic MOBOTIX folder/file structure.
- MxMC searches for the corresponding recordings in the subdirectories of the predefined file server path. Once the search has been completed, you can select the folder for this camera in the **Device Directory** selection box.

Access via local directory:

- Select the Local path option and set the corresponding recording format:
- Enter the file path in the **Local path** text box.

Note: Click on the pen icon in the text field to open a file selection dialog.

Access via MOBOTIX NAS:

- Select the appropriate MOBOTIX NAS and then select the appropriate device directory based on the displayed IP addresses.
- 2. Close the dialog box. The settings will be saved automatically when you close the dialog box.

Setting up and changing Alarm Notification

Note

The alarm feature is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ (see Camera Feature Overview, p. 13).

This section allows selecting the event types that will lead to an alarm if the corresponding event is triggered. An alarm will be indicated at the following locations:

- Alarm Bar, p. 305 Turns red or green (door bell), the alarm images are shown in the Alarm bar.
- Alarm Info Bar, p. 342 Turns red or green (door bell) in the live images.
- Alarm Settings, p. 329 In addition, you can set up visual and sound notifications for alerting (Mac:
 MxManagementCenter > Settings, Windows: File > Settings).
- 1. Click on **Alarms** to adjust the settings to your needs. The **Alarm Events** dialog opens.




Fig. 118: Setting up and changing Alarm Notification

- 2. Make sure that the **Alarms** option has been activated.
- 3. Select the event types that should create an alarm.
- 4. In addition, you can select a weekly profile for every event type that should trigger an alarm. As long as no other weekly profile has been selected, the setting is valid from Monday 00:00 to Sunday 24:00.
 - To create new weekly profiles, click on . The **Weekly Profiles** dialog opens. Several predefined profiles are available, such as the **Weekend** profile (Saturday 00:00 to Sunday 24:00).
 - To add a profile, click on +. Enter a description. Highlight the desired active times in the table. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, click on ...
 - You can change the description of an existing profile. Right-click on the name and overwrite it.
- 5. To select a weekly profile, click on the **Weekly Profile** dropdown list next to the event type and highlight the desired profile. The calendar icon turns white.

6. To easily invert the settings of the weekly profile, simply click on the calendar icon. For example, if you have created a profile with opening hours and would like to activate the alarms for the closing times, click on the calendar icon [3] to invert the profile. The icon turns red.

Multi-Camera Configuration

The **Multi-Camera Configuration** dialog box allows changing authentication data used by MxMC and the environment settings of many cameras in one step. When opening the dialog, the application shows the current settings of the cameras. The field is labeled with "multiple values" or a minus sign is shown in the checkbox if one option has several different settings.

Meaning of the setting options

The meaning of the entries can vary depending on the field type. The following table therefore gives a brief overview of the possible entries per field type and their meaning.

Field type	Current status
admin [Mehrere Werte]	All cameras have the user name admin . The cameras have different user names.
	This settings has been activated for all cameras. This settings has been deactivated for all cameras. The cameras have different settings.
HiRes [Mehrere Werte]	"HiRes" has been set as bandwidth setting for all cameras. The cameras have different values.

Editing Settings

The fields and settings in the **Multi-Camera Configuration** dialog are much the same as those in the **Camera Configuration** dialog. One difference is the way settings are edited. Therefore, only the editing will be explained here. For more information about the general meaning of the settings, see the Entering And Editing Camera Access Data help topic instead.

Unlike the **Camera Configuration** dialog, the **Multi-Camera Configuration** dialog allows you to reset settings that have not yet been saved. Depending on the field type, you can use different methods.

Field type	Explanation
User	If you change the text box of a setting, such as User name , a small cross appears on the right-hand side. Click on the cross to reset the entry to its original value.
	When closing the dialog, the previous setting will be restored.
[Mehrere Werte]	of you select Several Values in a selection box, closing the dialog will restore the previous setting.

Notes on the settings

When processing the following fields, these special features must be observed:

■ Recording path:

Local path: The **Local Path** option can be selected for all cameras. Note that you will need to enter the paths **individually for each camera** in the **Camera Configuration** dialog (see *Recording Path* in Entering and Editing Network Data).

Recording path: If you select a recording path (see *Recording Path* in Entering and Editing Network Data), MxMC automatically searches the device directory for each camera. The search has been completed if the progress bar is replaced by **OK**. If you close the dialog beforehand, you will have to enter the device directory for each camera in the **Camera Configuration** dialog.

■ Alarms:

The **Alarms** option activates or deactivates the alarm notification for all cameras. Note that you will have to set the alarm settings for the event types individually for each camera. Use the **Camera Configuration** dialog to do this (see Setting up and Changing Alarm Notification).

User Management

The user management in the application header allows for the centralized management of user data and access rights (see also: Adding Users, p. 98).

Managing users

Open the User Management in the application header by clicking on M.




Fig. 119: Managing users

Deactivating users

If - for security reasons - you want to prevent a particular user from logging in, you can deactivate that user. This prevents the user from logging in, but all settings remain in the system. To do this, select the user and deactivate the **Active** option.




Fig. 120: Deactivating users

Deleting Users

Click on and then on en next to the user you want to remove.

Changing access rights

Click on the user whose settings you want to edit. Then configure the user rights by enabling or disabling the corresponding rights in the **User Rights** section.




Fig. 121: Changing access rights

Temporarily assigning supervisor passwords to functions

Certain situations may require users to execute functions for which they usually do not have access rights. These functions can be made available temporarily using a supervisor password.

1. Click on **Supervisor** to protect functions with a supervisor password.




Fig. 122: Temporarily assigning supervisor passwords to functions

2. In addition, you can specify after how many minutes of inactivity this user will be logged out automatically.

Note

While a recording is being played back in Playback view or in Grid Playback, MxMC does not automatically terminate the supervisor mode after the specified period of time.

3. Select the functions that can be accessed after entering the password.

Program Settings

For MxMC, you can choose from various options and set preferences. To do so, open **Settings** in the **MxManagementCenter** > **Settings** (Mac) or **File** > **Settings** (Windows) menu.

General Settings




Fig. 123: General Settings

Language: Sets the program language. You may have to restart the software in order to apply your change. **Behavior:** Deactivate this option to prevent that a double-click triggers the full-screen view on the main mon-

itor or on other monitors.

Display Area: If you are working with the Camera/Group bars or the Alarm/Export bars, you can change the width of the bars. Use this option to automatically resize the display area in such a case.

Graphics Mode: If you want to correct hemispheric images, make sure that this option has been activated. A prerequisite for using this feature is a graphics card with OpenGL V2.1 support, since it performs the actual distortion correction of transferred hemispheric images. Deactivate OpenGL if your graphics card does not support this mode or if you experience problems when displaying the camera images.

Network




Fig. 124: Network

Proxy Server: Select the desired proxy here.

No Proxy, a direct connection will be established.

System Proxy will apply the proxy settings of the system, including the exceptions defined.

Software Update




Fig. 125: Software Update

MxMC can use the update feature to automatically search for new program versions. To do this, check the **Check for Updates** checkbox and set the polling interval. The update function requires an Internet connection.

The search for new versions can also be performed manually. To do so, click on **Search Now**. If a new program version is available, you will see this here.

Notifications




Fig. 126: Notifications

Alarms: In addition to the event notifications in the Alarm bar or the Alarm Info bar, you can set up an alarm notification and/or alarm sound that signals new alarms. Enable **Alarm Notifications** to receive an alert. Select the desired alarm sound and set its duration and volume.

Bell: When the bell is rung, a ringing notification is displayed. Select the desired ring tone for the notification and adjust its volume using this option (see Operate Door Stations, p. 143).

Monitoring




Fig. 127: Monitoring

Lost Connections: If the connection to a camera is lost (e.g., due to a network failure or changed camera access data), the application can show a warning.

This is where you configure the warning. Activate the **Lost Connection Detection** checkbox and specify how you want MxMC to react if the connection to a camera is lost (warning sound and window).

Action Log: MxMC can log any action, such as starting playback or export actions, activating the sound, etc. This means that you can log all user actions and thus deliver the entire chain of events for legal purposes. Activate the **Action Log** checkbox and specify the interval at which the action log is to be archived and a new log created. After enabling this feature, you must restart the application for the activation to take effect. The action log can be accessed from the menu via **Window > Action Log**.

Application Error Report: After an unexpected program termination, a service report is usually created. If you do not want this, uncheck the **Show Dialog** checkbox.

Audio




Fig. 128: Audio

Use the slider to set the sensitivity for recording the sound from the camera microphone. The default setting has been optimized for Intercom connections and should only be touched in very noisy or very quiet door station surroundings.

Hands-Free Talking and Push to Talk

The **Hands-Free Talking** option is activated by default. If the surroundings are very noisy or if intercom problems persist, you should try to use the **Push to Talk** option.

Data Volume




Fig. 129: Data Volume

Maximum Number of Events/Maximum Time Range: The number of events and the time range are controlling how far into the past MxMC will look for event information after the next launch of the application. The settings apply to the event counter in **Live View** and the event preview images in **Events View**. This avoids long loading times and saves storage space when initially loading the event information.

Caches




Fig. 130: Caches

Recording Path Cache Sizes: To improve playback performance, you can set the internal cache sizes for playback here. This applies to both playback via the camera and playback from a file server. Please be aware that the cache size set here will reduce the available RAM for other processes, which in turn can influence the performance of other applications.

Event Images Harddisk Cache: To load event images faster and reduce network load, you can increase the disk cache for event images. If you do not want the system to save event images to disk, clear the **Event Images Harddisk Cache** checkbox.

Snapshot Images




Fig. 131: Snapshot Images

You can save individual camera images as snapshot files. These settings control the location and the quality of the snapshot images stored by MxMC. If you do not specify a folder, the files will be created on the desktop.

Live Recorder




Fig. 132: Live Recorder

If you observe a suspicious situation that you want to record, you can start a manual recording in Live view as well as in Grid view. While you keep track of the situation in the live image, the images are recorded and saved as an MXG file. Here you can configure where the clips are stored and how long they are recorded. If you do not specify a folder, an MXG file will be created on the desktop.

Remote Control




Fig. 133: Remote Control

MxMC can be remote-controlled from other programs using HTTP requests. Activate this feature and set a proper port if you want to use this feature. Click on one of the example links to see a list of executable commands.

Joystick PTZ




Fig. 134: Joystick PTZ

You can adapt the joystick behavior to your personal requirements. Start by setting the PTZ type, then set the behavior for each axis.

PTZ Type

- **Screen PTZ:** The PTZ actions are taking place in the application. This means that only the visible image section of the current live image is modified. Any zooming does not influence the recordings of the current camera image that may be taking place.
- **Camera PTZ:** Zooming actions are executed on the camera and also influence the recordings unless you are recording in full-image mode.
- **External PTZ:** If you are using the camera of a different manufacturer, you can set its joystick behavior in this dialog.

Axes

- X Axis: Horizontal movement
- Y Axis: Vertical movement
- **Z Axis:** Zooming

Invert

Use this option to invert the joystick actions for that axis.

Sensitivity

If the PTZ actions are reacting too slowly, you can increase the sensitivity. If the reactions are too fast, reduce the sensitivity.

Progression

Click on the **b**utton to change the progression of the joystick movements. The default setting is linear progression.

MxMessageSystem




Fig. 135: MxMessageSystem

This setting is currently required for the MxThinClient. Since the live camera images are switched to the MxThinClient via the MxMessageSystem, you must first activate the MxMessageSystem here. Make sure that the same parameters are set as in the MxThinClient.

Customization




Fig. 136: Customization

This setting enables you to adapt MxMC optically to your needs. You user can freely select the primary color of the headers and the font displayed there. You also can add an individual logo.

Select header color: Click to select an individual header color

Select font color: Click to select an individual font color.

Select logo: Click to select a graphic file to be displayed as individual logo in the header. Possible file formats are .JPG, .PNG, .GIF


Components Settings

In the Component View, you can manage the following components:

- File Servers that are used to store video recordings (see File Server Settings, p. 245
- **Smart Data Sources** (license required for general sources) from which you can read transaction data, e.g. from MOBOTIX P7 Apps (no license required), POS systems or license plate recognition systems (see Smart Data Settings, p. 250).
- MxThinClients, which allow you to display live images from MOBOTIX cameras on a monitor or TV set with HDMI connection (see MxThinClient Settings, p. 254).

File Server Settings

Stored images can be accessed in two ways: Access via the camera or directly to a file server where the recordings are stored. If access is to be direct, you can create recording paths here that can be assigned to the cameras. (See Camera Configuration, p. 219).



Adding a File Server

- 1. Click the + icon ① and select a File Server type.
- 2. Configure the file Server in the Settings area ②.

Configuring File Servers


Name:

Enter a name for the file server here. Use this name to select the path in the Camera Configuration dialog as recording path.

Type:

- **Local**: Contains a local folder on this computer or on a connected network drive. You can either enter the folder path manually, drag&drop a folder to the text box or select the folder.
- **Network Share**: The program directly accesses a shared folder on a file server. In this case, you need to enter the computer, the folder and the access data.
- MOBOTIX NAS: Data is accessed directly on a shared folder on a MOBOTIX NAS.
- MOBOTIX NAS (ONVIF): The ONVIF recordings are accessed by Videomanagement Software QVR Prowhich must be installed on a MOBOTIX NAS.

Local



Path:

you must select the path that contains the recording folders created by the camera.

Network Share



File Server (IP): IP address or DNS name of the file server with the share.

Directory: Name of the share on the file server.


Note

Make sure that the path ends before the folder containing the factory IP address of the camera.

User Name/Password: Access data for the network share.

MOBOTIX NAS

Data is accessed directly on a shared folder on a MOBOTIX NAS.



File Server (IP): IP address or DNS name and port of the MOBOTIX NAS.

Directory: Name of the share on the MOBOTIX NAS.

Note

Make sure that the path ends before the folder containing the factory IP address of the camera.

User Name/Password: Access data for the MOBOTIX NAS.

MOBOTIX NAS (ONVIF)

The ONVIF recordings are accessed by Videomanagement Software QVR Pro which must be installed on a MOBOTIX NAS.




Fig. 137: MOBOTIX NAS settings

File Server (IP): IP address or DNS name of the file server.

User Name/Password: Access data for the file server.

Use Expert settings (ONVIF access): If special access data are required for ONVIF access, enter them here.

MOBOTIX NAS Configuration



Fig. 138: MOBOTIX NAS Configuration

The following functions are available for configuring and maintaining a **MOBOTIX NAS** or **MOBOTIX NAS** (ONVIF) system

Quick Guides

Links to download installation or configuration manuals for MOBOTIX NAS systems

Installation and Configuration

Open Device Finder:

The Device Finder finds MOBOTIX NAS systems in the network, making initial configuration easy.

Configure NAS:

Opens the web interface of the MOBOTIX NAS system with which you can configure the NAS device.

QVR Pro Settings:

Opens the web interface of the video management software QVR Pro. This software must be installed on the MOBOTIX NAS system first.

■ Recording Storage Space:

Opens the web interface of the MOBOTIX NAS system with the interface for setting up the storage space for video recordings.

■ Troubleshooting:

■ Here you can download the log files of the MOBOTIX NAS system or the QVR Pro software.

Download links:

Links to useful resources for installation, configuration and maintenance.

Container App: You need the Container App to install the QVR Pro App on a MOBOTIX NAS system.

QVR Pro App: The software for managing recordings from MOBOTIX MOVE or ONVIF cameras on a MOBOTIX NAS system.

Device Finder App - macOS: Use the Device Finder App to find MOBOTIX NAS systems in the network.

2Bay and 4Bay NAS Firmware: The latest firmware for your MOBOTIX NAS system.

8Bay NAS Firmware: The latest firmware for your MOBOTIX NAS system.

Smart Data Settings

With the MOBOTIX Smart Data System, transaction data, for example from POS systems, can be linked to the video recordings of transactions in MxMC.

Note

A license is required to activate the general Smart Data interface from which you can read transaction data, e.g. from POS systems or third party license plate recognition systems.

No license is required to use Smart Data from MOBOTIX P7 Apps.




Fig. 139: Smart Data settings

Adding a Smart Data Source

- 1. Click the + icon 1 and select a Smart Data type.
- 2. Configure the Smart Data Source the Settings area ②.

Configure General Smart Data Sources (license required)

Edit here Smart Data sources (e.g. POS systems or license plate recognition systems).




Fig. 140: Settings for general Smart Data sources

Description

Enter a meaningful name for the Smart Data Source here. Under this name, the source can be identified and selected in the MxMC for research.

Name

Enter the name (without spaces) for the Smart Data Source exactly as it was assigned in its configuration (also without spaces).

■ Smart Data Type

Select the type of Smart Data device here.

Data Source

Select the camera in which the Smart Data source (identified by the name given above) stores its transaction data.

Video Source

Select the camera that provides recordings for the transaction data. The video source and the data source do not have to be identical.

Configure P7 Apps as Smart Data Sources (no license required)

Edit here P7 Apps as Smart Data sources.




Fig. 141: Settings for general Smart Data sources

Note

The minimum Firmware Version on the MOBOTIX IoT Camera is 7.1.2.24.

Follow these steps in the Camera user interface to prepare the camera to run properly with the Smart Data interface of MxMC:

1. Go to Admin Menu > Smart Data Configuration and click Add Smart Data source.

2. Enter the specific identifier for a P7 App:

Vaxtor: VaxALPR.plate FF Group: FFLPR.plate Visage: VT_Face.face

- 3. Click Set
- 4. Store and reboot the camera
- 5. Go to Setup Menu > General Event Settings and enable Arming.
- 6. Click Set
- 7. Go to Setup Menu > Recording and select

Arming = Enabled

Recording (REC) = Continuous Recording, 2 fps

- 8. Click Set
- 9. Go to Setup Menu > Certified App Settings and check "Active"
- 10. Click "Set"-button

Description

Enter a meaningful name for the P7 App as Smart Data Source here. Under this name, the source can be identified and selected in the MxMC for research.

Name

Enter the name (without spaces) for the Smart Data Source exactly as assigned in its configuration on the camera .

Smart Data Typ

Select the type of Smart Data device here.

Data Source

Select the camera in which the Smart Data source (identified by the name given above) stores its transaction data.

Video Source

Select the camera that provides recordings for the transaction data. The video source and the data source do not have to be identical.

MxThinClient Settings

MxThinClients allow you to display live images from MOBOTIX cameras on a monitor or TV set with HDMI connection.




Fig. 142: MxThinClient settings

Adding a MxThinClient

- 1. Click the + icon \bigcirc .
- 2. Configure the MxThinClient the Settings area ②.

MxThinClient-Settings

Edit the MxThinClient setting here.




Fig. 143: MxThinClient settings

Name

Enter the name for the MxThinClient.

URL

Enter the URL or IP address of the ThinClient.

User Name

Enter the user name of the MxThinClient user here.

Password

Enter the password of the ThinClient user here.

Display resolution

Select the resolution of the camera image to be displayed on the monitor of the MxThinClient.

Camera display

Select here how long the assigned camera image should be displayed on the monitor of the ThinClient. After the selected time period the ThinClient will display the configured setting (e. g. sequences, still images etc.).

Wizards & Tools

MxMC provides cross-system maintenance and security features, such as creating backup copies of current camera configurations or checking and improving system security. This section provides an overview of the currently available system functions.

Note

The system functions described below are not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview.




Fig. 144: Wizards & Tools

1. To open the **Wizards & Tools** view, right-click on the navigation key in the Command bar and select **Wizards & Tools**.




Fig. 145: Opening Wizard & Tools View

- 2. Select the related camera or camera group in the Device bar or the Camera/Group bar.
- 3. Select the desired function:

Maintenance Functions

Reboot Devices

When it is required to reboot a device, for example to fix network issues. Click **Reboot Devices** to do so. You can determine which cameras are rebooted from the current selection of cameras or camera groups.

Back Up Devices

The current configuration of cameras or the cameras of one group are saved when you click **Backup Devices**. You can enter a name for each backup. The name should be meaningful enough enabling you to quickly select the desired configuration when you want to restore a configuration later on.

Restore Devices

The configurations you save when using Backup Devices can be used to restore a configuration, for example, if a camera is no longer operational due to a problem with a configuration. Click on **Restore Devices** and select the desired configuration.

Update Devices

You can apply a software version to a larger number of cameras at one time. Download the desired software version from the MOBOTIX download directory: www.mobotix.com > Support > Download Center > Marketing & Documentation. Next, click Update Devices and open the *.mpl file. The new software will be uploaded to the cameras. The cameras will automatically reboot when the update is complete.

Attention

that the software you select to install is compatible with all cameras in the group. Otherwise, the update cannot be performed.

Reset Devices

Click **Reset Devices** in order to reset one or more cameras to the factory settings. In the process, you can select whether or not security settings (user names and passwords) and network settings should be reset, as well. The cameras will then automatically reboot.

Note

Project data will not be automatically updated when you reset the camera(s) to factory settings. You will need to update them manually.

Security Functions

Secure System

This feature helps administrators when securing camera systems. It shows them exposed points of attack and prevents unauthorized or unencrypted access to cameras.

To check system security and secure the system, see Checking System Security, p. 258.

Health Check

A MOBOTIX camera independently checks its system status permanently. The results of this check are available in the **Wizards & Tools** view by using the **Health Check** function.

Also see Health Check, p. 261.

SSL Certificates

SSL is the standard technology for securing an Internet connection by encrypting the data sent between a website and a browser (or between two servers). This function allows an administrator to upload or create a SSL certificate to the selected cameras.

Also see Managing SSL Certificates, p. 262.

Initialize Door Station

The door station wizard will guide you through the basic configuration steps of the selected door station. Also see Door Station Wizard, p. 272.

Checking System Security


After completing the basic configuration of the system, you can check its security. The **Wizards & Tools, p. 256** view offers the **Secure System** wizard. It analyzes the security of the cameras and assesses their status based on common best practices. If test criteria are not met, possible measures to protect the cameras are provided.

Note

The system security check feature is not available for MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Verifying Settings for System Security

1. To open the **Wizards & Tools** view, right-click on the navigation key in the Command bar. Select the **Wizards & Extras** view.



2. Select the desired camera or camera group in the Device bar or the Camera/Group bar.



- 3. Click **Secure System**. The following criteria are checked:
 - Usage of the "meinsm" password with standard or ONVIF user accounts on MOBOTIX cameras. It is easy for cyber attackers to guess the standard "meinsm" password.
 - Enabled **Public Access**: If Public Access is enabled, a number of different camera functions can be used without a password.
 - Activated HTTP web server: It is possible for data, including user data such as passwords and images, to be transmitted via the network without encryption when HTTP is used.

The result of the check is displayed for each camera in the **Secure System** dialog. It will also show all cases in which cameras were not checked due to a connection error, for example.

Status	Explanation
⊗ Not secured	There was at least one criterion that was listed as not secure.
Software too old	Please check the camera software and update it, if necessary.
○ Connection error	Check your network connection to the camera and perform the security check again.
Not supported	The camera (s) cannot be analyzed or secured using the wizard.
⊗ Secured	Camera is secure; no further action is necessary.

Secure System

4. In the **Secure System** dialog, click on **Next**. Cameras resulting in a **Not secure** status are displayed together with whichever of the three criteria that were fulfilled as well as the measures that need to be taken to properly secure the cameras:

Criterion	Explanation
Password	Changes the password of all user accounts on the cameras that use the standard "meinsm" password. It also include ONVIF users whose passwords have never been changed. Enter a new password and confirm it. A suitable password has at least eight characters. It can consist of lowercase and uppercase letters, digits and special characters (see). If you set a password that does not meet these criteria, a red frame appears around the text field. The frame turns green once you have entered a valid password. The new password is automatically entered in the MxMC project data.
SSL encryption	Disables camera connections via unencrypted HTTP and configures the cameras to accept HTTPs connections only. The TCP port and the SSL setting will be automatically updated in the MxMC project data, if necessary. The TCP port will not be updated for cameras that are connected via a remote URL. For remote URL connections, you may need to change port forwarding in the router to the appropriate setting. Please note that different services, such as network messaging etc., will no longer work when you disable HTTP.
Public Access	Disables access that does not require password entry to the web interface and the APIs of the cameras.

5. Click on **OK** in the dialog box. The selected security measures will be performed. The security status for the selected camera or camera group will be analyzed once again and the result for each camera is displayed.

Health Check

A MOBOTIX camera independently checks its system status permanently. The results of the health check are available in the **Wizards & Tools, p. 256** view.





Fig. 146: Health Check

- 1. Click on Health Check.
- 2. The camera-internal checking data is now queried and listed in tabular form.

The Health Check dialog provides a overview of the proper operation or functional status of your MOBOTIX cameras. The Health Check is divided into two areas:




Managing SSL Certificates

SSL is the standard technology for securing an Internet connection by encrypting the data sent between a website and a browser (or between two servers). This function allows an administrator to upload or create a


SSL certificate to the selected cameras.

Upload a SSL certificate to a camera

1. Open the Wizards & Tools view, right-click on the navigation key in the Command bar.




- 2. Select the desired camera or camera group in the Device bar or the Camera/Group bar.
- 3. Click **SSL Certificates**. The SSL Certificate Wizard appears:



- 4. If the status of the camera is OK click **Next**.
- 5. Click **Upload** to upload of an existing SSL Root Certificate including private key



6. Select an existing certificate, the Private Key and enter the certificate Password.



7. Click Verify Data. If data verification was successful click Next.

Note


If data verification fails check your certificate

8. Click **Upload** A summary of about successful uploads or errors appears and the camera will be rebooted. See Summary about successful uploads and errors, p. 270.



Generate a SSL certificate


1. Open the **Wizards & Tools** view, right-click on the navigation key in the Command bar. Select the **Wizards & Extras** view.




- 2. Select the desired camera or camera group in the Device bar or the Camera/Group bar.
- 3. Click **SSL Certificates**. The SSL Certificate Wizard appears:



- 4. If the status of the camera is OK click **Next**.
- 5. Click **Create** to create a new SSL Root Certificate including private key




6. Enter a **Key Name** and a **Key Password** for the private key and click **Create and Save**.



7. After saving the private key click **Next**. The dialog **Create Certificate Authority** appears.

8. Fill out at least the mandatory fields and click Generate Cert. If




9. Optionally you can create a backup of the SSL certificate. When clicking on **Backup Cert**you can select a directory to save the certificate file.

Note

A backup of your certificate is recommended e. g. if you need to distribute it on other MxManagementCenter installations in within your project.

- 10. Click Next.
- 11. Enter the certificate Password you defined in Enter a Key Name and a Key Password for the private key and click Create and Save., p. 267.




12. Click **Verify Data**. If data verification was successful click **Next**.

Note

If data verification fails check your certificate.

13. Click **Upload** A summary of about successful uploads or errors appears and the camera will be rebooted. See Summary about successful uploads and errors, p. 270.



Summary about successful uploads and errors

The certificate could not be verified

There is no matching root certificate in MxMC's "Certificates" folder.



The certificate hostname does not match the camera hostname

E.g. the camera still has the MOBOTIX factory certificate but is connected using an IP address other than the factory supplied IP address.



Four or more cameras report SSL errors.

When four or more camera connections report SSL errors at the same time a list of untrusted cameras is shown.



Display the SSL certificate information

If an SSL error occurs it is now possible to display detailed certificate information.

Certificate information		
Field	Value	
Hostname(s)	10.22.10.30,	
Common Name	mx10-22-10-30	
Country	DE	
Issuer Name	MX-ProduktionSubCA-1	
Locality		
Organisation	MOBOTIX AG	
Organisation Unit	MX-PKI	
State	Rheinland-Pfalz	
Email-Adress		
Valid from	2016-12-23T20:34:55Z	
Valid to	2036-12-18T20:34:55Z	
Duration	7300 days	
Close		

SSL error on one camera

1. Click View certificate information.

List of multiple cameras with SSL errors

- 1. Select a camera in the camera list
- 2. Click on the exclamation mark icon on the right ①. The related Certificate information appears.

Door Station Wizard

The Door Station wizard will guide you through the basic configuration of a selected door station.

Also see:


- Door Station Settings, p. 207
- Operate Door Stations, p. 143

Basic requirements

- Make sure that the devices run the latest software otherwise the configuration could fail.
- Additional door stations (including S1x, S2x cameras) to be configured must be listed in the **Device** Bar.
- Apply the default password "meinsm" to all door stations. To do so, you can use the Secure System
 Wizard.
- Apply the default password "meinsm" to MxDisplay devices to be configured.

Step by step

1. To open the **Wizards & Tools** view, right-click on the navigation key in the Command bar. Select the **Wizards & Extras** view.



2. Select the related door station (camera) Device bar or the Camera/Group bar and click **Initialize Door Station**. The Door Station Wizard starts up.

3. Read the introduction text and make sure you meet the basic requirements for the further configuration. Click **Continue**.



4. Select the devices you want to configure and click **Continue**. The Selected devices will be configured. This can take while.

Note:

Only devices with suitable software can be selected. The Master door station cannot be deselected.



5. Check the summary of the configured devices and click **Continue**.



- 6. Follow the next remaining configuration steps and click **Finish**.
 - Initialization of door station RFID module
 - Add MxBell as remote Station
 - Define all relationships between addresses and remote stations
 - Configure I/O-wiring
 - Final configuration of all door station (cameras)
 - Setup MxDisplay



Licensing

Activation or purchase of a license is required to use certain features. This includes licenses for the following features:

- Smart Data: industry-specific solutions and special features, such as integration with POS systems.
- H.264 De-/Encoder: for displaying and exporting videos in H.264 format.
- Cameras from third-party manufacturers: Integrate cameras from other manufacturers than MOBOTIX.
- Advanced Config: Collection of functions for simplified configuration of cameras.

For license activation see MxMC Licensing, p. 276

For camera models from the MOBOTIX M73 series there is the possibility to use apps. Apps, for example, offer extended functions for image analysis which may be supported by algorithms of artificial intelligence. Various apps are pre-installed on the camera and must be activated for use with a valid license key (seeCamera App Licensing, p. 278).

MxMC Licensing

Activate licenses

After purchasing and receiving the activation IDs, enable them in MxMC as follows:

1. Open the License Management (Window > Licenses menu item) and click on Activate Licenses.



Activate license

- 2. Enter a valid activation ID and establish the number of licenses that will be installed on this computer.
- 3. Click on + if you want to license an additional product. Enter the corresponding activation ID in the new line and enter the number of desired licenses.
- 4. Click on to delete a line.

5. When you are finished entering all activation IDs, click on **Activate**. MxMCconnects to the license server for activation. It needs to establish an Internet connection.




Fig. 147: Entering license key

Successful activation

If the activation was successful, you will need to sign in again to apply the changes. Alternatively, you can also return to **License Management** <.

Activation failed (no Internet connection)

MxMC connects to the license server for activation. It needs to establish an Internet connection. An error message appears if there is no Internet connection. It will then save an offline request file (*.lic). This file enables the partner/installer from whom you purchased the licenses to generate a functionality response (.bin file) on the license server. If you have received such a response, open the **Activate Licenses** window (**Window > Licenses > Activate Licenses** menu). Click on **Load Functionality Response File**.

Once you have loaded the functionality response file, you will need to log back in to apply the changes. Alternatively, you can also return to **License Management** .

Managing Licenses




Fig. 148: Managing licenses

You can view a list of all licenses that have been activated on this computer in License management. To open the License Management, click on **Window > Licenses** in the Menu bar.

Designation	Explanation
Product	Name of the licensed function.
Expiration date	This column indicates whether the license is temporary and when the licensing period may end.
Number	Number of licenses that were purchased for a product.
Device ID	Unique identifier that is determined by MxMC for the used device. Note the device ID and keep it accessible if you should run into any problems during licensing.

Synchronizing licenses with the server

When launching the program, it does not automatically compare the licenses on the computer with the license server. For this reason, you need to click on **Update** to reload the licenses from the server.

Updating licenses

To update temporary licenses, click on **Activate Licenses**. The dialog box used for updating/activating licenses is shown.

Note:

You need administrator rights to synchronize and update licenses.

Camera App Licensing

For camera models from the MOBOTIX M73 series there is the possibility to use apps. Apps, for example, offer extended functions for image analysis which may be supported by algorithms of artificial intelligence. Various apps are pre-installed on the camera and must be activated for use with a valid license key.


Online-Activation

After receiving the activation IDs, activate them in MxMC as follows:

- 1. Select from the menu Window > Camera App Licenses.
- 2. Select the camera on which you want to license apps and click **Select**.



3. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.




Note

If necessary, correct the time set on the camera.

- 4. Enter a valid Activation ID and specify the number of licenses to install on this computer.
- 5. If you want to license another product, click on +. In the new row, enter the appropriate Activation ID and the number of licenses you want.
- 6. If necessary, click to remove a line.

7. When you have entered all Activation IDs, click **Activate License Online**. During activation, MxMC connects to the license server. This requires an Internet connection.



Successful activation

After successful activation, a new log in is required to apply the changes. Alternatively, you can return to license management.


Failed activation (missing internet connection)

If the license server cannot be reached, e.g. due to a missing internet connection, apps can also be activated offline (see Offline activation).


Offline-Activation

For offline activation, the partner/installer from whom you purchased the licenses can generate a capability response (bin file) on the license server to activate their licenses..

- 1. Select from the menu Window > Camera App Licenses.
- 2. Select the camera on which you want to license apps and click **Select**.



3. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.




Note:

If necessary, correct the time set on the camera.

- 4. Enter a valid Activation ID and specify the number of licenses to install on this computer.
- 5. If you want to license another product, click on ___. In the new row, enter the appropriate Activation ID and the number of licenses you want.
- 6. If necessary, click to remove a line.

7. When you have entered all Activation IDs, click **Download Capability Request File** (.lic). and send it to your partner/installer. This file allows the partner/installer from whom you purchased the licenses to generate a capability response file (.bin) on the license server.



8. Click Load Capability Response File and follow the instructions.


Successful activation

After successful activation, a new login is required to apply the changes. Alternatively, you can return to license management <.


Manage licenses

In the license management screen, you get a tabular overview of all licenses that have been activated for a camera.

- 1. Select from the menu Window > Camera App Licenses.
- 2. Select the camera on which you want to license apps and click **Select**.



3. An overview of the licenses installed on the camera may be displayed.



Field name	Explanation	
Name	Name of the licensed app.	
Product	The feature of the licensed app	
Expiration	Expiration the time limit of the license	
Quantity	Number of licenses purchased for a product.	
Serial number	Unique identification determined by MxMC for the device used. If problems occur during licensing, please have the device ID ready.	

Synchronize licenses with server

When the program starts, there is no automatic comparison of licenses between the computer and the license server. Therefore, click on Update to reload the licenses from the server.

Update licenses

to update temporary licenses, click Activate Licenses. The dialog for updating/activating licenses opens.

Note

You need administrator rights to synchronize and update licenses.



System Configuration

The MxManagementCenternow allows you to configure MOBOTIXcameras directly. This section addresses **administrators** and **system installers**. It provides an overview of the operation of the Configuration view and the Configuration bar and provides information on how to operate the graphical elements.

Topics	Explanation
Configuration: Overview, p. 285	Overview of the structure and working with the Configuration view and the Configuration bar
Graphical operation, p. 292	Explanations of how to operate the graphical configuration elements.

Configuration: Overview

The Configuration view you to directly access and make settings for MOBOTIX cameras. In general, the view is divided into a **Basic Settings** section and an **Advanced Configuration** section containing **Configuration Groups**.

The controls at the bottom can be used for actions such as storing the changed settings permanently or resetting the parameter values to their factory settings.

The settings are made for one camera at a time. The Configuration bar on the right margin also offers the possibility to change the settings of several cameras of a group simultaneously without having to change the camera or the camera group.

Note

The Configuration view is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S-compatible interface. For an overview of how the camera functions differ, see Camera Feature Overview, p. 13.

Structure of the camera configuration view



Fig. 149: Structure of the camera configuration view

Basic Settings

The Basic Settings ① contain basic configuration settings that are important for the setup of cameras and camera system. The Basic Settings include the following areas:

- General Settings,
- Network,
- Time,
- Image Settings,
- MxActivitySensor and Recording.

The parameters of the respective topic areas are grouped in tabs. For information about each tab, see Configuring Basic Camera Settings, p. 100.






Fig. 150: Basic settings

Advanced Configuration (license required)

The available configuration parameters are thematically grouped in tiles. The Advanced Configuration tiles ② are only visible if the required license key has been installed, otherwise only the basic settings are available. Clicking on a tile opens the topic area and tabs for the associated sub-topics.

Some of the topics contain graphical configuration items, such as those for defining exposure windows or detection areas. For more information on how to operate these configuration items (see Graphical operation, p. 292).

Extensive information on the setting options and parameters of the individual subject areas are currently available only via the help pages of the camera. You can access the camera help table of contents directly from MxMC by pressing **CMD+Shift+H** (Mac) / **CTRL+Shift+H** (Windows).





Fig. 151: Advanced Configuration



Advanced Configuration - Users and Groups

Configuring Advanced Settings

Caution

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!

- 1. Click on the respective tab to open the corresponding topic area.
- 2. Make your settings as required by topic.

Note

Clicking on the relevant topic area in the table opens an information page for the individual topic areas of the Advanced Configuration settings.




Fig. 152: Advanced Configuration - Users and Groups

Applying and saving changed settings

Warning

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!




Fig. 153: Applying and saving changed settings

You can use the controls at the bottom of the view to permanently save changed settings or to reset the parameter values to factory settings, among other things:

Resetting To Factory Settings

Click on to reset all parameters for the current camera tab to the factory settings.

Undo/Redo Last Change

Click on 🔁 to undo the last change. Click on 🔁 to redo the change you previously undid.

Apply Changes

You can make changes by pressing Enter or selecting the new value in the Configuration view. The changes made here are not automatically adopted because it could potentially cause problems with the network settings.

When a value is changed, the checkmark in the Command bar turns red, indicating that the change has not been implemented yet. Click to make this change.

Saving Configurations

If parameter values are changed, the **Store Configuration** icon turns red in the Command bar. Initially, changes are always temporarily stored in the camera. To ensure that the current settings are also used after the next restart, the changes must be saved permanently.

- 1. To do so, click on **Store configuration**. The program opens a system prompt. In the prompt, click on **Store**.
- 2. If you do not want to keep the changes, click on **Discard**. This discards the changes and restores the last permanently saved overall configuration.

Expert Settings

Various sections of the configuration provide additional settings that can be used to change parameters that are not necessary for the daily work with MxMC. Note that these settings have been combined as expert settings in the different sections. Click on to open the expert settings.

Changing Parameter Values For Multiple Cameras In The Configuration Bar

Warning

By modifying **User Settings**, you can loose access to your cameras. Make sure you do not delete or move user or passwords you do not know!

You can enter parameters for a **single** camera in the Configuration view. You can use the Configuration bar to check which parameter values are available for the other cameras in the group. There you can also change the settings of one or **multiple** cameras in the group without having to switch to a different camera or camera group.

Checking parameter values of other cameras in the group




Fig. 154: Checking parameter values of other cameras in the group

Example: Check arming for multiple cameras

- 1. Click on the relevant parameter name ①.
- 2. It turns yellow and the Configuration bar shows all values associated with this parameter that were defined for cameras in this group ②.

Changing a value for one camera or for multiple cameras




Fig. 155: Changing a value for one camera or for multiple cameras

Example: Change a value using the Configuration bar

- 1. Click the appropriate parameter name in the Configuration view ①. It turns yellow and the Configuration bar shows all values associated with this parameter for this group ②. The cameras for which this value is set are assigned to the individual values.
- 2. Highlight the desired camera and drag it onto the parameter value you want to set. The destination area turns yellow.
- 3. If the same value is set for several cameras and you want to change this value, click on the parameter selection field in the Configuration bar ③. Then select the desired value.

Graphical operation

Graphical window definition

In the configuration, graphical elements such as exposure windows and detection areas can now be easily edited with the mouse. The processing of these graphic elements is subject to a uniform operating concept, which is explained in the following table.

Action	Explanation
Create expos- ure/detection win- dow	Draw a window using the mouse pointer.
Move the exposure window/detection area	Left-click on the exposure window / detection area and move it to the desired position.
Change the expos- ure win- dow/detection area	Move the mouse pointer over one of the white "handles" until the ticon is displayed. Left-click with the mouse and drag the window making it larger or smaller.
Rotate the expos- ure win- dow/detection area	Click on and, while holding the mouse button down, rotate the green area clockwise or counterclockwise.
Change the shape of the exposure window/detection area	Switch to polygon mode by clicking on . You will see white corner points on the corners. Drag the corner points to the desired position. You can insert new corner points by right-clicking on the white line or in the green area. Right-click on a dot to delete a corner point. Then click on
Delete expos- ure/detection win- dow	Click on 🚫.
Exclude area from analysis	Pull open a window of the appropriate size at the position that should be excluded from the analysis. Click in the window and keep the mouse button depressed until two icons appear. Click on to determine the exclusion window. The window turns red.

Note

The processing status of graphical window elements is indicated by a yellow or a green window color. If a window is yellow, it cannot be edited. An example of this are predefined exposure windows. On the other hand, green windows, such as custom exposure windows, can be graphically edited.

Context Help

The section is a reference of all context help topics.



■ Temporarily Assign Supervisor Passwords to

Functions

Certain situations may require users to execute functions for which they usually do not have the rights. These functions can be made available temporarily using a supervisor password. The user will have access to all cameras available for the project when launching the Supervisor mode.

1. In addition, you can specify after how many minutes of inactivity this user will be logged out automatically.

Note

While a recording is being played back in Playback view or in Grid Playback, MxMC does not automatically terminate the supervisor mode after the specified period of time.

2. Select the functions that can be accessed after entering the password.

Histogram Bar

The histogram illustrates the **distribution of event frequency** and thus provides a quick overview of the events of one or more cameras.

Opening The Histogram Bar

To open the Histogram bar, click on the dark gray ribbon on the right margin of the MxMC. To begin with, the histogram always shows the entire range of the events logged by the camera.



Fig. 156: Opening the histogram bar

Working With The Histogram

Structure Of The Histogram

The histogram is split into the overview area on the top and the zoomed area of the selected range below. The yellow scroll bar in the overview area shows the range that is displayed in the zoomed area. Click on to set the displayed time range in the zoomed area (for example, six hours or one day). If you have set the zoomed area to Custom," you can modify the displayed time range by dragging the edges of the scroll bar.

If you want to see only events in the zoomed area that have triggered recordings, click on \(\bar{\varphi} \). The pink area indicates the time range for which recordings exist for the logged events.

Note

The range of logged events may reach farther back than the recordings.




Fig. 157: Histogram bar in details

User interface elements in the histogram

1: Resolution of zoomed area (high / low), s set zoom range (custom or pre-defined), $\boxed{\mathcal{F}}$

Context Help

Histogram Bar

- (2): Zoomed area
- (3): Overview area
- 4: Current time marker
- ⑤: Event type and camera / camera group
- 6: Time range with recordings
- 7: Time range in zoomed area

Displayed Time Range

The timestamps at the top and bottom of the histogram show the first and the last of the available events logged by the camera, respectively. You can change this range manually. A small cross at the left of the time range indicates that it has been changed manually. Click on the cross to reset the timestamps to their original values.

Filter Feature

You can filter the display by camera, by group or by event type. There two sliders for this purpose: the group/camera slider and the event type slider . To set the filters, move the sliders until you see the desired results. The following filters are available:

Camera filter

- all cameras
- cameras from the current group
- a current camera

■ Event filter

- MxActivitySensor event
- wideo motion events
- PIR events
- microphone events
- (a) signal input events
- temperature events
- illumination events
- bell events
- noice mailbox messages
- Door Station events
- (C) RFID rejected
- PIN rejected
- all event types

Distribution Of Frequency

The length of the bars indicates the frequency of logged events per time unit. Click on to examine the distribution of frequency for a specific point in time in more detail. The display switches to a higher resolution.

For more detailed information on a specific point in time with a high event frequency, click on the related spot in the zoomed area or the overview area.

In the Playback view, a red marker is also displayed to indicate the current position.

Smart Data Bar

With the MOBOTIXSmart Data System, transactions in the MxMC can be linked to the video recordings made at the time of the transactions. It enables you to quickly find and review any suspicious activities. The Smart Data Bar and the The Smart Data View, p. 70 are available for searching and analyzing transactions. The Smart Data Bar provides a direct overview of the most recent transactions (from the last 24 hours) and for this reason it is convenient to use it for reviews and searches.

Opening the Smart Data Bar

The Smart Data Bar is available in all views. To open the Smart Data Bar, click on the right frame border of the application. The Histogram bar will appear. Click on the frame border again to switch to the Smart Data Bar. You can also open it from the menu (**View > Smart Data Bar**).




Fig. 158: Smart Data Bar

Using the Smart Data Bar

If a Smart Data Source, e.g. a cashpoint is transmitting new data to the camera, the Smart Data Bar is automatically updated. It enables live surveillance of the cash point and of the retail data of a camera. You can group transactions that belong together and display them.

■ **Displayed time range:** The Smart Data Bar only contains the data from the last 24 hours. You can search data that is older than 24 hours in the Searching Transaction Data, p. 352 dialog.

- **Search feature/Filter feature:** You can filter the entries for each cash point's camera by search term. The hits are highlighted in yellow. You can jump to the next/previous search result using the two arrows on the lower edge.
- **Do not show system transactions:** By default, the Smart Data Bar shows all transaction that are stored on the corresponding camera. Some of the transactions, e.g. from a cash point, show purchases and events that are directly associated with the purchases, such as the "Total sum." Other transactions show only administrative events, such as when the cashier logs on. Click on to enable/disable display of system transactions.
- **Do not group receipts (for VECTRON cashpoints only):** Transactions are grouped by receipt number or purchase by default. Individual sales can be grouped if the cash point signals the conclusion of the transactions by creating a receipt number. Counter sales can be grouped by counter if the counter is settled in the cash point system. Click on to disable display by groups. The data will be reloaded.
- **Playback transactions:** Open the Playback view by double-clicking on a transaction line. The transaction will be played back.

Export Bar

The Export bar provides a quick and easy way to take camera recordings and MXG clips by dragging and dropping and create a list of recordings for subsequent exporting. From the bar, you can export recording time ranges as combined clips. You can add the clips in the Playback view, in Grid Playback, in the Research view and in the Smart Data View. The Export bar is not automatically deleted after an export. It is deleted when the program is closed.

Adding Clips for Exporting

Adding Clips for Exporting in the Playback View

- 1. Drag the desired camera or the desired clip from the camera bar or from the Device bar.
- 2. Find the recording you are interested in.
- 3. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green.
 - You can set the end marker first (gray flag on the right), then play the recording from the beginning so you can set the start marker (gray flag on the left) at the desired point.
- 4. Click on the image of the recording and maintain the position until you see a scaled-down image.

Export bar opens. Click on +. The selected time range will be copied to the Export bar.

5. Drag this image to the Alarm bar (regardless of whether or not it is open). The Alarm bar automatically turns into the Export bar, allowing you to place the image there.
Another option is to: Activate the Alarm bar. Click on the lower frame border of the open Alarm bar. The

Adding Clips for Exporting in Grid Playback

The Export bar in Grid Playback is the best way to combine **sequential time ranges** of different cameras. For example, you can use it to follow one person who passes by several cameras.

- 1. Drag the desired camera to the focus window in the grid and find the relevant recording.
- 2. Mark the start of the time range by clicking on the gray flag on the left. Play the recording until you have reached the end of the clip you want to export. Mark the end of the time range by clicking on the gray flag on the right. Both flags are now green.
- 3. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Alarm bar automatically turns into the Export bar, allowing you to place the image there.
- 4. After you have set the end marker of the time range, the recordings of all other cameras will reposition to show the same time. Drag the camera with the next recording in the sequence of events into the focus window. Mark the start and the end of the clip as described above, then drag the recording into the Export bar.
- 5. Repeat these steps until you have added all recordings you want to export.

Note

that you can also add time ranges from several cameras in the Export bar.

- 1. Simply drag the desired camera group from the Group bar or from the Device bar and search for the relevant recording.
- 2. Mark the start and the end of the clip as described above. The recordings of the other cameras will reposition accordingly.
- 3. Right-click on **Export**. A selection box with a checkmark appears in the top left corner of the recordings. If you do not want to add the recording range of a specific camera to the list, deactivate that camera.
- 4. Click on the image of the recording in the focus window and maintain the position until you see a scaled-down image. Drag this image to the Alarm bar (regardless of whether or not it is open). The Alarm bar automatically turns into the Export bar, allowing you to place the image there. This means that all selected clips have been added to the Export bar.
- 5. Repeat these steps until you have added all time ranges you want to export.

Adding Clips for Exporting in the Research View

In the Research view, you can add recorded event sequences to the list. The length of the event sequences is currently 10 seconds.

- 1. Set filters by camera, by group or by event type as needed.
- 2. Right-click on **Export**. A selection box appears on the event images in the top left corner. Select the desired events by clicking on the corresponding selection boxes.

- 3. Open the Export bar by clicking on the lower frame border of the open Alarm bar. Click on an event image and maintain the position until you see a scaled-down event image. Drag this image to the Export bar. The clips of all selected event images are added to the Export bar.
 - Another option is to: In the Export bar, click on +. The clips of all selected event images are added to the Export bar.
- 4. If needed, you can set new filters and add more event images to the Export bar.

Adding Clips for Exporting in the Smart Data-View

You can add clips for the individual Smart Data transactions to the Export bar. The default clip length is ten seconds on either side of the transaction time stamp, that is, for a total of 20 seconds.

- 1. Right-click on **Export** A selection box appears on the preview images in the top left corner. Select the desired transactions by clicking on the corresponding selection boxes.
- 2. Open the Export bar by clicking on the lower frame border of the open Alarm bar. Click on an preview image and maintain the position until you see a scaled-down preview image. Drag this image to the Export bar. The clips of all selected preview images are added to the Export bar.
 - Another option is to: In the Export bar, click on +. The clips of all selected preview images are added to the Export bar.

You can also add clips for the individual preview images of the selected transaction to the Export bar. To do so, drag the transaction preview image in the **Preview Image** section and drop it on the Export bar.

Editing Clips

If you have added a recording to the Export bar, for which you had activated distortion correction or zoom features during playback, you can choose to export the clip with or without PTZ settings. Likewise, you can export the clip with or without audio. To do so, move the mouse pointer over the recording in the Export bar. Three icons appear:

- (h): Clip is exported with PTZ.
 - Click on ① to export the clip without PTZ. The icon is disabled.
- : By default, the clips are exported with audio (provided that audio had been recorded).
 - To export without audio, click on . The icon is disabled.
- Note that you can review the clips before exporting by playing back individual clips directly in the Export bar. Click on to do so.

Right-click on a clip to open a context menu with these functions: Manually adjust time range, activate/deactivate audio and PTZ for all clips, duplicate a clip, delete one or all clips.

Exporting

Click on **Export**, then select MOBOTIX to export an MXG clip. Select a different profile to create an AVI file. Select a target folder in the Export dialog and enter a file name. Activate the **Automatically import** after export checkbox to automatically add the MXG clips to the Export bar after exporting.



Door Station Events

You can limit the display of event images so that only door station events are displayed. These events include:

- △ Ringing
- Mailbox Message
- Door Station
- (A) RFID Rejected
- PIN Rejected

Right-click on and select the desired event types.



Door Status Display

- = Door is closed.
- = Door is open.
- = Door is locked.
- 🔽 = Bolt is locked, but door is open!

Light Status Display

- 🏂 = Light is off.
- 💈 = Icon is on: Lights are on, need to be switched off manually.

Microphone Status Display

- Microphone is switched off, no announcements possible.
- ①: Microphone is switched on, announcements are possible.
- Microphone connection is blocked; possibly because a connection exists from another remote station.

Highlighted Images

Images that you have marked while examining them in the Playback view, can be displayed here. Click on D to show only the marked images.



Internal Events

You can limit the display of event images so that only internal events are displayed. These events include:

- Action Group Termination
- Custom Signal State
- Recording

Right-click on and select the desired event types.



Refresh

If the response to an action takes too long, you can click on **Refresh** to close and reopen the connection.

- Click on to close and reopen the connections to the **currently visible** cameras.
- Click on and hold the button for at least one second to close and reopen the connections to all cameras attached to MxMC.

Multi-camera Configuration

The Multi-camera Configuration dialog box allows changing authentication data used by MxMC and the environment settings of many cameras in one step. When opening the dialog, the application shows the current settings of the cameras. The field is labeled with "multiple values" if one option has several different settings.

Status Display

Field type	Current status
admin [Multiple Values]	All cameras have the user name admin . The cameras have different user names.
	This settings has been activated for all cameras. This settings has been deactivated for all cameras. The cameras have different settings.
[Multiple Values]	"HiRes" has been set as bandwidth setting for all cameras. The cameras have different values.

Changing the Settings

For more information on the individual settings, please see the Camera Configuration help topic. As opposed to the configuration of only one camera, you can revert the changes that have not been stored. Depending on the field type, you can use different methods.

Field type	Explanation
User ×	If you change the text box of a setting, such as User name , a small cross appears on the right-hand side. Click on the cross to reset the entry to its original value.
	When closing the dialog, the previous setting will be restored.
[Multiple Values]	If you select Several Values in a selection box, closing the dialog will restore the previous setting.

Notes on the Settings

Here are several tips that will help properly edit the contents of the boxes, although the boxes and settings in this dialog box are identical to the **Camera Configuration** dialog box (see Camera Configuration). These tips will be described in the following:

Recording path:

Local path: The **Local Path** option can be selected for all cameras. Note that you will need to enter the paths **individually for each camera** in the **Camera Configuration** dialog (see *Recording Path* in Entering and Editing Network Data).

Recording path: If you select a recording path (see *Recording Path* in Entering and Editing Network Data), MxMC automatically searches the device directory for each camera. The search has been completed if the progress bar is replaced by **OK**. If you close the dialog beforehand, you will have to enter the device directory for each camera in the **Camera Configuration** dialog.

Alarms:

The **Alarms** option activates or deactivates the alarm notification for all cameras. Note that you will have to set the alarm settings for the event types individually for each camera. Use the **Camera Configuration** dialog to do this (see Setting up and Changing Alarm Notification).

Program Call

The desired dialog could not be opened. This can have the following causes:

- MxMC was not started.
- The online help was not opened from MxMC.
- You do not have the required permission to access the dialog.

Live images

The Grid view shows the live images of all cameras of the selected camera group. The focus window can be used to closer examine the camera's live image, the grid area shows the live images of the other cameras. If you move the mouse over the bottom of one of the live images, the Alarm Info bar with the images appears. Move the slider to the left. This opens the Instant Player with the last event image. Drag the red counter along the bar to show the preceding images. Click on to play back the corresponding recording. By activating the edit mode, you can set the format of the Grid layout – and thus the size of the live images and the focus window directly in the Grid view. Click on to do so. The Command bar will display several controls.

Alarm Bar

The Alarm bar turns red if events occur that lead to an alarm. This happens only if the **Alarms** option has been activated in the **Camera Configuration** dialog box and if the corresponding event types have been activated

You can filter the displayed alarm images in the bar by event type or by camera and play back the recording of an event directly from the Alarm bar. Click on the frame border to show the Alarm bar. To hide the Alarm bar, pull down the upper frame border.

If you click on the lower frame border with the alarm bar open, the bar changes to show the Export bar. Using drag, the Export bar provides a quick and easy way to collect recordings for subsequent exporting.

Detecting and Acknowledging New Alarms

You can activate the **Alarms** option in the **Camera Configuration** dialog box (right-click on the respective camera in the Device bar) for the corresponding camera and environment if you want events to trigger an alarm in a camera. In addition, you can select the event types that will cause an alarm. If the bar is hidden, new alerts will be indicated by a red frame border . If the bar is open, the info bar of the event image turns red. A ringing at the door bell will color the bar in green

To acknowledge a new alarm, right-click on the event image and select **Confirm**. To acknowledge all new alarms at once, select **Confirm All**.

Viewing the Live Image of the Triggering Camera

To quickly check the current situation, a single click into the Grid view of the corresponding camera group is sufficient. The live image of the triggering camera is automatically displayed in the focus window. The advantage is that you see not only the live image of the triggering camera, but also the live images of the cameras in the same area, thus giving you a complete overview of the situation. Of course, you will have to combine the cameras into corresponding groups beforehand. To switch to the Grid view, move the mouse pointer over the alarm image. Three icons appear. Click on \blacksquare .

Filtering the Display of Alarm Images

The alarm images in the Alarm bar are sorted chronologically. You can filter the event images by camera and group, by alarms or by event type. There are three slider bars for this purpose: camera filter, alarm filter and event filter. To set the filter, move the sliders until you see the desired results:

- Camera filter:
 - All cameras 🚳, cameras from the current group 🔠, current camera 🚳.
- Alarm filter:
 - All events 🚱, alarm events 資, unconfirmed alarms 資.
- **■** Event filter:
 - MxActivitySensor events , video motion events , PIR events , microphone events , signal input events , temperature events , illumination events , bell events , voice mailbox messages , Door Station events , RFID rejected , PIN rejected , all event types .

Note

If background alarm calls have been deactivated in the **Camera Configuration** dialog box (see Entering and Editing Network Data), the application will only open an connection for the cameras if necessary, such as when live stream of the camera or recordings are played back via the camera. This means that if you set the camera filter to **All cameras** when background alarm calls are deactivated, only the alarms of the currently connected cameras are displayed.

Playing Back Recordings

- You can play back the recordings of an alarm directly from the Alarm bar. To do so, move the mouse pointer over the alarm image. Three icons appear. Click on ▶.
- To play back the alarm in the Playback view, move the mouse pointer over the alarm image. Click on to switch to the Playback view.

Deactivating Alarms

You can use the Camera Configuration dialog box or the Alarm bar to deactivate alarms.

- Deactivating alarms for a specific camera and event type:
 Right-click on the desired alarm image and select **Deactivate As Alarm**.
- Deactivating alarms for all event types:
 Right-click on an alarm image and select **Deactivate All Alarms**

List View

The search results from the Smart Data Search can be displayed either as a list or as tiles. Click on stoplay the results in a list.

Event Images

In the Research view, the program displays an overview of all event images. To narrow down the number of displayed event images, click on the desired event type in the command bar. All event images are shown with the date/time of the triggering event and an icon for the event type.

Playing Back Event Recordings

■ The event image provides direct access to the event recording. To do so, move the mouse pointer over the image. Three icons appear. Click on to start the playback.

Note

A click into the image after starting the playback opens the recording in full screen mode in the current program window.

■ To play back the event in the Playback view, move the mouse pointer over the event image. Click on to switch to the Playback view.

Loading Additional Event Images

It can happen that the number of recordings of a camera is quite large. In such a case, loading all event images would take very long. In order to prevent long wait times, the camera loads only a certain amount of images. However, you can manually load the remaining images. Click on **Load more** at the end of the list.

Note

If the **Load more** icon at the end of the list is not present, there are no remaining event images in the selected category.



In Auto Grid mode, MxMC always tries to distribute the available space as well as possible according to the specified grid parameters, such as the aspect ratio of the tiles (4:3, 16:9, 8:3) and the number of cameras. This may cause the grid layout to change when resizing the program window.

Click on \nearrow to freeze the displayed layout and to prevent the automatic layout adjustment. This means that the frozen grid layout will be used regardless of the window size.



By clicking on , you can establish a two-way audio connection to any camera equipped with a microphone and speaker or to any door station. If you only want to hear what the camera's audio channel is recording, you can activate/deactivate the microphone of the computer by right-clicking on . To close the audio connection, click on .

Search Results in Tiles

The individual search results are displayed in the Tile view as preview images. You can either directly view the recording for the transaction in this preview image as an instant playback or you can switch to the camera's Playback view and view it there. In addition, you can switch to this camera's Live view directly from the preview image.

Switching to the Live View

To do so, move the mouse pointer over a preview image. Three icons appear. Click on 💼 to switch to the Live view.

Preview Image Playback

You can either directly view the recording for the transaction in the preview image or you can switch to the Playback view and view it there. To do so, move the mouse pointer over the preview image. Three icons appear.

Click on to activate the Instant player.

Note

A click into the image after starting the playback opens the recording in full screen mode in the current program window.

■ To see the recording directly in Playback view, click on □.

Adding Recordings for Exporting

The Export bar provides a quick and easy way to add clips for exporting. The default clip length is ten seconds on either side of the transaction time stamp, that is, for a total of 20 seconds.





Connection Monitoring

If the connection to a camera is lost (due to a network failure, for example), the application can show a warning. To set up this warning, select MxManagementCenter > Preferences > Monitoring (Windows: File > Settings > Monitoring) from the menu. Activate the Lost Connection Detection checkbox and specify how you want MxMC to react if the connection to a camera is lost.

Setting the Behavior When Detecting a Lost Connection

Play sound

- You can choose to always play a sound when a lost connection is detected or only if the camera is in
 HiRes mode. If the camera is not in HiRes mode, you are probably accessing the camera remotely, that is,
 from a mobile network, which makes dropped connections more likely. The HiRes Only option excludes
 unnecessary warnings.
- 2. Then select the desired sound.

Visual warning

- 1. Specify if you want to see a visual warning in addition to the sound. As above, you can choose to always show a warning when a lost connection is detected or only if the camera is in HiRes mode.
- 2. Adjust the dead time for the sound and the visual warning. The application will wait for the dead time to pass before playing a sound or showing a warning.

Note

You should not set the dead time too short, since this would cause many unnecessary warnings.

Checking for Dropped Connections

At any time, you can manually check the connection status of the cameras. This check is independent of the lost connection settings in the preferences. To see the status, click on **Windows > Lost Connections** in the menu.

Detecting Lost Connections

been re-established.

Depending on your lost connection settings, the application will play a sound and show a warning or it will only play a sound or only show a warning if a connection is lost. If you have deactivated both the sound and the visual warning, the lost connections icon appears in the header bar and shows the number of lost cameras.

- **Sound:** To manually stop the sound, click on in the header bar or on **Mute** in the visual warning. If you do not manually stop the sound, it will stop automatically once all connections have been reestablished.
- Visual warning: The warning shows the preview images of the cameras that cannot be reached. Note that you can temporarily ignore the visual warning. To do so, click on Ignore and select the time span for which no visual warning should appear when detecting lost connections.
 If you do not manually close the warning, it will disappear automatically once all connections have
- **Icon in Header bar:** If you have deactivated both the sound and the visual warning, only the red icon in the Header bar will inform you about dropped connections. Click on the icon to show the cameras that cannot be reached. A warning will open, showing the corresponding preview images.



Cameras of the Camera Group

When opening the Graphic view of a camera group for the first time, all cameras of the group are shown as icons at the right-hand border. You can then move the cameras to their actual position on the ground or floor plan, just like in reality.

If you have activated the **Alarms** option in the **Camera Configuration** dialog box, the corresponding camera icon turns red upon detecting an alarm or green if the bell rings. You can quickly check the current situation in the Graphic view by showing a small live image (move the mouse pointer over the icon) or by showing a large live image (click on the camera icon). If a second monitor is available, double-clicking on the icon will show the live image on that monitor.

Instructions:

Activate the edit mode to arrange the cameras. Click on to do so. To save the changes, click on ...



+ Adding Cameras, Devices, Clips and Recordings,

Creating Groups

Please select the desired action: Adding cameras in the local network, adding cameras manually, creating camera groups, importing clips and recordings, creating recording paths or adding a MxThinClient.

Adding Cameras in the Local Network

All cameras and door stations in the local network are detected automatically.

- 1. Click on The Installation Wizard opens and lists all cameras that were found on the local network.
- 2. Select the camera you want to add (use CMD-click on a Mac or CTRL-click on Windows to select several cameras).
- 3. Specify a user name and a password. Click on [7] to do so. When multiple cameras have been selected, all of these cameras will get this user name and password.
- 4. Click on and then on **Finish**. All new cameras are shown in the device bar in the **Cameras** section and you can already see the live images of the cameras.
- 5. You should now complete the data for the individual cameras. Open the **Camera Configuration** dialog box for this purpose. To open the dialog box, you can either right-click onto individual cameras or you click on the o icon, which is shown if you position the mouse pointer over the camera name. The Camera Configuration dialog opens.
- 6. Close the dialog once you have completely filled in the camera data in the Camera Configuration dia-

Adding Cameras Manually

Cameras outside of the local network (for example, on the Internet) need to be added manually.

- 1. Click on . The **Camera Configuration** dialog opens.
- 2. Enter the camera access data:

Name: Enter a descriptive camera name.

URL: IP address of the camera.

Remote URL: You can enter the corresponding external address of the camera (such as a DynDNS name) when adding it to access the camera from outside the local network.

Please note: You need to activate the **Remote** option for the corresponding environment in order to use the remote URL to connect the camera. The camera connection may be switched when the environment is changed.

User name, password: Enter the user name and password of the camera.

- 3. Complete the network data and set up alarm notification as described in Camera Configuration.
- 4. Close the dialog once you have completely filled in the data in the **Camera Configuration** dialog. Then deactivate the edit mode of the device bar by clicking on ...

Creating Camera Groups

You can combine individual cameras into camera groups. For example, you can combine all cameras situated on the same floor in one group. This allows checking on entire surveillance areas at one glance and – in case of an alarm, you are quicker to access the relevant cameras.

- 1. To create a camera group, click on . The **Group Configuration** dialog opens.
- 2. Fill in the data as described in Creating Camera Groups.
- 3. Close the dialog once you have completely filled in the data in the **Group Configuration** dialog. Then deactivate the edit mode of the device bar by clicking on ...

Adding Clips and Recordings

Adding Clips

You can use MxMC to play back exported MxPEG clips. Click on to do so. The **Load Clips** dialog opens: Select the desired MXG file and click on **Open**. The clip appears in the device bar in the **Clips & Recordings** section.

The Sicon indicates that a clip file cannot be located anymore.

Adding recordings

You can directly access recordings that are saved on a file server, even if the respective camera is not integrated in MxMC. Click on to import a recordings folder. Select the desired folder and click on **Open**. The sequences will appear in the **Device** bar in the **Clips & Recordings** section.

Creating Groups for Clips and Recordings

Clips and recordings can be compiled into groups and subgroups to better organize the clips and recordings. Click on to create a group. A new group will be added. By default, this group will be called "New Group." Click on the selected new entry and enter the desired name. Drag and drop the desired clips and recordings onto the group.

The **property** icon indicates that there are no clips or recordings in the group.

Adding a MxThinClient and Activating Live Images

You can now also integrate one or more MxThinClients in MxMC. For example, you can an additional display unit (monitor or TV) by double-clicking on the camera live images of P3 and Mx6 cameras from MxMC.

Adding a MxThinClient

the same time server.

- The MxMessageSystem needs to be activated in the settings and you need to make sure that the Broad-cast port and Password fields contain the same settings as you configured in the MxThinClient because the camera live images are switched on with MxMessageSystem (Mac: MxManagementCenter > Settings > MxMessageSystem; Windows: File > Settings > MxMessageSystem).
 You also need to make sure that the MxThinClient and the computer running MxMC are synchronized via
- 2. Click on to add a MxThinClient. The **MxThinClient Configuration** dialog box opens. Complete the entries as described under Entering MxThinClient Settings.

Activating Camera Live Images

There are two options for activating a camera live image on an additional display unit:

- **Double-click:** Double-click on the desired camera live image.
 - The images are displayed directly on the display unit connected to the MxThinClient if there are not any other monitors connected to the MxMC computer and the MxMC is only connected to one MxThinClient.
 - If there are more than one monitors connected to the MxMC computer or several MxThinClients connected with MxMC, you are prompted to select the desired display unit for displaying the images.
 - **By drag and drop:** Drag and drop the desired camera live image from the Camera bar or from the Device bar onto the desired MxThinClient in the Device bar.

Note

The **MxThinClient** section is only visible in the Device bar if a MxThinClient has been integrated. You need to possess administrator rights to add, manage or delete a MxThinClient.



Use the **Playback speed** button to adjust the speed when playing back the recordings in the selected playback mode.

Tile View

The search results from the Smart Data-Search can be displayed either as a grid or as a list. Click on play the results as tiles.

⊘ Time Events

You can limit the display of event images so that only time events are displayed. These events include:

- Periodic Event
- Random Event
- 🥎 Time Task

Right-click on o and select the desired event types.

d Edit Mode

To change the Graphic, Grid, and Info views, click on in the corresponding view. To save the changes, click on .

△ Bell Settings

New bell events will increase the counter on the icon. Click on the icon to show these events. Click again on the icon to open the Playback view and to display the most recently viewed bell event. To edit the settings, open the shortcut menu by right-clicking .

Note

You can set the bell sound and its volume in Notifications (Mac menu MxManagementCenter > Preferences, Windows menu File > Preferences).

Possibilities of Doorbell Notification

You can have the doorbell ring at various places in MxMC:

- Alarm bar: The Alarm bar turns green.
- Alarm info bar: The Alarm info bar in the live images turns green.
- **Doorbell message:** A blue dialog box appears with the live image of the door camera. You can start a conversation and open the door directly.
- Counter on the bell icon: The red counter on the bell icon 🍱 increases by one.

You can configure the following options for notifications in MxMC:

Notifications	Setting options
Completely off	Deactivate the Bell checkbox in the Bell Settings to switch off the bell completely. (see Turn Off Bell Completely, p. 315)
Doorbell message, Alarm bar, Alarm Info bar and Counter on the bell icon	 You need to configure the Alarm notification for the doorbell to ring at these places. To do so, open the Camera Configuration dialog box by right-clicking on the corresponding camera in the Camera bar. Another option is to open the dialog box in the Device bar by clicking and then right-clicking the corresponding camera. Click Alarms and activate the Alarm notification and the doorbell ringing. See also: Setting Up and Changing Alarm Notification
Counter on the bell icon only	 Deactivate doorbell ringing in the Alarms dialog box and only the counter on the bell icon will increase by one each time. To do so, open the Camera Configuration dialog box by right-clicking on the corresponding camera in the Camera bar. Another option is to open the dialog box in the Device bar by clicking and then right-clicking the corresponding camera. Click Alarms and deactivate doorbell ringing.
Bell sound on or off	You can turn the bell sound on/off in Notifications (Mac menu MxManagementCenter > Preferences, Windows menu File > Preferences).

Note

You need to make sure that Alarm notifications are activated and a bell profile has been set up in order for doorbell notification to work.

Turn Off Bell Completely

Deactivate the **Bell** checkbox if you want to switch the bell off completely. It means that a doorbell ringing will not be indicated at other remote stations and the counter for the doorbell will not increase. In this case, you will not be informed if you missed any visitors, they cannot leave a message and the camera will not store any recordings.

Selecting a Bell Profile

You can now also select the bell profile in the Bell Settings. This specifies how MxManagementCenter reacts when the doorbell rings. The camera provides several **predefined** bell profiles. You can also create your own bell profiles. Use the Configuration view for this purpose.

- No ringing: MxManagementCenter and all other remote stations will not react, meaning that you will not notice if someone is ringing (neither visually nor by sound).
- Ring and message: You will hear if someone rings the doorbell. If you do not react within a given period of time, the Door Station plays back an announcement and the visitor can leave a message.
- Message only: After ringing, the Door Station immediately plays back an announcement and the visitor can leave a message.

Click **Profile** and select the desired profile.



© Camera Configuration

After you have added the cameras, you should enter the remaining camera data. Even when the system is up an running, you may have to make some changes. Open the Camera Configuration dialog to enter and edit the camera data.

Entering and Editing Camera Access Data

- 1. Name: The camera name is displayed automatically. If required, you can enter an individual name for each camera.
- 2. Connection Protocol: To enable MxMC to establish a connection to the camera, the appropriate connection protocol must be selected depending on the available interface of the camera manufacturer. If you have integrated the camera with the Welcome Wizard, the corresponding protocol is automatically selected. When manually adding the camera, select the appropriate protocol.
- 3. URL: The IP address is either discovered automatically via Bonjour or it has been entered manually.

- 4. *Remote URL:* You can enter the corresponding external address of the camera (such as a DynDNS name) when adding it to access the camera from outside the local network.
 - Please note: You need to activate the **Remote** option for the corresponding environment in order to use the remote URL to connect the camera. The camera connection may be switched when the environment is changed.
- 5. User name, password: Access data that had been entered when adding the camera.

Entering and Editing Network Data

- 1. *Environment:* Shows the current network environment. After starting the program for the first time, it shows the standard environment. All existing network environments are shown in the blue bar. Click on the environment you want to use. Next, enter the network settings you want to use for this environment.
- 2. Background alarms: An **activated** option means that the application maintains an active event stream connection to the camera, regardless of whether or not MxMC is showing the live stream. Using the event stream connection, the cameras will send event information to MxMC, which will show them as alarms depending on the settings (see Setting up and Changing Alarm Notification). You can deactivate this option if a permanent event stream connection is not required or even unwanted (due to high system loads on systems with very many cameras or when using MxMC in low-bandwidth networks, for example).

If this option has been **deactivated**, the application will only open an event stream connection if necessary, such as when MxMC shows the live stream of the camera or recordings via the camera. In this case, alarms will only show for this camera, while the connection has been established. This option is deactivated by factory default.

Note: This option is not supported by MOBOTIX MOVE cameras and third-party cameras that provide an ONVIF S compatible interface. For an overview of the camera function differences, see Cameras Function Overview.

- 3. *Remote*: When adding the camera in the local network, you do not change this setting. Only activate this option if you want to access the camera from a remote location (via DynDNS).
- 4. *SSL*: By default, the connection between MxMC and the camera is not encrypted. If you rather want to use an encrypted connection, activate this option. Note that HTTPS needs to be activated on the camera (in the browser in **Admin Menu > Network Configuration > Web Server > HTTPS Settings**).
- 5. *Bandwidth:* Depending on the bandwidth of the current camera connection, you can choose to see the images in HiRes, in LoRes.

Determining Recording Settings

Stored recordings can be accessed in different ways depending on the connection protocol.

For MOBOTIX cameras:

- Via camera (MOBOTIX cameras): The camera is handling access to the recordings.
- **Via recording path:** The camera is handling access to the recordings via a previously defined recording path. Recording paths can be defined in the program settings (Mac:
 - MxManagementCenter > Settings > Recording Paths; Windows: File > Settings > Recording Paths).
- Via a local directory: Local path (recordings are accessed on the local computer).

For MOBOTIX MOVE / ONVIF cameras:

■ Via MOBOTIX NAS: Access to recordings via a previously defined MOBOTIX NAS. You can specify the access data in the application settings (Mac: MxManagementCenter > Settings > Recording Paths; Windows: File > Settings > Recording Paths).

Click on **Recording settings** to adjust the settings to your needs. This opens another dialog box.

1. Choose the desired recording path:

Access via the camera:

No further settings are necessary.

Access via recording path:

- Select the corresponding recording path and set the corresponding recording format:
 Use MxFFS if the recordings have been stored in an MxFFS archive.
 Use MxFileServer if the recordings have been stored in the classic MOBOTIX folder/file structure.
- MxMC searches for the corresponding recordings in the subdirectories of the predefined file server path. Once the search has been completed, you can select the folder for this camera in the **Device Dir-ectory** selection box.

Access via local directory:

- Select the Local path option and set the corresponding recording format:
- Enter the file path in the **Local path** text box.

Note

Click on the pen icon in the text field to open a file selection dialog.

Access via MOBOTIX NAS:

- Select the appropriate MOBOTIX NAS and then select the appropriate device directory based on the IP addresses displayed.
- 2. Close the dialog box. The settings will be automatically saved when you close the dialog box.

Setting up and Changing Alarm Notification

This section allows selecting the event types that will lead to an alarm if the corresponding event is triggered. An alarm will be indicated at the following locations:

- Alarm bar: Turns red or green (door bell), the alarm images are shown in the Alarm bar.
- Alarm info bar: Turns red or green (door bell) in the live images.
- Alarm messaging: In addition, you can set up visual and sound notifications for alerting.

Click on Alarms to adjust the settings to your needs. The Alarm Events dialog opens.

- 1. Make sure that the **Alarm notification** option has been activated.
- 2. Select the event types that should create an alarm.
- 3. In addition, you can select a weekly profile for every event type that should trigger an alarm. As long as no other weekly profile has been selected, the setting is valid from Monday 00:00 to Sunday 24:00.
 - Click on Edit weekly profiles to create new weekly profiles. The Weekly Profiles dialog opens. Several predefined profiles are available, such as the Weekend profile (Saturday 00:00 to Sunday 24:00).
 - To add a profile, click on + . Enter a description. Highlight the desired active times in the table. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, select one first and then click on M.
 - You can change the description of an existing profile. Right-click on the name and overwrite it.
- 4. To select a weekly profile, click on the Weekly Profile dropdown list next to the event type and select the desired profile.
- 5. Click on the calendar icon to easily invert the settings of the weekly profile. For example, if you have created a profile with opening hours and would like to activate the alarms for the closing times, click on the **Invert weekly profile** checkbox and the profile is used in inverted fashion.



Post Video Motion Detection

This is where all functions in MxMC are listed that have been added as plug ins. Post video motion detection (Post VM) has already been added as a plugin. The post video motion detection allows searching recordings for changes in one or more image areas of a camera. This is done with the help of "motion windows."

Creating Motion Windows

- 1. Open the context menu of the plug in by right-clicking on . Select **Post Video Motion detection**. The dialog for setting up the post VM settings opens.
- 2. Click on pain the image area on the right-hand side of the settings dialog. A new window with a predefined video motion window opens.

3. You can execute the following commands:

- Modify the size of the video motion window: By moving the sides or the corners of the window.
- Create additional video motion windows: Draw a new window with the mouse.
- Duplicate a video motion window: Click on 📵.
- Delete a video motion window: Click on 🐼.
- Deactivate a video motion window: Click on

To close the editor window, click on \mathbf{X} in the top right corner of the window.

Setting Trigger Conditions

The Post VM windows allows setting different parameters that influence the detection results:

■ **Trigger level:** (White bar in diagram)

Controls the trigger threshold of the video motion windows. Move the bar to the bottom to recognize a movement if only a few pixels change from one image to the next. Move the bar to the top to recognize a movement only if many pixels change.

Sensitivity:

This setting controls how large the change of each pixel in a video motion window must be to count as movement. Together with a low threshold value, this setting can be used to fine-tune video motion detection. If you move the slider to the right, the detection's sensitivity increases, i.e., even smaller changes will trigger the detection.

■ **Correct Changes in Illumination:**

Activate this option to avoid false alarms, such as when lighting conditions change rapidly (for example, from sun to a cloudy sky).

Deadtime:

This sets the amount of time after the last detected post video motion event, during which pixel changes in a video motion window are ignored.

■ ØMedian Value:

Enter a long duration (2.0 sec., for example) to improve the detection of slow movements.

Note: Setting a value that is too high can lead to smears in the preview window.

Color Filter:

Select a color to limit the motion detection to a specific range or colors. The Post VM event will trigger if this color changes during post video motion detection.

Searching for Changes in Video Motion Windows

Once you have defined the video motion windows and have set the trigger conditions, you can search the recordings for changes in the video motion windows. Use the playback buttons in the command bar at the bottom.

It is best to use the **Backward/Forward playback** buttons when searching continuous recordings. For searching in event images, use the **Previous/Next image** buttons. If MxMC detects a change within a

video motion window, the frame of that window turns red and the search stops.

Device Bar

The device bar has a tree structure and provides for quick navigation of camera groups, cameras, devices and clips by opening/closing the branches. The tree structure makes it easy to manage camera groups and their associated cameras thanks to the sorting options. At the same time, you can use the Device bar to create camera groups, as well as add and edit cameras, clips and devices (a MxThinClient, for example).

Note: Note that you need administrative rights for most of the functions of the device bar. This is why the command bar with the buttons for **deleting**, **adding** and the **edit mode** at the bottom of the device bar is only available to users with administrative rights.

Adding Cameras and Devices, Creating Groups, Importing Clips and Recordings

Activate the Edit mode if you want to add cameras and devices (a MxThinClient, for example), create groups (for cameras and clips) or import clips and recordings. To do so, click on and then on at the bottom of the device bar. The Add and Import dialog opens.

Note

If you have administrative privileges, you can drag an MxPEG clip into the **Clips** section of the device bar to import it.

Adding Cameras to a Camera Group

After you have added cameras and created camera groups, you now need to assign cameras to the proper groups.

- 1. Activate the edit mode by clicking on 🛅.
- Simply drag the desired camera (use CMD + click on a Mac, Ctrl + click on a Windows computer to select multiple items) from the Cameras section to the desired group in the Camera Group section.
 Note: If you have assigned a camera to one group, you can copy this assignment to other groups by dragging the assignment from the first group to other groups.
- 3. Once you have assigned the cameras to the desired groups, you can deactivate the edit mode by clicking on .

Setting Group Functions

You can define group functions in the Grid and the Graphic views. For example, you can switch the lights of several cameras at once, make an announcement via several speakers or open a door without having to select a specific camera.

- 1. To define the group functions, activate the edit mode by clicking on

 ...
- 2. To do so, move the mouse pointer over the group name. Three icons appear. Click on .
- 3. The Group Functions dialog opens.

Changing the Data of Many Cameras

The **Multi-Camera Configuration** dialog allows changing authentication data used by MxMC and the environment settings of many cameras in one step.

- 1. Activate the edit mode by clicking on 🙃.
- 2. Select the cameras as needed.
 - Mac: CMD + click, Windows: CTRL + click
- 3. Right-click on one of the selected cameras. The Multi-Camera Configuration dialog opens.

Deleting Cameras, Removing Cameras from Groups, Deleting Groups

Note: Use CMD + click on a Mac or CTRL + click on Windows to select several cameras or groups.

Deleting Cameras

- 1. Activate the edit mode by clicking on 🙃.
- 2. Drag the camera from the **Cameras** section to ...
- 3. Once you have deleted the cameras, you can deactivate the edit mode by clicking on .

Note

Deleting a camera from the **Cameras** section will also delete the group assignments of that camera.

Removing Cameras from Groups

- 1. Activate the edit mode by clicking on 🙃.
- 3. Once you have deleted the cameras from the groups, you can deactivate the edit mode by clicking on \Box

Deleting Groups

- 1. Activate the edit mode by clicking on 🛅.
- 2. Drag a group from the corresponding section to $\overline{\ensuremath{\varpi}}$.
- 3. Next, activate the edit mode by clicking on

Working With the Device Bar

The device bar supports you in many ways: not only can you use it to create camera groups, add cameras and clips and manage these objects. The device bar's main purpose is to give you a quick overview over all camera groups, cameras and projects. By opening/closing the branches, you can simply navigate the camera groups and the corresponding cameras. The sorting options help in managing these objects.

Opening/Closing Sections

Click on to close a section, click on to open it again.

Moving Sections

If you move the mouse over the upper part of the section, the ‡ icon appears and the mouse pointer changes to the Move cursor. You can now click and drag the section up or down.

Setting Display Options

You can select how the cameras are listed, i.e., by camera name, IP address, factory IP address or reference image. Note that you can set different display options for the **Cameras** and **Camera Groups** sections. For clips, you can choose to list the clips by name or by path.

Click on and select the desired display option.

Sorting the Cameras

The Cameras section allows sorting the list. Click on $\uparrow \downarrow$ and select the desired sorting mode.

Overview of the Different Camera Statuses

An icon next to the camera name or the camera IP address will indicate the current status of the camera:

- Camera is not reachable.
- Wrong camera password
- Privacy mode is active
- Limited functionality (only live image access) due to old firmware (<4.0), old camera model (M/D/V12, M/D/Q22M) or proxy issue.

Selecting Favorites from Cameras and Groups

You can filter the displayed cameras in the Camera bar and the groups in the Group or camera bar using different filter criteria (by favorites, for example). Before you can use favorites, however, you need to label the desired cameras and groups in the device bar as favorites.

Activate the Edit mode by clicking on \Box . Move the mouse pointer over the camera or group name. Several icons are shown. Click on \Box . Next, deactivate the edit mode by clicking on \Box .

Selecting Views

The device bar allows selecting a specific view for a group of cameras or one camera. Move the mouse pointer over the camera or group name. Different icons will appear depending on whether you have moved the mouse over a camera or a group name. Click on the icon of the view you want to use.

Camera views: :: Live view, :: Playback view, :: Research view

Group views: :: Grid view, :: Graphic view, :: Grid Playback, :: further views (Research view, Info view)

Editing Names

Using the device bar, you can quickly modify the names of cameras and groups. Activate the edit mode by clicking on . Click on the camera or group name you want to change – it will turn yellow. Click again on the name and edit it as needed. Deactivate the edit mode by clicking on .



The Live recorder is available in the Live view and the Grid view. Click on to record directly from the displayed camera live images and save as *MXG files. In the Grid view, the camera's live image that is in the focus window is always recorded. For this reason, live recording can also only be used in the Grid view when there is a focus window.

Users with administrator rights can determine where the clips are saved and how long the recordings can be in **Settings** (Mac menu: **MxManagementCenter > Preferences > Live Recorder**, Windows menu: **File > Settings > Live Recorder**).

Note:

Audio can only be recorded with the Live Recorder under these conditions:

- Audio transmission must be activated on the camera side.
- In the Live View of the MxManagementCenter, the audio connection must be activated by clicking on



Starting and Stopping Recording

To start recording, click on . To stop the recording before the set period of time has elapsed, click on again. A message appears shortly before the set period of time has elapsed. You can stop the recording using this message or extend the set period of time.

The recording is also stopped when you switch to a different view from the Live view or the Grid view. However, the recording is not stopped when the camera is changed in the Live view or the group in the Grid view (unless this group does not have a focus window, in this case the recording is also stopped).

Play Clip

The live image data is stored in an *MXG file at the location specified in Settings during recording. The clip file is automatically imported into the current project when the live recording stops and the Device bar lists it using the project icon in the **Clips** section. You can click on the clip name to playback the *MXG clip file via the Device bar.



Meta Events

You can limit the display of event images so that only meta events are displayed. These events include:

- Event Counter
- 🔛 Event Logical AND
- 🛐 Event Logic

Right-click on and select the desired event types.



Next Image

You first set the desired mode for browsing the recordings in the **Playback mode**, for example, using one hour or all highlighted events. Depending on this setting, this button will jump to the **next** image in the recording (starting from the current image).



Use the two **Previous view** and **Next view** buttons to browse the view history. Note that the history will also store temporary views, such as briefly viewing the live image in the Graphic view or a temporary bandwidth adjustment for a specific network environment. When browsing the view history, the views will be shown with exactly the same settings as before.

Image Analysis Events

You can limit the display of event images so that only image analysis events are displayed. These events include:

- MxActivitySensor
- 🛪 Video Motion
- Behavioral Detection

Right-click on and select the desired event types.

≅ Camera Sequencer

If you want to see a different camera in the focus window, simply drag that camera to the focus window. Note that the camera sequencer can also switch cameras automatically.

Instructions:

- 1. Click on the camera sequencer icon state to activate the automatic switching.
- 2. Right-click on 🔁 to change the following settings:
 - **Duration Slider:** Move the slider to the desired duration (1 sec to 60 sec) to show each camera.
 - Autostart: Once you switch to the Grid view, the sequencer starts automatically.
 - **Stop at event:** The sequencer stops when an event has occurred, allowing you to further investigate the situation. To start again, click on ...
 - **Restart after confirmation:** Activate this option if you want to avoid having to restart the sequencer over and over again.

Search Results in Lists

The search results are displayed in the List view in a table in which the individual transactions are entered with detailed information. Click on a transaction line to view the receipt data and a preview image of the selected transaction.

Displaying Search Results

The most recently selected search query is automatically performed when you open the Smart Data View. Click on the desired tab to perform a previously saved search. The search results are displayed in the table as individual transactions.

Displaying Transaction Data

Click on a row in the table to select a transaction. The matching receipt data of the selected transaction is displayed in the **Transaction details** section.

Do not show system transactions

E.g. the transactions of a cash point contain events that are directly associated with the purchase, such as the total or subtotal. Some transactions also show administrative events only, such as when the cashier logs on or off. The system transactions can be hidden in the table with the receipt data. To do so, click on in the Title bar of the **Receipt** section.

Showing Preview Images

When you click on the row in the table, you do not only receive a display of the transaction data in the **Receipt** section, you also receive a preview image that belongs to the camera recording for the transaction in the **Preview Image**.

Switch to Live view

To do so, move the mouse pointer over the preview image. Three icons appear. Click on
to switch to the Live view.

Playback recording for the transaction

You can either directly view the recording for the transaction in the preview image or you can switch to the Playback view and view it there. To do so, move the mouse pointer over the preview image. Three icons appear.

- Click on to activate the Instant player.
 Hint: A click into the image after starting the playback opens the recording in full screen mode in the current program window.
- To see the recording directly in Playback view, click on □.

Adding Individual Clips for Exporting

The Export bar provides a quick and easy way to create clips on individual Smart Data transaction for subsequent exporting. To do so, drag the transaction preview image in the **Preview Image** section and drop it

on the Export bar. The default clip length is ten seconds on either side of the transaction time stamp, that is, for a total of 20 seconds.



Image Correction: PTZ and Display

Modes in Recordings

You can zoom and move the visible image area not only in live images but also in recorded images (PTZ). It enables you to examine specific image areas more closely while the recorded video stream plays back. On Dual cameras, the program also shows the find slider. Use this slider to show the images of either the right, the left or both image sensors. When playing back the recordings of hemispheric cameras, you can set different display modes .

Zooming and Moving Image Sections

You can zoom using the slider 🗗 or the mouse wheel. To see other image areas, you can move the recorded image using the mouse.

Choosing a Sensor

On Dual cameras, you can opt to see the recordings of the right, the left or both image sensors. To do so, move the slider to the right to (left sensor) or further to the right to (right sensor).

Display Modes and Panorama Correction

When showing recorded images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. Note that this type of correction only takes place locally. This means that the distortion correction of the recorded images only takes place on this computer. The stored recordings (from the camera or a file server) are not influenced in any way.

Select the Display Mode

- **○Full image:** Shows the entire (distorted) full image.
- **Normal:** Shows a distortion-corrected image and allows executing PTZ actions. This is the factory default for hemispheric cameras.
- Panorama: Shows the distortion-corrected image of an entire room (corrected 180° panorama view) from the left to the right wall. The aspect ratio (width to height) is 8 to 3.

- **Surround:** Shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the Northern half of the image and a second panorama view of the Southern half of the image using an aspect ratio (width to height) of 4 to 3. This mode only makes sense for a hemispheric camera that is mounted to the ceiling.
- **Panorama focus:** This display mode combines the panorama view (aspect ration 8 to 3) with two smaller images (each with aspect ratio 4 to 3) in one large image.

Move the slider on to the right until you see the desired view. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined using the panorama correction. Move the slider to the right to and use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.



If new mailbox messages are available, the counter at the icon shows the corresponding number. Click on the icon to show the messages. Click again on the icon to open the Playback view and to position it on the mailbox message you viewed the last time. In the Mailbox settings, you can activate the mailbox and select the announcement, among other things. To edit the settings, open the shortcut menu by right-clicking on

Selecting a Voice Mailbox and a Bell

Depending on the installed options and the configuration of the door station, you may have several bell buttons or – in case a MOBOTIX keypad module has been installed – several contact numbers. Each of these bells or contact numbers has its own mailbox. The corresponding mailboxes are presented in the list (below the name of the bell). Select the desired voice mailbox.

Note

All settings made in the **Mailbox** function always apply to the selected mailbox. This also means that the new messages counter only applies to this mailbox. To get the messages and recordings of a different mailbox, select that mailbox first.

- 1. Click on Mailbox and select the desired bell.
- 2. Proceed by selecting one bell profile for each mailbox.

Activating the Voice Mailbox and Selecting a Welcome Message

- 1. Activate the mailbox with **Active**. Select the message that will be played to the visitor.
- 2. Click on **Welcome message**. Select the desired message.

Enabling the Message

If visitors should be allowed to leave a message, activate the **Leave Message** option.



P Highlight Recorded Images

When you come across events that you want to examine later, you can add markings to the corresponding images. The images thus marked can be shown one after the other in the Playback view or you can display them in the **Research view** and examine them more closely.

Click on to highlight a recorded image.





Image Settings

The display of the current camera can be easily adjusted to the current environment.





Instructions:

Move the sliders upwards and downwards. The new settings are stored automatically for the current camera. The default values can be restored by double-clicking on the corresponding sliders.

Adjusting the image settings does not have any effect on the camera settings. These will not be changed.

Alarm Settings

New events will increase the counter at the **Alarms** button . Click on to see the event that triggered the alert. Click again on 🖀 to open the Playback view and to position it on the event you viewed the last

Bandwidth

time.

If the Alarms option has been activated in the Camera Configuration, the alarm and alarm info bars will

turn red and will inform you about the events that triggered the alert.

In addition, you can choose to receive an alarm message and an alarm sound. To do so, activate the **Alarms** option in Notifications (Mac: menu **MxManagementCenter > Settings**; Windows: menu **File > Settings**) and select the alarm sound, alarm duration and volume.

Note that you can also activate the **Privacy Mode** in the alarm settings. This feature can disable and lock certain features of the camera for a specific period of time. This mode is valid for 24 hours. Note that you can also deactivate the mode manually before the 24 hours have passed. Click on and select the features that you want to switch off. If the **Privacy Mode** icon appears in the top right corner of the camera image, this mode has been activated.



Bandwidth

Using MxManagementCenter, you can access cameras from different locations. To do so, you need to define different **environments**, which will store the access data for the individual cameras. By assigning a bandwidth to an environment, you can specify how the images are pulled from the cameras given different connection speeds. This basically controls how the images can be displayed for live viewing and event research. Note that you can temporarily overwrite the bandwidth setting without actually changing the setting for the current environment.

- HiRes: The images are transferred using the current camera settings.
- Lores: The images provided are in CIF size and with low frame rate.
- **Unchanged:** If you have changed the bandwidth several times, you can use this setting to quickly revert to the camera settings for this environment.



Control Elements of the Focus Window

This window provides the same controls as the Live view. You can thus open the doors of the camera in the focus window, control the lights or show the temperature.

Focus Window

The Grid view shows the live images of all cameras of the selected camera group. You can drag the camera image that is most interesting to you into the focus window. Use the switching and control functions at the bottom to control the camera.



Save Snapshots

You can save snapshots from live images or from recordings. The snapshot also contains the camera name and date/time of its creation. To set a different destination folder or quality for the snapshot images, open the Settings in the menu (Mac: MxManagementCenter > Preferences > Snapshot Images, Windows menu: File > Settings > Snapshot Images). To save a snapshot, click on .



Projects and Network Environments

A project comprises all access data of the attached cameras in MxManagementCenter, the settings of these cameras and camera groups with assigned layouts, among other information. You can store such a project in order to install the same environment on other computers.

You can use MxManagementCenterto access cameras from different locations. This usually means that each location requires using different network access data. To avoid having to change the network access data every time, you can set up different network environments with the corresponding network access data.

Saving and Providing Projects

If you save a project, you can include the encrypted access data for each camera (user name and password). This access data is automatically used when the project is opened in MxManagementCenter. If you do not include the access data, the user name and password will have to be entered manually for each camera. The same applies to a project sent by email; you can opt to include the encrypted camera access data (user name and password).

Saving Projects

In the header bar, click on **Projects and Environments** and then on **Save as**. Fill in all remaining fields of the dialog.

Providing Projects via Email

Note that you need a properly configured email client for this purpose. In the header bar, click on **Projects**and **Environments** and then on **Email to**. The file is automatically attached to a new email.

Opening Projects

In the header bar, click on **Projects and Environments** and then on **Open**. Decide if you want to save the current project as a backup or if you want to replace the current project. Fill in all remaining fields of the dialog.

Opening Projects Received by Email

Store the attached file on your computer. In the header bar, click on **Projects and Environments** and then on **Open**. Decide if you want to save the current project as a backup or if you want to replace the current project. Fill in all remaining fields of the dialog.

Creating Network Environments

Creating Environments

- 1. In the header bar, click on **Projects and Environments** and then on **Environment**.

Deleting Environments

Click on 🗖 and then on 😑 next to the environment you want to remove.

Changing Network Data and Selecting Environments

After creating the environments, you can select the cameras that will be active for each environment and adjust the network data as needed.

- 1. In the command bar, right-click on the desired camera to open the **Camera Configuration** dialog box.
- 2. Select the environment and bandwidth you want to use for the environment for this camera.

Selecting Environments

In the header bar, click on **Projects and Environments** and then on **Environment**.

Display Focus Window

Click on to switch the focus window of the current group on or off.

Message Events

You can limit the display of event images so that only message events are displayed. These events include:

- IP Receive
- MxMessageSystem

Right-click on and select the desired event types.

Forward Playback

You first set the desired mode for browsing and playing back the recordings in the **Playback mode**To example, you can play back the entire recording or just intervals of one hour between images. Use the button to start and stop the playback. Starting with the currently displayed image of a full recording, the program plays back all recorded sequences in regular (**forward**) direction. If you set the playback mode to one hour, the program will play back the images with one-hour intervals (time-lapse playback) in **forward** direction.

Camera Group

To display additional camera groups, drag them from the Group bar or the Device bar onto the current Graphic view. Click on the group icon to open the Grid view of the camera group. If a new alarm occurs (the

bar at the bottom of the group icon turns red or green), you only need one click to open the live image of the alerting camera as well as the live images of the other cameras of that group.

Instructions:

Activate the edit mode by clicking on . Drag the desired camera group from the Group bar or the Device bar onto the Graphic view.



Environment Events

You can limit the display of event images so that only environment events are displayed. These events include:

- 🔏 Illumination
- Microphone
- Passive Infrared Detector
- B Temperature

Right-click on and select the desired event types.



Creating Users or Administrators

You need administrator rights to add a new user or establish an additional administrator.

User type and user name

- 1. Enter the corresponding user name.
- Select the desired user type: user or administrator.
 The user type is set to User by default. The sections Weekly profiles and User rights are available for
 - users, in contrast to administrators. All other settings apply to both user types and will be used in the following description; however, reference will only be made to **User**.
- 3. Use the **Active** option to enable the new user immediately or later on.

Password

- 1. Enter a password and confirm it.
- 2. Use the **Expires** option if you want to require the user to change the password at regular intervals.

3. If the user is to change the original password upon the next log in, select the **Force change on next log in** option.

Note: Activating this option automatically gives the user the "Change Password" right, even if it had been disabled before.

4. The **Force Complex Password** option ensures that users can only set secure passwords.

A secure password has at least eight characters, consists of lowercase and uppercase letters, including at least one special character, one digit and one character. Furthermore, it cannot be one of the last thirteen passwords used on this user account. If you are trying to set a password that does not meet the criteria, a red frame around the text field will appear.

Log in

1. You can establish a specific setting for time ranges in a weekly profile for users who can only access MxMC at specific times. This section is not displayed when creating an administrator because the administrator always has all rights and access to MxMC.

Click on **Edit weekly profiles** to create a weekly profile. The **Weekly Profiles** dialog opens. There are two predefined profiles available from the beginning: the **Weekend** profile (Saturday 00:00 to Sunday 24:00) and the **Working days** profile (Monday 00:00 to Friday 24:00).

- To add a profile, click on ____. Enter a description. Highlight the desired active times in the table. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, select one first and then click on ...
- You can change the description of an existing profile. Right-click on the name and overwrite it.
- Close the dialog box to finish editing the weekly profiles. You can then use the new (or modified) weekly profile in user management. To do so, click on the Weekly Profile box and select the desired profile.
 Note: 24 hours is set by default. In this example, the user always has access to MxMC.
- 3. Click on the calendar icon to easily invert the settings of the weekly profile. For example, if you have created a profile with access on the weekend and would like to activate the alarms for working days, click on the **Invert** checkbox and the profile is used in inverted fashion.

Log out

In addition, you can specify after how many minutes of inactivity this user will be automatically logged out.

User Rights

Every user has all user rights initially. Deactivate the rights that should not be available for a specific user in the **User Rights** section.

This section is not displayed when creating an administrator because the administrator always has all rights.

Access and Save the Home View

Access and Save the Home View

You can save any view of the program as "Home view". To load the view, simply click on 🦳 In addition, you can set this view as Start view that is automatically loaded when starting the program. If no Start view has been set, the program starts with the view that was visible when exiting the last time.

Instructions:

To set the current view as Home view, right-click on A. Then click on Save as Home view. This will save the current view just as you have configured it.

If you also want to use the selected Home view as Start view, right-click on and activate the **Start view** option.



Use the Navigation button to select a specific view for a group or a camera. Right-click on the Navigation button. Then click on the arrow to the right of the view and select the desired group or camera.



Searching Recordings for a Specific Point in

Time

You can use this slider in the Playback view to search for events at a specific point in time.

Instructions:

Click on [6]. The date and time will be shown above the slider. Move the slider until you reach the date and time that is closest to the point in time you want to examine. Once you release the slider, the event image jumps to the event in the recordings that is closest to the specified date and time.

Note

The farther away you move the mouse pointer from the slider, the more precisely you can adjust the slider.



You can limit the display of event images so that only signal events are displayed. These events include:

- Signal Input
- **®** User Click

Right-click on (a) and select the desired event types.





Setting the Playback Mode

In the Playback view, you can search for recordings and play them back. This is done using the buttons and the playback mode. You first set the desired mode for browsing the recordings, such as event images only or with one hour time-lapse, in the Playback mode. Next, use the playback buttons to browse and play back the images one-by-one or continuously in backward or forward direction.

Playback Mode Playback Buttons				
Playb	аск моде	Playb	DACK BUTTONS	
(1)	Complete Recordings	\bowtie	Jumps one image backward/forward.	
		\bigcirc	Plays back all recordings backward/forward.	
B	Event Record- ing	\bowtie	Jumps to the end/the start of the recorded sequence.	
		\bigcirc	Plays back until the start/the end of the recorded sequence has been reached.	
\$	Event Images	\bowtie	Shows the previous/next image every time you click on the button.	
√ 7	Pre-alarm Images			
₽\$\frac{1}{2}	Marked Images	\triangleleft	The previous/next images are shown automatically one after the other.	
C*	1 day time lapse			
<u>(60</u> :	1 hour time lapse			

Playback Mode		Playback Buttons
(10):	10 minute	
	time lapse	
(j):	1-minute	
	time lapses	







🗓 🂈 🥭 Controls of a Camera Group

You can use the group buttons to control the functions of a camera group (provided that group functions were defined in the Group functions dialog box). A group function enables you to switch on/off lights, open a door and make an announcement for a predefined camera of this group, regardless of the currently displayed camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors.

In addition, you can right-click on the group buttons to open the corresponding shortcut menu and even control cameras that are not part of the current group. Before you can do this, the cameras have to be set up accordingly, that is, they need to be connected to door openers/light contacts and have to be configured properly.



◯ Backward Playback

In **Playback mode** \$\overline{\psi}\$, you first set the desired mode for browsing and playing back the recordings. For example, you can play back the entire recording or just intervals of one hour between images. Use the 🗖 button to start and stop the playback. Starting with the currently displayed image of a full recording, the program plays all recorded sequences in backward direction. If you set the playback mode to one hour, the program will play back the images with one-hour intervals (time-lapse playback), starting from the current image.



Open Doors

If a camera is connected to a door opener and has been configured accordingly, you can open the door in the Live view by clicking on 📊. If the door opener is connected to the proper door accessories, the door icon in the status display indicates when the door has been opened and when it has been shut again.

Opening Doors of Other Cameras

Right-click on . All cameras connected to a door station are listed in the context menu, including the door status. To open a door, click on the door camera.

Viewing the Clip of the Last Opening

From the Live view, you can jump directly to the clip of the last time the door opened and play the clip without having to search for it in the Playback view.

Right-click on and then on **Last Opened**. The view switches to the Playback view.





Audio Functions of a Camera Group

If you have defined audio functions for a camera from a group in the Group functions dialog box, you can control these audio functions using these two buttons.

Creating Camera Groups

To show the camera groups, you can use the Grid view (cameras are grouped according to various criteria on a grid) and the Graphic view (realistic arrangement of the cameras on a graphical background). You are setting the grid layout for showing the cameras in the Grid view when creating camera groups. Likewise, you can select a background image (for example, ground/floor plan) on which you will be showing the cameras in Graphic view. In addition, you can assign a picture or icon to a group for easier identification.

Note: If you have created a group and have not added any cameras yet, the application will show the icon



Instructions:

- 1. Enter a group name and if desired add an image or an icon that will be used to represent the group in the group bar later on. To do so, click on the gray field and select one of the predefined icons. If you want to use one of your own images, click on **Custom**.
- 2. Add a **background image**: Move the slider to the right until you reach the position. Click on the arrow in the gray field and select the file with the background image (for example, ground or floor plan).
- 3. You can add an **information page** to a camera group in order to show special instructions for this camera group, for example. Move the slider to the right until you reach the position. Click on the arrow in the gray field and select the file you want to use.

4. Grid Tiles Bandwidth Limits: If a very large number of cameras are displayed in the Grid View, this can lead to an impairment of the performance. To avoid this, you can limit the frame rate and image size of the live images of the tiles here. This limitation has no effect on the camera displayed in the focus win-

Use ONVIF LoRes Profile: Use this checkbox to limit the frame rate for third-party cameras that provide an ONVIF S compatible interface and MOBOTIX MOVE cameras. If this checkbox is checked, the settings for the live images in the tiles that were captured in the **Bandwidth Settings** as LoRes profile for these cameras are used.



Notification

The Alarm bar and the Alarm Info bar will notify you if new alarms occurred. In addition, you can add visual and sound notifications for ringing and alarm messages (Live view > Command bar > Alarm settings > Notification). You can temporarily deactivate the alarm messaging and/or the alarm sound, for example, if you do not want to be disturbed during a meeting. Note that by deactivating messaging, you will deactivate all notifications at once. Enabling messaging again activates all notifications.

- Notification on: Signaling in case of ringing and alarm messages
- Notification off: No signaling in case of ringing and alarm messages

Exporting Recordings

Using the Playback view, you can export recorded video data from one camera, while the Grid Playback allows exporting from several cameras at once. Use the Export bar to combine several clips to one export.

Exporting from the Playback View

- 1. Drag the desired camera from the Camera bar or the Device bar.
- 2. Find the start of the relevant recording.

- 3. Specify the export range. There are two possibilities for this export:
 - Select export range using visual markers:

 Mark the start of the clip by clicking on the gray flag on the left ▶. Play back the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right. Click on Export and select the export profile. The Export dialog box appears. Select a target folder and enter a file name.
 - Manually capture export range:

 Click on **Export** and select the export profile. The dialog box used for defining the export range appears. Specify the export range. Click on **OK** and then on **Save**.

Exporting From the Grid Playback

The Grid Playback allows setting a time range on several cameras for a recording (event or continuous recording) and to select it for exporting.

- 1. Drag the desired camera group from the Group bar or the Device bar.
- 2. Find the start of the relevant recording for the camera in the focus window.

 At the same, the search is extended to the other cameras in the group, and the recordings with the closest relevance to those in the focus window recording will be displayed in the tiles.
- 3. Specify the export range. There are two possibilities for this export:

Select export range using visual markers:

- 1. Mark the start of the clip by clicking on the gray flag on the left . Play back the recording until you have reached the end of the clip you want to export. Mark the end of the clip by clicking on the gray flag on the right.
- 2. Instead of exporting all cameras of this group, you can also select one or more cameras for exporting. To do so, right-click on **Export**. A circle appears on the camera images in the top left corner. To do so, select the desired cameras by clicking on the corresponding circles.
- 3. Click on **Export** and select the export profile. The Export dialog box appears. Select a target folder and enter a file name.

Manually capture export range:

- 1. Before you determine the export range, you can limit the selection if you do not want to export all of the recordings that appear in the tiles. To do so, right-click on **Export**. A circle appears on the tiles in the top left corner. To do so, select the desired cameras by clicking on the corresponding circles.
- 2. Click on **Export** and select the export profile. The dialog box used for defining the export range appears. Specify the export range. Click on **OK** and then on **Save**.

Alarm Info Bar

Events that lead to an alarm are also shown on the Alarm Info bar. This is done only if the Alarms option has been activated in the Camera Configuration dialog box for the individual cameras and if the corresponding event types have been activated. The bar beneath the corresponding live image turns red or green (door bell) if the camera detects an event. Move the mouse over the image to show the slider 📵. Move the slider to the left. This opens Instant Playback and shows the last alarm image.



Drag the red counter ① along the bar to show the preceding alarm images; the number in the counter increases as you move the slider. Click on Playback ② to see the recording for the corresponding event

Note that the Alarm Info bar in the Live view works differently. When moving the mouse over the lower frame border of the live image, the Alarm Info bar appears. When moving the mouse to the left on the Alarm Info bar, a still image of the corresponding alarm shows and the counter near the still image increases by one.









Image Correction: PTZ and Display

Modes

To better identify objects in an image section, you can zoom the live image and move the resulting image area around (PTZ). This depends on the image settings (Panorama or Full Image, for example) of the camera images. To quickly load these image sections, several image positions are already pre-configured, which can be loaded by using the \(\mathbb{\lambda} \) slider.

The program also shows the 🗖 slider on Dual cameras. Use this slider to show the live images of either the right, the left or both image sensors.

When showing the live images of hemispheric cameras, you can set different display modes .



Zooming and Moving Image Sections

You can zoom using the slider 🛖 or the mouse wheel. Zooming with the slider takes place only on the computer. This means that only the image section of the current live image is modified.

To see other image sections, you can move the live image using the mouse.

If you want to execute the PTZ actions on the camera, you can also switch to camera PTZ. In this case, the PTZ actions are applied to the camera's live image and also influence the recordings (but only if the camera does not record the full image). To use this feature, click on the 🛖 slider and keep it pressed until it starts

flashing. You can now adjust the zoom level as needed. To store the setting, click again on the slider and keep it pressed until the slider stops flashing.

Selecting and Adjusting Image Sections

Selecting Image Sections

To quickly focus on a specific image section, you can use one of the factory default image positions that are predefined in the camera.

- Preview ♠, detail ♠, overview ♠ and point of interest♠
- Top ①, bottom ①, left ②, right

The camera will then move to the selected position. Note that the PTZ actions are executed on the camera and also influence the recordings (only if the camera does not record the full image). Move the slider to the next position or until you have found a suitable position.

Adjusting Image Sections

You can adjust the predefined image positions of the factory default. Select a position and modify it as needed. Keep the slider on this position until it flashes once. The new image section has been stored.

Choosing a Sensor

If you want to show the live images of only the right or the left image sensor, you can move the ___ slider to the right to ___ (left sensor) or further to the right to ___ (right sensor).

Display Modes and Panorama Correction

When showing the live images of hemispheric cameras or cameras with the lenses L12/B016, L23/B036, L25/B041, you can select different display modes. Note that the **OpenGL** option in the settings (Mac menu **MxManagementCenter > Preferences > General**, Windows menu **File > Settings > General**) needs to be activated for this purpose. In order to get naturally-looking images, the camera will automatically correct the distortion in these modes. This distortion correction can be refined even further when using the panorama correction. The selection of a display mode is always done locally and thus does not influence the camera settings. However, the selection is also applied to the other program views. When selecting a display mode in the live view for a specific camera, this mode is also applied if the camera shows up in the focus window of the Grid view as well as in the live images of the Graphic view. Consequently, the alarm images in the Alarm bar and in the Research view are also shown in the selected display mode.

Select the Display Mode

- **Full image:** Shows the entire (distorted) full image.
- Normal: Shows a distortion-corrected image and allows executing PTZ actions. This is the factory default for hemispheric cameras.

- Panorama: Shows the entire distortion-corrected image (corrected 180° panorama) from the left to the right border. The aspect ratio (width to height) is 8 to 3.
- **Surround:** Shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Double panorama:** This mode shows a panorama view for the Northern half of the image and a second panorama view of the Southern half of the image using an aspect ratio (width to height) of 4 to 3. This mode makes sense for a hemispheric camera that is mounted to the ceiling.
- Panorama focus: This display mode combines the panorama view (aspect ration 8 to 3) with two smaller images (each with aspect ratio 4 to 3) in one large image.

To select a mode, move the slider **()** to the right until you reach the desired position. This slider position will be stored automatically until you change it again.

Panorama Correction

The distortion-corrected images of the different display modes can be further refined. For example, if the image in Panorama mode is not centered, you may see a trapezoidal distortion. The panorama correction allows adjusting the skewed (vertical) lines of the image to produce a more naturally-looking image. To do so, move the slider to the right to and use the mouse to correct the image. To store the corrected setting, click on the slider and hold it until the slider icon briefly appears in the center of the image.



You can adjust the audio volume of the displayed camera to the current environment.

Instructions:

Move the **Volume** slider . The new setting is stored automatically for the displayed camera. To restore the default value, simply double-click on the slider.

Camera Live Images

If you want to display individual camera live images, drag them from the Camera bar or the Device bar onto the current Graphic view. You can place live images either temporarily or permanently. Temporarily means that these live images will be removed if you open a different view.

You can use the switching on/off and control functions at the bottom of the live image, similar to in the focus window of the Grid view:

- PTZ and Display Modes
- Establishing/Closing Audio Connections
- Controls
- Alarm Info Bar

Note

If the live image was corrected for distortion in the tile afterward, this is also adopted when playing an instant playback for the configured image mode.

Instruction:

Temporary placing: Drag the desired camera from the Camera bar or the Device bar onto the Graphic view. **Permanent placing:** Activate the Edit mode by clicking

Drag the desired camera from the Camera bar or the Device bar onto the Graphic view. Close the Edit mode by clicking a

Recording Date/Time

This field contains the date and time of the currently displayed image. At the same time, you can use this field to search the recordings for a specific date and time. Enter the date and time you are looking for and press the Return key to start the search. The image jumps to the event in the recordings that is closest to the specified date and time.

Note

that you can move the date box to a different location. To do so, grab the red storage card icon and move it to the desired position.



8 Temperature Display

MOBOTIX cameras have a built-in temperature sensor that measures the temperature inside the **housing**. If an ExtIO module or an MX-GPS-Box is connected to the camera, you can also show the ambient temperature measured by the module or the box. Click on \bigs\{ \bigs\} to display the temperature profile of the current camera.

Display the Current Temperatures of All Cameras

Right-click on **Temperature** §. The context menu shows all attached cameras with their current internal temperatures and, if available, with the ambient temperatures of connected modules/boxes. In addition, you can display the temperature profile of each listed camera. To do so, click on the desired camera.

Change the Temperature Unit

The default temperature unit is Celsius. To change the unit, right-click on **Temperature** 8 and then on **Set Up**.

11 Group Sequencer

If you want to display a different camera group in the focus window, drag and drop that camera group into the focus window. A grid with all cameras of the group will be displayed and each camera of the group will be shown sequentially in the grids focus window for a defined time. You can automate this camera group change with the group sequencer.

Instructions:

- 1. Click on the group sequencer icon

 to activate the group sequencer.
- 2. To change the sequencer settings right-click on:
 - **Duration:** set the duration to show each group. You can set a value between 1 sec and 60. The "Combined Sequencer" activates the group sequencer together with the camera sequencer ("Autostart" on the camera sequencer is not needed). The group sequencer waits until all cameras on a grid or graphic have been cycled before switching to the next group. When the "Combined Sequencer" is active then the camera sequencers "Stop at Event" and "Restart after Confirmation" also apply to the group sequencer.
 - Autostart: Once you switch to the Grid view, the group sequencer will start automatically.







Zoom and Change the Views of Event

Images

To better identify objects in an image section, you can zoom the event images. If you have set reference images (one overview and one detail) when adding the cameras, you can display the event image in the overview or the detail view. Use the slider to control the number of columns and thus the size of the displayed event images.

Instructions:

Move the slider to the right or left to make the event images larger/smaller, respectively. Move the slider to the right to switch from the overview to the detail view of the preview images. Move the slider

to the right to increase the number of columns to show.

Camera Bar and Camera Group Bar

The camera bar and the camera group bar at the upper border of MxManagementCenter provide the means for quickly selecting the camera groups or individual cameras. These bars also allow switching views. In addition, the icons in the camera images of the camera bar indicate the current status of the corresponding camera:

- Camera is not reachable.
- Privacy mode is active
- Limited functionality (only live image access) due to old firmware (<4.0), old camera model (M/D/V12, M/D/Q22M) or proxy issue.
- Camera password does not grant administrator rights.

Instructions:

Click on the gray frame border to show the bars. To switch between the camera bar and the camera group bar, click on the upper frame border of the activated bar. Pull up the lower frame border to close the bars.









Set Grid Layout

Auto Grid Mode

By default, the auto grid mode is used in the grid layout. In auto grid mode, MxMC always tries to distribute the available space as well as possible according to the specified grid parameters, such as the aspect ratio of the tiles (4:3, 16:9, 8:3), the size of the focus window and the number of cameras. When you change the window size, the grid layout adjusts **automatically**. The following sliders are available to adjust the grid layout:

- 8:3: Format of the camera images and the focus window (4:3, 16:9, 8:3)
- 3x: Size of the focus window (1x, 2x, ..., 8x the size of the camera images)
- 16: Maximum number of cameras

Move the sliders to the desired settings. To close the edit mode, click on

Manual Mode

You can use this mode to position every grid tile of a group (including focus windows) applying the configured primary grid (4:3, 16:9, 8:3) as the basis and change their sizes. You can scale either along the horizontal or vertical axis using multiples of whole numbers for the primary grid tiles. In contrast to the automatic grid mode used previously, this feature enables you to use different image formats within one group. For example, if the primary grid has an aspect ratio of 4:3, the formats 4:3, 8:3, 16:3, 4:6, etc can be used. Likewise, tiles with an aspect ratio of 16:9, 32:9, 16:18, etc. can be created for a primary grid with an aspect ratio of 16:9.

MxMC automatically reduces the absolute size of all tiles and inserts columns and rows to ensure that the tiles will be displayed in the desired area if the available space is not sufficient when a tile is moved or enlarged (because there is already one in the new position).

Tiles that are automatically arranged in this manner will be fixed for each window size, which means that the tile layout will not be changed when the program window size changes, as opposed to the automatic grid layout.

To switch from auto grid mode to manual mode, move the slider to the right until you reach the position. The following sliders are available in manual mode:

- 8:3: Format of the camera images and the focus window (4:3, 16:9, 8:3)
- 16: Maximum number of cameras

Move the sliders to the desired settings. To move a tile to a different position, move the mouse pointer over

the tile. Click on and drag the tile onto the desired position. For better orientation, a blue frame indicates the target position.

To set the size of a tile based on the selected format, move the mouse pointer over the border of the tile until a double arrow is shown. Drag the tile to the desired size. To close the edit mode, click on ...



If you have defined hyperlinks, you can execute them by clicking on . When defining hyperlinks, you can select an individual button icon for the hyperlink (there are several predefined icons to choose from) or set one button from which to run all hyperlinks.

Instructions:

To define a hyperlink, right-click on and then on +.

In case you did not assign an icon for the individual hyperlinks, they will be combined under one button.

To execute such a hyperlink, click on and then on the name of the desired hyperlink.





User Management

If you want to set up users with different rights for MxManagementCenter, you need to add these users first. For this purpose, the application differentiates between "administrator" and "user" roles. You can assign rights for users depending on the specific functions they need, whereas the administrator possesses all rights.

Creating Users or Administrators

You need administrator rights to add a new user or establish an additional administrator. Open the user man-



User Type and User Name

- 1. Enter the corresponding user name.
- 2. Select the desired user type: user or administrator. The user type is set to **User** by default. The sections **Weekly profiles** and **User rights** are available for users, in contrast to administrators. All other settings apply to both user types and will be used in the fol-
- lowing description; however, reference will only be made to **User**. 3. Use the **Active** option to enable the new user immediately or later on.

Password

- 1. Enter a password and confirm it.
- 2. Use the **Expires** option if you want to require the user to change the password at regular intervals.
- 3. If the user is to change the original password upon the next log in, select the Force change on next log **in** option.

Note: Activating this option automatically gives the user the "Change Password" right, even if it had been disabled before.

4. The **Force Complex Password** option ensures that users can only set secure passwords. A secure password has at least eight characters, consists of lowercase and uppercase letters, including at least one special character, one digit and one character. Furthermore, it cannot be one of the last thir-

teen passwords used on this user account. If you are trying to set a password that does not meet the criteria, a red frame around the text field will appear.

Log in

- 1. You can establish a specific setting for time ranges in a weekly profile for users who can only access MxMC at specific times. This section is not displayed when creating an administrator because the administrator always has all rights and access to MxMC.
 - Click on **Edit weekly profiles** to create a weekly profile. The **Weekly Profiles** dialog opens. There are two predefined profiles available from the beginning: the **Weekend** profile (Saturday 00:00 to Sunday 24:00) and the **Working days** profile (Monday 00:00 to Friday 24:00).
 - To add a profile, click on ____. Enter a description. Highlight the desired active times in the table. You can resize an active time block by clicking on the time block and then moving the borders accordingly It is also possible to move a block. Click on the block to select it, then drag the block to the new position. To delete a time block, select one first and then click on ...
 - You can change the description of an existing profile. Right-click on the name and overwrite it.
- 2. Close the dialog box to finish editing the weekly profiles. You can then use the new (or modified) weekly profile in user management. To do so, click on the **Weekly Profile** box and select the desired profile. **Note: 24 hours** is set by default. In this example, the user always has access to MxMC.
- 3. Click on the calendar icon to easily invert the settings of the weekly profile. For example, if you have created a profile with access on the weekend and would like to activate the alarms for working days, click on the **Invert** checkbox and the profile is used in inverted fashion.

Log out

In addition, you can specify after how many minutes of inactivity this user will be automatically logged out. **User Rights**

Every user has all user rights initially. Deactivate the rights that should not be available for a specific user in the **User Rights** section.

This section is not displayed when creating an administrator because the administrator always has all rights.

Managing Users

Changing the Rights

Click on the user whose settings you want to edit. Then configure the rights by setting the appropriate switches in the **User Rights** section.

Deactivating Users

If – for security reasons – you want to prevent a particular user from logging in, you can deactivate that user. This prevents the user from logging in, but all settings remain in the system. To do this, select the user and deactivate the **Active** option.

Deleting Users

Click on and then on enext to the user you want to remove.

Temporarily Assigning Supervisor Passwords to Functions

Certain situations may require users to execute functions for which they usually do not have the rights. These functions can be made available temporarily using a supervisor password.

- 1. Click on **Supervisor** to protect functions with a supervisor password.
- 2. In addition, you can specify after how many minutes of inactivity this user will be logged out automatically.

Note: While a recording is being played back in Playback view or in Grid Playback, MxMC does not automatically terminate the supervisor mode after the specified period of time.

3. Select the functions that can be accessed after entering the password.



Setting Group Functions

Group functions in the Grid and the Graphic views enable you to switch on/off a light, open a door or make an announcement for one camera group, regardless of the selected camera. You can also assign the functions for switching on/off lights and opening doors to several cameras of this group, enabling you to switch on/off several lights or open several doors by clicking on the corresponding group button.



Set Reference Time

Use this option if you want to see whether and what several cameras have recorded at a specific point in time.

Instructions:

- 1. Right-click on 🖟 and enter the date and time to search for.
- 2. Drag the cameras from the Camera bar or the Device bar one by one.
- 3. The application shows the event images of each camera that are closest to the specified point in time.

Entering MxThinClient Settings

Name

The name for the MxThinClient that is shown in the Device bar. You can freely select the name and it does not have to be unique.

Serial Number

The serial number is the factory-defined IP address that is printed on the housing of the MxThinClient. Remember that you need to enter the number correctly because it represents the address at which the MxThinClient is accessed in the MxMessageSystem.

URL (optional setting)

The IP address or DNS domain name at which the MxThinClient can be accessed.

User Name and Password (optional setting)

The access data on the MxThinClient that you entered when installing the MxThinClient.

Display Resolution

Here you can select the resolution that the camera's live image uses when data is sent to the display unit. If the display unit does not support the desired format, the MxThinClient displays the message **Resolution not supported** on the monitor.

Camera Display Time

You can select how long the armed camera's live image is displayed before the MxThinClient continues with displaying the normal sequence of configured image sources.

If you select **Unlimited** for the display length, the camera's live image is displayed until the MxThinClient receives a new command, such as when an event is triggered when it receives MxMessages from other cameras/devices in the network.

If you want to stop the display of the camera's live image before the set display length elapses, click on the licon. It appears when you move the mouse pointer over the name of the MxThinClient in the Device bar.

Searching Transaction Data

In the Smart Data View you can search and filter Smart Data (transaction data) of one or more MOBOTIX IOT Cameras.

Defining Search Queries

You can define and store several search queries. Enter a name for each search. The search query will be automatically saved every time the search criteria are changed. This also happens when individual search parameters and terms are changed.

- 1. By default there is one search query already. Click on the tab and enter the desired name.
- 2. Select the desired cash points. You can select more than one or even all cash points for a search query.
- 3. Specify the period of time for the search. You can also enter a period of time that allows you to enter any start and end time stamp, in addition to a series of preset time windows (including "today").

- 4. You define the search criteria to limit the scope of the search once you have selected the cash points and defined the period of time for the search. Click on to do so. A new line will be inserted.
 - The individual criteria can be linked using **AND** or **OR**. The logical search operators can only be applied to all search criteria at the same time. Select to link the search criteria using **AND** and to link them using **OR**.
 - **Please note** that the search criteria are only applied to individual transaction rows, e.g., a search for a total > 100 and < 150. For the time being, it is not possible to apply the search to all transaction rows of a receipt, e. g., the search for a specific item linked to the total amount > 100.
- 5. Click on 📺 to delete a search criterion.
- 6. Click on to define further search queries, in addition to the most recent search query. Enter a name and repeat steps 1–5.

Deleting Search Queries

Click on \times to the left of the name for the search query to delete a search query.

Reloading Searches

A new search is performed on the Smart Data on the camera with the filter when the search query is reloaded. The search results are displayed again. Click on to reload a search query.

Displaying Search Results

The search results are displayed with preview images in a list with a detailed display of the cash point data or in tiles, depending on the selected display format from the Command bar (List view).

Previous Image

You first set the desired mode for browsing the recordings in the **Playback mode**, for example, using one hour or all highlighted events. Depending on this setting, this button will jump to the **previous** image in the recording (starting from the current image).

Camera Date and Camera Time

If the date and time display is flashing, the system time of the computer deviates from the system time of the camera by more than one minute. If this happens, make sure that the correct time is set on the computer. In

addition, you need to make sure that the camera is attached to a time server and that it gets valid time information.



Switching Lights

If a camera is connected to a light switch and has been configured accordingly, you can click on switch the lights on or off in the Live view. The light icon in the status display is blue as long as the lights are on.

Switching the Lights of Other Cameras

Right-click on . All cameras connected to a light switch are listed in the context menu. To switch individual lights on or off, activate/deactivate the **Lights** function next to the camera name.

To switch all lights on, click on **All on**. To switch all lights off, click on **All off**.



Click on to undo the last change.



Applying Modified Values

You can make changes by pressing Enter or selecting the new value in the Configuration view. The changes made here are not automatically adopted because it could potentially cause problems with the network settings

When a value is changed and the background of the white checkmark is red, it indicates that the change has not been implemented yet. Click to make this change.

General Settings

The general topics on operating the cameras are found in the general settings.

Arming

The main arming feature needs to be activated in order to process events, execute actions and notifications and record images and audio data.

Parameter	Explanation	
Activated	The camera is always armed.	
Off	The camera is not armed: no image storage, actions or messages.	
CS	Arming is controlled via a custom signal that needs to be previously configured on the camera. The camera can use a signal input or connected MX-GPS-Box, for example, as the main	
	switch for arming by using the custom signal.	
From master	The camera is armed only when the master camera is armed.	
See also:	Recording/ArmingMxActivitySensor	

Frequency of Power Supply

If the camera's exposure control is not matched to the frequency of the power supply, sources of artificial lighting may lead to image interference. This parameter sets the camera to the power supply frequency of the respective country to prevent interference.

Parameter	Explanation
No artificial light	If the camera is used in daylight conditions (rather than with artificial lighting), you can also use the No artificial light setting.
50 Hz	The factory default setting for Europe is 50 Hz.
60 Hz	Set the power supply frequency to 60 Hz for Canada, the U.S. and Japan.

Audio Source

Select the desired audio source. It is also possible to integrate an external audio source, in addition to using the camera's microphone. The audio source is used for two-way communication and recording audio data, for example.

Image Settings

Resolution

You can select a predefined resolution or determine a user-defined size to determine the image size of the live image. If you select the **User-defined size** option, the image size that was defined for this option in the camera web interface is used. Dual images (right and left image sensor) automatically require twice the width.

JPEG Quality

The JPEG quality influences both the image quality as well as the file size of the JPEG and MxPEG files generated by the camera.

Using a compression of 60% (default) will usually deliver good-quality images that are suitable for most purposes. If the value is lower than 20%, you can see pixelation within the image. For values higher than 70%, differences to the uncompressed original image are hardly visible. The file size, however, may increase to more than 100 kB (for a 640x480 pixel image).

Camera Selection

On Dual cameras, select the image sensor to use when displaying the images: right image sensor, left image sensor, both image sensors or automatic day/night switching.

When configuring the image settings for both sensors, first select the sensor you want to configure using the left or right checkbox in the live image preview window and enter the settings you want.

Display Mode

There are various display modes available depending on the camera model.

All Cameras Except Hemispheric Models

- Full image: The entire live image from the camera is displayed.
- **Lens correction:** This option displays a portion of the live camera image (with lens correction). This option is only available for L22 lenses, provided that the camera configuration is adjusted accordingly.
- **Picture-in-Picture:** This option displays a small image from one camera sensor inset in the large image of the other. This setting is available on MOBOTIX Dual models only.
- **Picture in Zoom:** This option displays a small version of the entire live camera image in the lower right corner of the large live camera image. This way, the entire image is visible even when the live image is zoomed.
- **Event in Picture:** This option displays a small version of the latest event image in the lower right corner of the large live camera image.

Hemispheric Models

- **Full image:** The entire (distorted) full image of the image sensor is displayed.
- **Normal:** A corrected image is displayed. This image can be panned and tilted. This is the factory default for hemispheric cameras.
- **Surround:** This option shows four image sections (one for each cardinal direction: N, E, S, W) in one joint view. Note that you can use PTZ actions to modify all four views independently from one another.
- **Panorama:** This option shows the distortion-corrected image of an entire room (corrected 180° panorama view) from the left to the right wall. The aspect ratio (width to height) is 8:3.
- Panorama focus: This display mode combines the panorama view (aspect ratio 8:3) with two smaller images (each with aspect ratio 4:3) in one large image.
- **Double panorama:** This mode shows a panorama view for the North half of the image and a second panorama view of the South half of the image using an aspect ratio (width to height) of 4:3. This view only makes sense for the ceiling-mounted MOBOTIX Hemispheric model. Both partial views (North and South) can be changed independently of each other using PTZ commands.

Installation

You can set the mounting position of a MOBOTIX Hemispheric camera: wall, ceiling or floor. The mounting positions are set separately for the left and right lenses for cameras with two active image sensors.

Exposure Window

Exposure windows are used to ensure the proper exposure/brightness for the live camera image.

Custom

Creating and editing custom exposure windows. Select the **Custom** option and click in the live image at the bottom. You can execute the following actions with the icons that appear:

- Create exposure windows: Draw a window using the mouse pointer.
- **Move exposure windows:** Left-click with the mouse pointer on the exposure window and drag it to the desired position.
- Modify exposure windows: Place the mouse pointer on one of the white squares until you see the \$\dp\$ icon. Left-click with the mouse and drag the window making it larger or smaller.
- **Delete exposure windows:** Click **⊗**.

Visible Image Area

This setting enables you to use the current visible image section as the exposure window.

Predefined

You can use a number of predefined exposure windows: When you select the corresponding window, it will be displayed in the live image for review. A predefined exposure window is always applied to the full-image area, that is, the entire image of the sensor.

- Full image: Entire area of the image.
- Quarter: An exposure window at the image center that covers a quarter of the viewable image area.
- Center: One exposure window at the image center.
- **Spot:** One small exposure window at the image center.
- **Top:** One horizontal exposure window at the top of the image.
- **Center:** One horizontal exposure window at the image center.
- **Bottom:** One horizontal exposure window at the bottom of the image.
- **Right:** One vertical exposure window at the right border of the image.
- **Vertical:** One vertical exposure window at the image center.
- **Left:** One vertical exposure window at the left border of the image.
- **Right AND left:** Two vertical exposure windows at the left and right borders of the image.

Exposure Program

These parameters influence the balance between an exposure time that is as short as possible and hardware amplification that is as low as possible. The objective is to reach a fair compromise between clear images of moving objects (short exposure time, high amplification) and as little image noise as possible (long exposure time, low amplification).

- 0: Default program.
- **Negative:** The programs will reduce exposure times to decrease motion blurring; could increase image noise
- **Positive:** The programs will increase exposure times to reduce image noise; exposure in very bright environments is not impacted.

Maximum Exposure Time

This parameter determines the longest exposure time used by the camera. This setting enables you to either avoid motion blurring as lighting conditions decrease, or even specifically allow it. Select shorter maximum exposure times if you do not want motion blurring. You can use a longer maximum exposure time (max. of 1/1 = 1 second, for example) if you want the camera to produce images with good exposure (with motion blurring), even in low light situations.

Time

Time

The date and time can be manually set, adopted from the computer, or continuously synchronized through a time server. If you use a time server, the clock can be synchronized using a time server over the Internet, a time server service in the local network or another MOBOTIX camera. In this case, you need to access the camera web interface (Admin > Camera Administration > Time and Date > Use Camera as Time Server) in the Admin menu and activate the time server.

Automatically Synchronize Using a Time Server

Two protocols are available for synchronizing the camera using a time server: NTP and Time Protocol.

Parameter	Explanation	
Time	■ NTP: With this protocol, the camera continuously synchronizes with one or more NTP	
Server	time servers. If the NTP protocol has been selected, you can enter up to five time servers	
and	under Time server address . Theses servers must support the protocol specified in RFC	
Time	1305. A green dot to the right of the time server address indicates that the time server is	
Server	accessible and offers an NTP service. It can take a moment for the camera to connect to	
Address	the time server and the dot to turn green.	
	■ Time Protocol: With this protocol, the camera synchronizes every six hours (and when it	
	is rebooted). If Time Protocol (RFC 868) is selected, enter the Time server address in	
	this box. The server must support the protocol specified in RFC 868.	
Current	Display time of the current camera	
Time		
Time Zone	Select the correct time zone for the camera location.	

Do Not Adjust Automatically

Deactivate automatic synchronization if the date and time are set automatically or if they are adopted from the computer.

Parameter	Explanation
Current Time	Display time of the current camera
	If the camera's time deviates from the computer's time, click on $\textbf{Use}~\textbf{PC}~\textbf{time}$ to adopt the
	computer's time.
Set time manu-	Capture the desired data to manually set the date and time and click on Set time to con-
ally	firm the entry.
Time Zone Select the correct time zone for the camera location.	



Expert Settings

Various sections of the configuration contain additional settings for handling special aspects of camera behavior. For everyday use, however, these settings are not really needed in MxMC.

Note:

that these settings have been combined as expert settings in the different sections. Click on to open the expert settings.



Save Configurations

Changes to the configuration are only temporary. To use the current settings after the next reboot of the camera, you have to permanently store the configuration. To do so, click on **Store configuration** The program opens a system prompt. In the prompt, click on **Save**.

If you have modified the configuration temporarily and do not intend to keep the changes, you can retrieve the last configuration that has been stored permanently. To do so, click on **Save configuration**. The program opens a system prompt. In the prompt, click on **Discard**.



Resetting to Factory Settings

Click to reset all parameters for the current camera to the factory settings.

Configuration Bar

You can enter parameters for a camera in the Configuration view. If you want, you can display the parameters available for the other cameras in the group by viewing them in the **Configuration Bar**.

You can also change the settings of one or more cameras in the group, without having to switch to a different camera or camera group.

Displaying the Settings of Other Cameras in the Group

Click on the corresponding name of the parameter in the Configuration view to displaying the settings of other cameras in the group. It turns yellow and the Configuration bar shows all values associated with this parameter for this group. The cameras for which this value is set are assigned to the individual values.

Changing Parameters

You can also change the parameters of one or more cameras in the Configuration bar, without having to switch to a different camera in the group. To do so, highlight the desired camera and drag it onto the parameter value you want to set. The destination area turns yellow.

If you want to change the value that is used by more than one camera, select the desired value in the parameter selection box.

MxActivitySensor

The MxActivitySensor is a camera-internal video motion detector that can identify direction of motion detection and object size while blocking out any undesired interference (such as trees swaying in the wind) when detecting motion. There is an MxActivitySensor profile that is preset in the factory settings and contains all settings necessary to operate the MxActivitySensor.

You can activate and deactivate this profile here, change the name of the profile, adjust the event dead time, change the detection range and define new areas.

Active

The MxActivitySensor profile is also activated when the Arming feature is enabled in the general settings.

Profile Name

You can change the preset profile name.

Event Dead Time

The event dead time defines a period of time (0–3600 sec.) after an event during which no new events from the same profile are detected. By defining an event dead time you can avoid, for example, that a complex action (person walks through the active image area) triggers multiple events. You can adjust the preset event dead time (5 sec.).

Edit Detection Area

Proceed as follows to adjust the default detection area or to define additional image areas: Click in the green detection area. You can execute the following actions with the icons that appear:

Action	Explanation				
	Place the mouse pointer on one of the white squares until you see the icon. Then left-				
Detection Area	click with the mouse and resize the detection area making larger or smaller.				
Move Detection Area	Place the mouse pointer on the detection area. Then left-click with the mouse to drag the detection area to the desired position.				
Rotate Detection Area	Click on and right-click with the mouse to rotate the detection area clockwise or counterclockwise.				
Change Shape of Detection Area	Switch to polygon mode by clicking on . You will see white corner points on the corners. Drag the corner points to the desired position. You can insert new corner points by right-clicking on the white line or in the detection area. Right-click on a dot to delete a corner point. Then click on .				
Deleting a Detection Window	Click on 😮.				
Creating Addi- tional Detec- tion Window	Draw a new window with the mouse.				
Within the Detection Area	You can define an area within the detection area that is blocked from the analysis. Drag a window corresponding to the size and position to the area that should be blocked from the analysis. Click in the window and keep the mouse button depressed until two icons appear. Click on to determine the exclusion window. The window turns red. Drag another window and position it so that it covers the desired detection area.				

Network

Your network interface settings determine how the camera can communicate with the "outside" world and how the camera can be accessed from outside of the local network.

Internal Host Name

The host name is the unique camera name in the network under which it is accessible.

BOOTP/DHCP

BOOTP and DHCP are protocols with which IP addresses can be managed in a network and automatically assigned. The camera can use them to automatically obtain its network configuration.

Parameter	Explanation					
Off	The camera's network configuration is manually established. Enter the appropriate inform in the IP address and subnet mask boxes and, if necessary, change the standard route or way and the DNS server.					
	▶ IP Address					
	You can access the camera in the network via its IP address. Ask your network administrator which IP address is available.					
	▶ Subnet Mask					
	A matching subnet mask needs to be entered for the IP address in order for computers to be able to communicate in a network. Again, it is your network administrator who will tell you which subnet mask to use.					
	▶ Default Gateway					
	The gateway acts a relay between individual networks and it coordinates the data traffic between these networks. Enter the IP address of the gateway that should be used.					
	DNS Server					
	A Domain Name Service (DNS) resolves computer names to IP addresses. If you have a DNS on your network, you can specify up to three IP addresses of DNS servers. This is only necessary if you want to address computers using their name instead of their IP address for other configurations (FTP, email).					
On client mode	Use BOOTP/DHCP to set the IP address and network configuration automatically. The gateways and the default route are automatically determined via BOOTP/DHCP and configured.					
On server	This camera provides DHCP service to clients on the local network. The IP address of the camera will be 192.168.0.19 with subnet mask 255.255.255.0 by default.					

mode

Default Gateway

Enter the IP address of the gateway that should be used.

DNS Server

A Domain Name Service (DNS) resolves computer names to IP addresses. If you have a DNS on your network, you can specify up to three IP addresses of DNS servers. This is only necessary if you want to address computers using their name instead of their IP address for other configurations (FTP, email).

Additional IP Address

The camera can manage two different network configurations. If you enable this checkbox, the factory default IP address and the subnet mask will also be used, ensuring that the camera remains accessible at all times.

Recording

You can make the most important settings for recordings in this dialog box.

Arming

The arming feature for event control handles camera recording. However, the main arming of the camera needs to be activated in order to make the recordings in the first place.

Parameter	Explanation
Off	The recording feature is deactivated.
	No further parameters will be displayed.
Activated	The recording features of the camera are activated (default setting).
CS	The recording is activated by a custom signal (CS).
From master	The recording feature of the camera will only be enabled if recording has also been activated
	on the master camera.

Recording Mode

You can select the type of recording for events and story images. The availability of the parameters will depend on the recording mode you select.

Recording Type	Parameter					
Snap Shot Recording						
	▶ Snap Shot Interval					
	This option determines the amount of time between the individual pre-alarm and post-alarm images. You can set values from zero to ten minutes (max.).					
	▶ Pre-alarm Images					
	Number of the image that are recorded before the event.					
	Post-alarm Images					
	Number of the image that are recorded after the event.					
	Recording Time Unlimited					
	The time to keep is set to unlimited by default. You can select a maximum time to keep , expressed in hours and days, if you deactivate this option. The maximum value for time to keep indicates how long images and video clips need to be stored.					
Event Recording	This option stores clip files for every event using the MxPEG codec with variable frame rate and optional audio data.					
	Record Audio Data					
	Audio data can be recorded if it is available in the camera. Set this option to active to activate the microphone.					
	▶ Event Frame Rate					
	Recording speed if an event is detected, expressed in frames (fps) or seconds (s).					
	Recording Time Before Event					
	Time (in seconds) to include in recorded stream before an event has occurred.					

Recording Time After Event

Time (in seconds or minutes) to include in recorded stream after an event has occurred.

Recording Time Unlimited

The time to keep is set to **unlimited** by default. You can select a **maximum time to keep**, expressed in hours and days, if you deactivate this option.

The maximum value for time to keep indicates how long images and video clips need to be stored.

Continuous Recording

Continuous Continually saves video and (optionally) audio data as MxPEG clips.

Record Audio Data

Similar to Event Recording, audio data from the camera be recorded with the same quality, regardless of the frame rate. Set this option to **active** to activate the microphone.

Frame Rate

Recording speed for continuous recording.

Recording Time Unlimited

The time to keep is set to **unlimited** by default. You can select a **maximum time to keep**, expressed in hours and days, if you deactivate this option.

The maximum value for time to keep indicates how long images and video clips need to be stored.

Redo the Last Change

Click on a to redo the last change.

License Management

You can view a list of all licenses that have been activated on this computer in License management.

Name	Explanation
Product	Name of the licensed function.
Expiration	The license is either valid indefinitely or it expires on a specific date, which is listed in this column.
Quantity	Number of licenses that were purchased for a product.
Device ID	Unique identifier that is determined by MxMC for the used device. Note the device ID and keep it accessible if you should run into any problems during licensing.

Activate Licenses

- 1. Click on Activate licenses to activate licenses. The dialog box used for activating licenses appears.
- 2. Enter a valid activation ID and establish the number of licenses that will be installed on this computer.
- 3. Click on + if you want to license an additional product. Enter the corresponding activation ID in the new line and enter the number of desired licenses.
- 4. Click on 🗑 to delete a line.
- 5. When you are finished entering all activation IDs, click on **Activate**.
 - Activation successful

If activation was successful, you can return to License Management, p. 366 or relaunch MxMC for the changes to be applied.

Activation failed (no Internet connection)

MxMC connects to the license server for activation. It needs to establish an Internet connection. An error message appears if there is no Internet connection. It will then save an offline request file (*.lic). A partner/installation technician can generate a capability response file (*.bin file) using this file. If you have received on, open the **Activate licenses** window (menu **Window > Licenses > Activate licenses**) and click on **Load capability response file**.

If the capability response file was successfully loaded, you can return to License Management, p. 366 or relaunch MxMC for the changes to be applied.

Update

When launching the program, it does not automatically compare the licenses on the computer with the license server. For this reason, you need to click on **Update** to reload the licenses from the server.

Note: You need administrator rights to activate or update licenses.



Edit Network Data

The camera list allows editing the network data not only of one camera (by double-clicking on the URL), but also of several cameras at once. To do so, select the desired cameras and click on 🚓. It would make sense to have the DHCP server also assign the camera's IP addresses if your computer gets its IP address automatically from a DHCP server (your DSL router, for example). To do so, activate the Automatic IP address option. If you have assigned a fixed IP address to your computer, you will certainly prefer to assign fixed IP addresses to the cameras as well. To do so, enter the first camera's IP address and the subnet mask. The IP addresses are incremented automatically for all selected cameras.



Add Cameras

Use this wizard to quickly and easily integrate your cameras and door stations into MxManagementCenter. To do so, click on and complete the individual steps.



Rename a Camera

The camera list allows renaming not only one camera (by double-clicking on the camera name), but also several cameras at once. To do so, select the desired cameras and click on 🥖. Enter a new camera name, such as "Parking lot." All selected cameras are renamed to "Parking Lot_001", "Parking Lot_002", etc.



Change the Camera Access Data

The camera list allows editing the access data not only of one camera (by double-clicking on the user name and password), but also of several cameras at once. To do so, select the desired cameras and click on \cite{Q} . Enter the new user name and password. All selected cameras get the new access data.



Click on > to show the next page.



Importing *.mxu files

You can conveniently add large numbers of cameras, camera groups, devices and recordings/clips using a list that you manually generate in MxMC as an *.mxu file. You need to adhere to specific rules for the format when creating the list in order to correctly export the contents of the *.mxu file.

Important: When you import *.mxu files, it does not replace the project import, in which program settings, such as settings for the cameras and camera groups with assigned layouts, are imported.

Format for Simple Imports

An *.mxu file needs to use the following format for a simple import of cameras:

- Unformatted UTF-8 text
- One or more camera lines with the following structure: Name<TAB>IP<TAB>Username<TAB>Password<CR LF/LF>
- Elements in a camera line need to use **TAB**s as separators.
- Line breaks are either **CR LF** (Windows) or **LF** (UNIX).
- Comment lines are preceded by a //.
- Camera names need to be unique and cameras using the same name will not be added more than once.

Example:	Main Entrance	10.6.37.25	admin	meinsm
	Side Entrance	10.6.15.206	admin	meinsm
	Entrance Gate	10.6.23.132	admin	meinsm

Format for Advanced Imports

The file needs to adhere to additional rules for the format when importing cameras, groups, clips and settings for graphics and grid view.

Importing MXU Files

- 1. Click on **Import MXU** to import cameras and camera groups in the Welcome wizard. You can save the existing project, if necessary.
- 2. Open the *.mxu file.
- 3. Decide whether the cameras and groups from the *.mxu file should replace the entire configuration or they should be only added.

Creating MXU Files for Imports

You can conveniently add large numbers of cameras, camera groups, devices and recordings/clips using a list that you manually generate in MxMC as an *.mxu file. There are several format specifications that need to be followed when generating an *.mxu file.

Format for Simple Imports

An *.mxu file needs to use the following format for a simple import of cameras:

- Unformatted UTF-8 text
- One or more camera lines with the following structure:
 Name<TAB>IP<TAB>Username<TAB>Password<CR LF/LF>
- Elements in a camera line need to use **TAB**s as separators.
- Line breaks are either **CR LF** (Windows) or **LF** (UNIX).
- Comment lines are preceded by a //.
- Camera names need to be unique and cameras using the same name will not be added more than once.

Example:	Main Entrance	10.6.37.25	admin	meinsm
	Side Entrance	10.6.15.206	admin	meinsm
	Entrance Gate	10.6.23.132	admin	meinsm

Format for Advanced Imports

Expanded Format

The file needs to use the following format for the advanced import of cameras, groups, clips and settings for graphics and grid view:

- The first line must contain the string #EXTMXU
- Any additional commands must start with #EXT. Parameters use ":" as separators.

Example:#EXTGROUP:Doorstations

Commands for advanced imports

#EXTMXU Markers for beginning of file

#EXTGROUP:name:f:r:icon:map:info Group "name" is created and all further cameras will be added to this

group.

f: Large focus window (0=0x, 1=1x, 2=2x ...)

r: Tile ratio (0=4:3, 1=HD, 2=8:3)

icon: If numeric, index of the internal group icons; otherwise, file name

corresponding to the *.mxu file.

map: File name of the background image

info: File name of the information page

#EXTGROUP: All further cameras will not be added to a group if no name is specified

(unless "All cameras").

#EXTCLIP:clipMXG Camera demo clip is added. Clips need to be stored in the same dir-

ectory as the *.mxu file.

#EXTMXPEG:name<TAB>clipMXG MxPEG clip with "name" is added. clipMXG is the absolute path of the

clip file to be imported.

#EXTCURRENTCAMERA:name Select camera.

#EXTCURRENTGROUP:name Select group.

#EXTSUBGROUPS:name The following groups (each with the name in a line) are added to the

group "name" as a subgroup.

#EXTMXFSS:name<TAB>folder_

MxFileServer recording with "name" is added. folder_path is the abso-

path lute path of the recording.

#EXTMXFFS:name<TAB>folder_path MxFFS recording with "name" is added. folder_path is the absolute

path of the recording.

#EXTTHINCLIENT:name<TAB> MxThinClient is added. The parameters use TAB as separators.

serNo<TAB>url<TAB>username

<TAB>password<TAB>duration

<TAB>resolution

#EXTINFO:Comment Comment line.

#EXTEND End of file, all further lines are ignored.

Example: #EXTMXU

#EXTGROUP:Doorstations:2:2:2

Main Entrance 10.6.37.25 admin meinsm Side Entrance 10.6.15.206 admin meinsm

#EXTGROUP: Indoor: 2:2:3

10.3.31.251 admin Building East meinsm Building West 10.7.25.186 admin meinsm Staircase 10.6.115.57 admin meinsm Canteen 10.12.32.65 admin meinsm

#EXTGROUP:Outdoor:2:2:4

Parking Visitors 10.5.46.39 admin meinsm Parking Employees 10.10.231.107 admin meinsm

#EXTGROUP:Dual Cams:2:2:10

Checkout1 10.10.106.26 admin meinsm Checkout2 10.10.152.225 admin meinsm Checkout3 10.13.242.195 admin meinsm

#EXTGROUP:Faststreams:2:0:11

Ground Floor 10.2.2.169 admin meinsm First Floor 10.2.104.130 admin meinsm Second Floor 10.3.11.51 admin meinsm Elevator 10.3.209.198 admin meinsm

#EXTGROUP:Clips:2:2:groupIcon.png:groupMap.jpg

#EXTCLIP:FiremanMXG
#EXTCLIP:PoleMXG

#EXTCURRENTCAMERA:Main Entrance
#EXTCURRENTGROUP:Doorstations



Import MxControlCenter

If you have already used MxControlCenter, you can import the existing configurations from MxControlCenter into MxManagementCenter. This speeds up things because you will not have to add the cameras or reconfigure the program settings.



Import MxEasy

If you have already used MxEasy and you want to use the same cameras and the same settings, you can import the existing configurations from MxEasy into MxManagementCenter. This speed up things because you will not have to add the cameras or reconfigure the program settings.



List View

The cameras found on the local network using Bonjour can be displayed either in a list or as tiles. Click on to display the camera in a list.



Open and Integrate an Existing Project

MxManagementCenter allows saving the current cameras and camera groups with all settings as a "project" at any time. If a project had been stored by a different installation of MxManagementCenter, you can integrate this project into your own MxManagementCenter installation. Click on rate to do so.



Previous Page

Click on < to show the previous page.



Search Cameras

The Welcome wizard automatically starts searching for MOBOTIX cameras when it is launched. Click on to stop the camera search. All found cameras are displayed either in a list or as tiles. The counter near the button shows the number of cameras that have been found, but not yet integrated into the system.

Note: If you are using encryption to access the cameras under Windows, it can happen that no cameras are found. In this case you should change the search mode by right-clicking on and selecting the SSL option.

Search Filters

You can narrow down the list of displayed cameras by entering a filter in this field. Possible filters in this field are the camera name, IP address and camera model.



Log in User

If several users have been configured on this installation, the log in dialog opens after starting the program. Click on your user name and enter the password.



Removing All Cameras and Camera Groups

Click on + to remove all cameras and camera groups from MxManagementCenter.



Update Software

If a camera uses an older software, the program will indicate this in the camera list. To update the software on all devices, click on .

III Tile View

The cameras found on the local network using Bonjour can be displayed either as tiles or as a list. Click on to display the camera as tiles.

Activate Licenses

- 1. Enter a valid activation ID and establish the number of licenses that will be installed on this computer.
- 2. Click on + if you want to license an additional product. Enter the corresponding activation ID in the new line and enter the number of desired licenses.
- 3. Click on to delete a line.
- 4. When you are finished entering all activation IDs, click on **Activate**.
 - Activation successful
 If activation was successful, you can return to License Management or relaunch MxMC for the changes
 - to be applied.
 - Activation failed (no Internet connection)

MxMC connects to the license server for activation. It needs to establish an Internet connection. An error message appears if there is no Internet connection. It will then save an offline request file (*.lic). A partner/installation technician can generate a capability response file (*.bin file) using this file. If you have received on, open the **Activate licenses** window (menu **Window > Licenses > Activate licenses**) and click on **Load capability response file**.

If the capability response file was successfully loaded, you can return to License Management or relaunch MxMC for the changes to be applied.