



Guideline

FF Group License Plate Recognition App - Region ME

© 2024 MOBOTIX AG



Table of Contents

Table of Contents	2
Before You Start	5
Support	6
MOBOTIX Support	6
MOBOTIX eCampus	6
MOBOTIX Community	6

Safety Notes	6
Legal Notes	7
About FF Group License Plate Recognition App - Region ME	9
Smart Data Interface to MxManagementCenter	9
Technical Specifications	10
Licensing Certified Apps	12
License Activation of Certified Apps in MxManagementCenter	12
Managing Licenses in MxManagementCenter	17
Camera, image and scene requirements	19
Recommendations on mounting and adjusting.	22
Troubleshooting	23
Activation of the Certified App Interface	29
Configuration of FF Group License Plate Recognition App - Region ME	30
Basic Settings	31
Recognition Zones	32
Integration Interfaces	33
Whitelist & Black list	34
Overlay Configuration	35
MxMessage Configuration	35
Installation Tools	36
Storing the Configuration	37
MxMessageSystem	38
What is MxMessageSystem?	38
Facts about MxMessages	38
MxMessageSystem: Processing the automatically generated app event	39
Checking automatically generated app events	39
Action handling - Configuration of an Action Group	40
Action settings - Configuration of the camera recordings	43
MxMessageSystem: Processing the meta data transmitted by apps	45
Meta data transferred within the MxMessageSystem	45
Creating a Custom Message Event	46
Examples for message names and filter values of the FF Group License Plate Recognition App - Region ME	48

Before You Start

Support	6
MOBOTIX Support	6
MOBOTIX eCampus	6
MOBOTIX Community	6
Safety Notes	6
Legal Notes	7

Support

MOBOTIX Support

If you need technical support, please contact your MOBOTIX dealer. If your dealer cannot help you, he will contact the support channel to get an answer for you as quickly as possible.

If you have internet access, you can open the MOBOTIX help desk to find additional information and software updates.

Please visit www.mobotix.com > [Support](#) > [Help Desk](#).



MOBOTIX eCampus

The MOBOTIX eCampus is a complete e-learning platform. It lets you decide when and where you want to view and process your training seminar content. Simply open the site in your browser and select the desired training seminar.

Please visit www.mobotix.com/ecampus-mobotix.



MOBOTIX Community

The MOBOTIX community is another valuable source of information. MOBOTIX staff and other users are sharing their information, and so can you.

Please visit community.mobotix.com.



Safety Notes

- This camera must be installed by qualified personnel and the installation should conform to all local codes.

- This product must not be used in locations exposed to the dangers of explosion.
- Do not use this product in a dusty environment.
- Protect this product from moisture or water entering the housing.
- Install this product as outlined in this document. A faulty installation can damage the product!
- Do not replace batteries of the camera. If a battery is replaced by an incorrect type, the battery can explode.
- External power supplies must comply with the Limited Power Source (LPS) requirements and share the same power specifications with the camera.
- When using a Class I adapter, the power cord shall be connected to a socket-outlet with proper ground connection.
- To comply with the requirements of EN 50130-4 regarding the power supply of alarm systems for 24/7 operation, it is highly recommended to use an uninterruptible power supply (UPS) for backing up the power supply of this product.

Legal Notes

Legal Aspects of Video and Sound Recording

You must comply with all data protection regulations for video and sound monitoring when using MOBOTIX AG products. Depending on national laws and the installation location of the cameras, the recording of video and sound data may be subject to special documentation or it may be prohibited. All users of MOBOTIX products are therefore required to familiarize themselves with all applicable regulations and to comply with these laws. MOBOTIX AG is not liable for any illegal use of its products.

Declaration of Conformity

The products of MOBOTIX AG are certified according to the applicable regulations of the EC and other countries. You can find the declarations of conformity for the products of MOBOTIX AG on www.mobotix.com under **Support > Download Center > Marketing & Documentation > Certificates & Declarations of Conformity**.

RoHS Declaration

The products of MOBOTIX AG are in full compliance with European Unions Restrictions of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS Directive 2011/65/EC) as far as they are subject to these regulations (for the RoHS Declaration of MOBOTIX, please see www.mobotix.com, **Support > Download Center > Marketing & Documentation > Brochures & Guides > Certificates**).

Disposal

Electrical and electronic products contain many valuable materials. For this reason, we recommend that you dispose of MOBOTIX products at the end of their service life in accordance with all legal requirements and regulations (or deposit these products at a municipal collection center). MOBOTIX products must not be disposed of in household waste! If the product contains a battery, please dispose of the battery separately (the corresponding product manuals contain specific directions if the product contains a battery).

Disclaimer

MOBOTIX AG does not assume any responsibility for damages, which are the result of improper use or failure to comply to the manuals or the applicable rules and regulations. Our General Terms and Conditions apply. You can download the current version of the **General Terms and Conditions** from our website at www.mobotix.com by clicking on the corresponding link at the bottom of every page.

It is the User's responsibility to comply with all applicable local, state, national and foreign laws, rules, treaties and regulations in connection with the use of the Software and Product, including those related to data privacy, the Health Insurance Portability and Accountability Act of 1996 (HIPPA), international communications and the transmission of technical or personal data.

About FF Group License Plate Recognition App - Region ME

Certified App for License Plate Recognition - Region Middle East

The app's artificial intelligence-based algorithms, which have been successfully tested in numerous middle eastern markets, allow the reliable recognition of single and two-line license plates of vehicles in the supported regions of origin (Saudi Arabia, United Arab Emirates, Bahrain, Kuwait, Qatar, Oman). Typical application areas for the app are: Parking management, access control and regulation, traffic monitoring.

- App delivers events via MxMessageSystem in real-time
- Integrated recognition protocol (last 1000 recognized license plates)
- Detection with 95% accuracy (depending on environmental conditions)
- Camera can be online or offline
- Configuration of the application also via MxManagementCenter (free Advanced Config license required)
- Can be used with all cameras of the MOBOTIX 7 system platform

CAUTION! Thermal sensors are not supported by this app.

Smart Data Interface to MxManagementCenter

This app has a Smart Data interface to MxManagementCenter.

With the MOBOTIX Smart Data System, transaction data can be linked to the video recordings made at the time of the transactions. Smart Data source can be e.g. MOBOTIX Certified Apps (no license required) or general Smart Data sources (license required) like POS systems or license plate recognition systems.

The Smart Data System in MxManagementCenter enables you to quickly find and review any suspicious activities. The Smart Data Bar and the Smart Data View are available for searching and analyzing transactions. The Smart Data Bar provides a direct overview of the most recent transactions (from the last 24 hours) and for this reason it is convenient to use it for reviews and searches.

NOTE! For information on how to use the Smart Data System, see the corresponding online help of the camera software and MxManagementCenter.

Technical Specifications

Product Information

Product Name	FF Group License Plate Recognition App - Region ME
Order Code	Mx-APP-FF-LPR-ME
Supported MOBOTIX Cameras	Mx-M73A, Mx-S74A
Minimum Camera Firmware	v7.3.0.x
MxManagementCenter Integration	<ul style="list-style-type: none">min. MxMC v2.5.3Configuration: Advanced Config license requiredEvent Search: Smart Data Interface license included

Product Features

App Features	<ul style="list-style-type: none">Recognition of one- and two-line license platessimultaneous recognition on one or more image sensorsRecognition of latin charactersConsolidated event search via MxManagementCenter Smart Data InterfaceMOBOTIX events via MxMessageSystemMultiple license plate lists for individual actions (e.g. access granted, alarm, etc.)
Maximum number of lanes	3
Maximum number of enrolled license plates	1000
Meta Data / Statistic formats	JSON
Trial License	30-day trial license pre-installed
MxMessageSystem supported	Yes

Integration interfaces	<ul style="list-style-type: none"> ▪ 3rd party integration via HTTP(S) Post and TCP messages ▪ UMTC protocol ▪ compare supported camera interfaces
------------------------	---

MOBOTIX Events	Yes
----------------	-----

ONVIF Events	Yes (Generic message event)
--------------	-----------------------------

Supported Regions

Supported license plates / countries	Saudi Arabia, United Arabic Emirates, Bahrain, Kuwait, Qatar, Oman
--------------------------------------	--

Scene Requirements

License Plate Width	min. 130px max. 300px
---------------------	--------------------------

Maximum Vertical Angle	30°
------------------------	-----

Maximum Horizontal Angle	30°
--------------------------	-----

Maximum Tilt Angle	5°
--------------------	----

Technical App Specifications

Synchronous / Asynchronous App	synchronous
--------------------------------	-------------

Simultaneous execution of other apps	Yes (considering performance requirements)
--------------------------------------	--

Accuracy	min. 95% (considering scene requirements)
----------	---

Processed framerate	typ. 10 fps
---------------------	-------------

Detection time	typ. 80ms (one lane) typ. 120ms (two lanes)
----------------	--

Licensing Certified Apps

The following licenses are available for the FF Group License Plate Recognition App - Region ME:

- **30-day test license** pre-installed
- **permanent commercial license**

The usage period begins with activation of the app interface (see)

NOTE! For buying or renewing a license, contact your MOBOTIX Partner.

NOTE! Apps are usually pre-installed with the firmware. In rare cases, apps must be downloaded from the website and installed. In this case see www.mobotix.com > **Support** > **Download Center** > **Marketing & Documentation**, download and install the app.

License Activation of Certified Apps in MxManagementCenter

After a test period commercial licenses must be activated for use with a valid license key.

Online-Activation

After receiving the activation IDs, activate them in MxMC as follows:

1. Select from the menu **Window > Camera App Licenses**.
2. Select the camera on which you want to license apps and click **Select**.




Fig. 1: Overview of Camera App Licenses in MxManagementCenter

NOTE! If necessary, correct the time set on the camera.

1. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.





Fig. 2: Overview of the licenses installed on the camera

NOTE! If necessary, correct the time set on the camera.

2. Enter a valid Activation ID and specify the number of licenses to install on this computer.
3. If you want to license another product, click on . In the new row, enter the appropriate Activation ID and the number of licenses you want.

Licensing Certified Apps

License Activation of Certified Apps in MxManagementCenter

- To remove a line click .
- When you have entered all Activation IDs, click **Activate License Online**. During activation, **MxMC** connects to the license server. This requires an Internet connection.




Fig. 3: Adding licenses

Successful activation

After successful activation, a new log in is required to apply the changes. Alternatively, you can return to license management.

Failed activation (missing internet connection)

If the license server cannot be reached, e.g. due to a missing internet connection, apps can also be activated offline. (see [Offline Activation](#), p. 14).

Offline Activation

For offline activation, the partner/installer from whom you purchased the licenses can generate a capability response (.bin file) on the license server to activate their licenses.

- Select from the menu **Window > Camera App Licenses**.
- Select the camera on which you want to license apps and click **Select**.




Fig. 4: Overview of Camera App Licenses in MxManagementCenter

NOTE! If necessary, correct the time set on the camera.

3. An overview of the licenses installed on the camera may be displayed. Click **Activate License**.






Fig. 5: Overview of the licenses installed on the camera

NOTE! If necessary, correct the time set on the camera.

Licensing Certified Apps

License Activation of Certified Apps in MxManagementCenter

4. Enter a valid Activation ID and specify the number of licenses to install on this computer.
5. If you want to license another product, click on . In the new row, enter the appropriate **Activation ID** and the number of licenses you want.
6. If necessary, click  to remove a line.
7. When you have entered all Activation IDs, click **Download Capability Request File (.lic)** and send it to your partner/installer.

NOTE! This file allows the partner / installer from whom you purchased the licenses to generate a capability response file (.bin) on the license server.




Fig. 6: Adding licenses

8. Click Load Capability Response File and follow the instructions.

Successful activation

After successful activation, a new log in is required to apply the changes. Alternatively, you can return to license management.

Managing Licenses in MxManagementCenter

In MxManagementCenter you can comfortably manage all licenses that have been activated for a camera.

1. Select from the menu **Window > Camera App Licenses**.
2. Select the camera on which you want to license apps and click **Select**.




Fig. 7: Overview of Camera App Licenses in MxManagementCenter

An overview of the licenses installed on the camera may be displayed.




Fig. 8: Overview of the licenses installed on the camera

NOTE! If necessary, correct the time set on the camera.

Column	Explanation
Name	Name of the licensed app
Expiration	the time limit of the license
Quantity	Number of licenses purchased for a product.
Serial Number	Unique identification determined by MxMC for the device used. If problems occur during licensing, please have the device ID ready.

Synchronize licenses with server

When the program starts, there is no automatic comparison of the licenses between the computer and the license server. Therefore, click **Update** to reload the licenses from the server.

Update licenses

To update temporary licenses, click **Activate Licenses**. The dialog for updating/activating licenses opens.

NOTE! You need administrator rights to synchronize and update licenses.

Camera, image and scene requirements

In order to be able to recognize license plates in the best possible way, the following prerequisites must be fulfilled for the scene:

Quality of the license plate to be captured in the image

- The license plate must be high-contrast and clearly legible, i.e. as clean as possible, without dents or holes and well illuminated.
- The license plate should be rectangular
- License plate width
 - min. 130p
 - max. 300px
- Maximum rotation angle: 5°



- Maximum tilt angle of the license plate to the camera: 30° horizontal and vertical

Examples of clearly recognizable license plates



Fig. 9: Easily readable license plate in daylight



Fig. 10: Easily readable license plate at night with infrared LED illumination

Vertical pointing of the camera

The vertical angle to the registration plate must not exceed 30°. The minimum distance (**x**) from the camera as a function of its mounting height (**h**) is calculated by the formula:

$$x = h * \sqrt{3}$$

Example: calculation of the vertical alignment of the camera

h (Meter)	x (Meter)
1	1,7
1,5	2,6
2	3,4
2,5	4,3
3	5,1
3,5	6
4	6,8




Fig. 11: Vertical pointing of the camera

Horizontal pointing of the camera

The horizontal angle to the registration plate must not exceed 30°. The minimum distance (**x**) from the camera as a function of its mounting height (**y**) is calculated by the formula:

$$x = y * \sqrt{3}$$

Sample calculation of the horizontal alignment of the camera

y (meter)	x (meter)
1	1,7
1,5	2,6




Fig. 12: Horizontal alignment of the camera

y (meter)	x (meter)
2	3,4
2,5	4,3
3	5,1
3,5	6
4	6,8




Fig. 12: Horizontal alignment of the camera

Depth of field in relation of vehicle speed and recognition time per plate

To effectively capture the vehicle camera should be set so as to provide the minimum depth of field (DOF). Depth-of-field (or length of the zone of sharpness) is the distance between the nearest and farthest objects that appear in acceptably sharp focus in a video.

The depth of field can be calculated by the formula:

$$L_{dof} = \frac{4 * T_{rec} * V_{max}}{3600}$$

Definition of the variables use in the formula

L_{dof} = depth of field in meters (m)

T_{rec} = recognition time per plate in milliseconds (ms)

V_{max} =maximum vehicle speed in kilometers per hour (km/h)

Example: calculation of typical cases

maximum vehicle speed in kilometers per hour (km/h)	recognition time per plate in milliseconds (ms)				
	100	200	300	400	500
depth of field in meters (m)					
40	4	9	13	18	22
80	9	18	27	36	44
100	11	22	33	44	56
120	13	27	40	53	67
140	16	31	47	62	78
180	20	40	60	80	100
200	22	44	67	89	111
220	24	49	73	98	122
240	27	53	80	107	133

Camera, image and scene requirements

Recommendations on mounting and adjusting.

NOTE! The minimum sizes of the license plate on the edges of the zone of sharpness must be at least as mentioned in [Quality of the license plate to be captured in the image, p. 19](#).

NOTE! For the best possible depth of field it is strongly recommended to manually adjust the camera's aperture settings instead of using the automatic settings.

Exposure time in relation to maximum vehicle speed

The exposure time must be adjusted to get the best results in recognition of license plates. Values are calculated for a camera mounted at a horizontal angle of 30 degrees.

Example: calculation of typical cases

exposure time in seconds (s) **maximum vehicle speed in kilometers per hour (km/h)**

1/100	5
1/500	40
1/1000	100
1/2000	200
1/4000	400

NOTE! The exposure time must be adjusted according to the light conditions.

Recommendations on mounting and adjusting.

- If you want to recognize license plates on multiple lanes it is generally recommended to mount the camera on a crossbar.
- Use an IR LED to recognize license plates at night or under low light conditions.
- Shutter speed must be high enough to cut the light from car's headlights at night (usually it's about 1/1000). Keep in mind, that too high shutter speed may obscure the edges of the lines (especially shadows).
- Depth of focus is a very important parameter. If you are using a camera with a CS-mount lens, use a fixed lens. Fixed lenses are better for license plate recognition due to greater depth of focus. Megapixel lenses are also strongly recommended.
- Respect changing light conditions (e. g. due to sunrises and sunset) when choosing the place of mounting. Direct sunlight beams can distort a picture. If the cars are facing a direct sunlight consider using a lens with auto iris mode.

- If mounting a camera on a roadside pole check how the pole reacts to heavy cars or a convoy of cars. Some poles have tangible tremor, this could make license plate recognition almost impossible.
- It is recommended to turn down WDR and BLC. In most cases, they will make the picture more pretty, but at the cost of smudging details like an edges of letters in the license plate. For the same reason keep digital noise reduction as low as possible.
- On certain rare conditions there may be a cases of false detections e. g. because of recognizing image parts that structurally or semantically look similar to a license plate(e. g. fences or ads). To minimize this:
 - Adjust the region of interest accordingly. It may be a good idea to make it smaller, or change it's shape, omitting the parts, which potentially may be false detected.
 - Adjust the min and max license plate settings according to upper instructions do not leave a default 130 - 300.
 - There may be cases, when the best performance will occur by changing angle of lens or moving the camera. In some cases, shooting a front license plate is better.

Troubleshooting

Blurred license plates can not be recognized

Problem: If you need to recognize multiple license plates of cars following one another a wider depth of field might be necessary. In the example below only the license plate in the green frame can be recognized.

Solution: adjust the lens focus to archive a higher depth of field.



Fig. 13: Insufficient depth of field

Problem: License plate is blurred due to wrong focus settings or to long exposure time.

Solution: Adjust focus settings or increase shutter speed



Fig. 14: Blurred license plate due to long exposure time

License plates cannot be recognized due to over exposure

Problem: In certain situations license plates can be over exposed and therefore no more readable. Possible cause could be direct sunlight shining on the license plates or to strong IR LED light at night.

Solution: Adjust shutter speed or dim IR LED light.



Fig. 15: Over exposed license plate at daytime



Fig. 16: Over exposed license plates due to too strong IR LED light

License plates cannot be recognized due to insufficient light

Problem: In certain situations there is not enough light which results in low contrast. Therefore license plates are not readable. Possible cause could be direct sunlight shining on the license plates or too strong IR LED light at night.

Solution: Adjust the shutter speed or provide extra light.



Fig. 17: Insufficient light to recognize license plate

License plates cannot be recognized due to low resolution

Problem: It seems that the license plate is well recognizable despite good illumination and sufficient resolution.

Solution: Measure the resolution of the license plate to be captured with an image processing program. It may be necessary to adjust the horizontal resolution to the minimum required 130 px (see [Camera, image and scene requirements](#), p. 19).




Fig. 18: Insufficient light to recognize license plate

Activation of the Certified App Interface

CAUTION! The FF Group License Plate Recognition App - Region ME does not consider obscure areas defined for the live image. Therefore there is no pixelation in obscure areas while configuring the app and during image analysis by the app.

NOTE! The user must have access to the setup menu ([http\(s\)://<camera IP address>/control](http(s)://<camera IP address>/control)). Therefore check the user rights of the camera.

1. In the camera web interface, open: **Setup Menu / Certified App Settings** ([http\(s\)://<camera IP address>/control/app_config](http(s)://<camera IP address>/control/app_config)).



2. Under **General Settings** activate the **Arming** of the MOBOTIX app service ① .
3. Click Set ③ . The installed apps are now listed.
4. Under **App Settings** check the **Active** option of the of the relevant app.
5. Click on the name of the App ② to be configured to open the Apps user interface.
6. For configuration of the App see [Configuration of FF Group License Plate Recognition App - Region ME, p. 30.](#)

Configuration of FF Group License Plate Recognition App - Region ME

NOTE! For best performance and results in LPR processing make sure to have scene set up to meet the [Camera, image and scene requirements, p. 19](#).

CAUTION! The user must have access to the setup menu ([http\(s\)://<camera IP address>/control](http(s)://<camera IP address>/control)). Therefore check the user rights of the camera.

1. In the camera web interface, open: **Setup Menu / Certified App Settings** ([http\(s\)://<camera IP address>/control/app_config](http(s)://<camera IP address>/control/app_config)).
2. Click on the name of the **FF Group License Plate Recognition App - Region ME**.

The configuration window of the app appears with the following options:

Basic Settings

MOBOTIX M73 mx10-32-6-96 FFLPRME Settings

FFLPRME

Sensor Selection	Automatic	Select the image sensor
Image Size	1920x1080	Defines the image size, which is used as basis for the license plate recognition. Factory default: Full HD (1920x1080)
Enable Overlays	<input type="checkbox"/>	Highlight recognized license plates and enable the on-screen text overlay
Enable MxMessage	<input type="checkbox"/>	Send an MxMessage for each license plate recognized. The MxMessage is required for the configuration of Message Events on the camera and for the usage of the MxMC Smart Data Interface.
Region	Middle East	Recognition of number plates within the selected region. For countries belonging to the region, see the app documentation.
Recognition Zones of the Right sensor		<input checked="" type="checkbox"/>
Recognition Zones of the Left sensor		<input checked="" type="checkbox"/>
Integration Interfaces		<input checked="" type="checkbox"/>
Whitelist		<input checked="" type="checkbox"/>
Blacklist		<input checked="" type="checkbox"/>

Set Factory Restore Close

Sensor selection: Select the sensor(s) to be used for the video stream to be analyzed by FF Group License Plate Recognition App - Region ME.

NOTE! Automatic corresponds to the live image configured on the camera FF Group License Plate Recognition App - Region ME.

Image Size: Select the resolution for the video stream to be analyzed by FF Group License Plate Recognition App - Region ME).

NOTE! The resolution for LPR processing could be different from the resolution used for live stream.


Enable Overlays: Check to highlight recognized license plates and enable the on-screen text overlay in the live view.

Enable MxMessage: Check to enable sending a MxMessage for each license plate recognized. The MxMessage is required for the configuration of Message Events on the camera and for the usage of the MxMC Smart Data Interface.

Region: Select the region to be set for the LPR engine.

Recognition Zones

Recognition zones can be defined on up to two sensors. Per sensor up to three recognition areas can be defined. Each recognition zone is evaluated by the LPR engine independently of the others. Accordingly, each zone is assigned an individual ID (zone number).




Drawing a Recognition Area

1. Click the **plus** icon ① to switch into the live image.
2. In the live view simply click and drag a rectangular recognition area.
3. Drag the corner points to refine the recognition area.
4. In the top right corner of the live view click **Submit** to adopt the coordinates of the rectangle.
5. Optionally click the **bin** icon ② to delete the recognition area.

NOTE! Without activating the zones the full image will be analyzed.

Integration Interfaces

LPR events can be send to 3rd party systems, e. g. Access Control Systems or Video Management Systems. Therefore the following configurations should be taken into account:

Integration Interfaces 		
Enable	<input type="checkbox"/>	Enable the integration interface to send IP notifications to a defined external receiver (e.g. 3rd party access control systems, video management system, etc.)
Destination Address	<input type="text" value="http://server.address"/>	Receiver / Server IP address and port. Separate IP address and port using a colon (e.g. 10.0.0.1:80)
Transfer Protocol	<input type="text" value="HTTP(s) POST"/>	Transfer notification data using these protocol headers
Device ID	<input type="text" value="defaultID"/>	Device ID is used as unique identifier for the device sending the IP notification (e.g. camera's serial number / factory IP address)
Attach Image	<input type="checkbox"/>	Enable to attach an event image to the IP notification
Image Selection	<input type="text" value="License plate crop"/>	Selection of the event image to be attached to the IP notification
Event Type: New	<input type="checkbox"/>	Send the IP notification for event type 'new'. Condition 'new' becomes true, if the license plate appears for the first time in 5 seconds
Event Type: Update	<input type="checkbox"/>	Send the IP notification for event type 'update'. Condition 'update' becomes true, if the license plate was already detected in the last 5 seconds
Event Type: Lost	<input type="checkbox"/>	Send the IP notification for event type 'lost'. Condition 'lost' becomes true, if plate was not seen in the last 5 seconds since previous detection
self-signed certificates	<input type="checkbox"/>	Allow self-signed certificates for HTTPS

Enable: Check to enable the integration interface to send IP notifications to a defined external receiver (e.g. 3rd party access control systems, video management system, etc.).

Destination Address: Receiver / Server IP address and port. Separate IP address and port using a colon (e.g. 10.0.0.1:80).

Transfer Protocol: Select the protocol on the basis of which the LPR events are transmitted.

TCP: Data will be transmitted via TCP.

HTTP POST: Data will be transmitted via FFG protocol. [Download a detailed description.](#)

Device ID: Set an unique text string to identify your camera device in messages. Device ID is used as unique identifier for the device sending the IP notification (e.g. camera's serial number / factory IP address).

Attach Image: Check to attach an event image to the IP notification.

Image Selection: If images should be send select the image type here:

License plate crop: The image contains the license plate only.

Vehicle crop: The image contains the vehicle with the recognized license plate.

Full frame: the full image is transmitted.

Event Type: New: Check to send an IP notification for event type 'new'. Condition 'new' becomes true, if the license plate appears for the first time in 5 seconds.


Event Type: Update: Check to send an IP notification for event type 'update'. Condition 'update' becomes true, if the license plate was already detected in the last 5 seconds.

Event Type: Lost: Check to send an IP notification for event type 'lost'. Condition 'lost' becomes true, if plate was not seen in the last 5 seconds since previous detection.

Self signed certificates: Allow self signed certificates for HTTPS.

Whitelist & Black list

You can define a black list and a white list with up to 1000 license plates per list. If a license plate from one of the lists is recognized, a corresponding event is sent within the MxMessageSystem of the camera.



Adding a license plate to a list

- Enter the license plate text into the text field ① and click **Enter**.

Adding multiple license plates from a text file

1. Make sure that your text file contains one license plate per line.
2. Copy the relevant license plates from the text file and paste them into the text field ① .

Deleting a license plate from a list

- Click on the small x ② to the right of the license plate number.

Deleting all license plates from a list

- Click the trash icon ③ .

Sorting all license plates from a list alphabetically

- Click the sort icon ④ .

Copy all license plates from a list to the clip board

- Click the copy to clipboard icon ⑤ .

Filtering license plates

- Enter the license plate or parts of it into the filter text field⑥ . Only license plates containing the filter text are displayed accordingly.

Overlay Configuration

In this section you can customize the overlay.

Overlay Configuration		
Color for overlay	White	Color of overlay text
	Full color	Opacity of overlay text
Overlay Duration	2	Set overlay duration in seconds
Overlay Position	Left Top	Select position of overlay text
Overlay license plate crop	<input type="checkbox"/>	Display recognized license plate crop
Image overlay Position	Left Top	Select position of overlay image

Color for overlay: Select a color the opacity of overlay text.

Overlay duration: Set the overlay duration in seconds.

Overlay Position: Select the overlay text position in the camera image.

Overlay License Plate Crop: Check to display the recognized license plate crop.

Image Overlay Position: Select the overlay image position in the camera image.

MxMessage Configuration

In this section, you can specify for which events a MxMessage is to be sent.

MxMessage Configuration		
MxMessage New	<input checked="" type="checkbox"/>	Send an MxMessage for LPR NEW event
MxMessage Update	<input type="checkbox"/>	Send an MxMessage for LPR UPDATE event
MxMessage Lost	<input checked="" type="checkbox"/>	Send an MxMessage for LPR LOST event

MxMessage New: Check to send a MxMessage for "LPR NEW" event.

MxMessage Update: Check to send a MxMessage for "LPR UPDATE" event.

MxMessage Lost: Check to send a MxMessage for "LPR LOST" event.

Installation Tools

In this section you find useful tools for calibration and trouble shooting.

Installation Tools		
Calibration grid	<input type="checkbox"/>	Turn on the calibration grid to detect the acceptable license plate size. Vertical lines indicate a distance of 130 pixels wide. Please keep the license plates in the range 130-300 pixels wide
Debug level	<div style="border: 1px solid black; padding: 2px;"> <div style="background-color: #ffff00; padding: 2px;">✓ NO LOG</div> <div style="background-color: #0000ff; color: white; padding: 2px;">DEBUG</div> </div>	Available options NO LOG: No debug log is created (Factory default). DEBUG: Added additional info to overlay text
LPR Confidence	0.7	Set the confidence threshold which must be reached to recognize license plates. The confidence value within the sent MxMessage can be used as an indication for a proper configuration.
Minimum license plate characters	6	Defines the minimum number of characters in the recognized license plates, shorter sequences will be ignored. The practical recommended minimum is 5. Default 6.
Maximum license plate characters	10	Defines the maximum number of characters in the recognized license plates, longer sequences will be ignored. Default 10.
The Levenshtein distance is a string metric for measuring the difference between two sequences.	1	The Levenshtein distance between two words is the minimum number of single-character edits (insertions, deletions or substitutions) required to change one word into the other.

Calibration grid: Turn on the calibration grid to detect the acceptable license plate size. Vertical lines indicate a distance of 130 pixels wide. Please keep the license plates in the range 130-300 pixels wide.

Debug level: Select a debug level to generate a log file, which can be helpful e.g. for trouble shooting.

NOLOG: no debug log is created (default setting)

DEBUG

LPR Confidence: Set the confidence threshold which must be reached to recognize license plates. The confidence value within the sent MxMessage can be used as an indication for a proper configuration.

Minimum License Plate Characters: Minimum number of characters that the license plate may have. Recommended minimum is 5. The default setting is 6

Maximum License Plate Characters: Minimum number of characters that the license plate may have. Maximum number of characters that the license plate may have. Longer sequences will be ignored.

Levenshtein distance: The minimum number of single-character edits (insertions, deletions or substitutions) required to change one word into the other.

CAUTION! Wrong settings can lead to bad recognition results. In most cases the default settings are sufficient.

Storing the Configuration

To store the configuration you have the following options:



- Click **Set** to activate your settings and to save them until the next reboot of the camera.
- Click **Factory** to load the factory defaults for this dialog (this button may not be present in all dialogs).
- Click **Restore** to undo your most recent changes that have not been stored in the camera permanently.
- Click **Close** to close the dialog. While closing the dialog, the system checks the entire configuration for changes. If changes are detected, you will be asked if you would like to store the entire configuration permanently.

After successfully saving the configuration, the event and meta data are automatically sent to the camera in case of an event.

MxMessageSystem

What is MxMessageSystem?

MxMessageSystem is a communication system based on name oriented messages. This means that a message must have a unique name with a maximum length of 32 bytes.

Each participant can send and receive messages. MOBOTIX cameras can also forward messages within the local network. This way, MxMessages can be distributed over the entire local network (see Message Area: Global).

For example, a MOBOTIX 7 series camera can exchange a MxMessage generated by a camera app with an Mx6 camera that does not support certified MOBOTIX apps.

Facts about MxMessages

- 128-bit encryption ensures privacy and security of message content.
- MxMessages can be distributed from any camera of the Mx6 and 7 series.
- The message range can be defined individually for each MxMessage.
 - **Local:** Camera expects a MxMessage within its own camera system (e.g. through a Certified App).
 - **Global:** the camera expects a MxMessage that is distributed in the local network by another MxMessage device (e.g. another camera of the 7 series equipped with a certified MOBOTIX app).
- Actions that the recipients are to perform are configured individually for each participant of the MxMessageSystem.

MxMessageSystem: Processing the automatically generated app event

Checking automatically generated app events

NOTE! After successfully activating the app (see [Activation of the Certified App Interface, p. 29](#)), a generic message event for this specific app is automatically generated in the camera.

1. Go to **Setup-Menu / Event Control / Event Overview**. In section **Message Events** the automatically generated message event profile is named after the application (e. g. FFLPRME)

The screenshot shows the MOBOTIX web interface for configuring a Message Event. The page title is "M73 mx10-32-6-96 Message Events". A table lists the events, with "FFLPRME" selected. Below the table, the configuration for the selected event is shown, including the Event Dead Time, Event Sensor Type, Message Name, Message Range, and Filter Message Content.

Events	Value	Explanation
DermalogFaceAttendance	<input type="checkbox"/> Inactive <input type="checkbox"/> Delete	
FFLPRME	<input checked="" type="checkbox"/> Inactive <input type="checkbox"/> Delete	

Event Dead Time:
Time to wait [0..3600 s] before the event can trigger anew.
5

Event Sensor Type:
Choose the message sensor.
 IP Receive
 MxMessageSystem

Event on receiving a message from the MxMessageSystem.

Message Name:
Defines an MxMessageSystem name to wait for.
FFLPRME

Message Range:
There are two different ranges of message distribution:
Global: across all cameras within the current LAN.
Local: camera internal.
Local

Filter Message Content:
Optionally choose how to ignore messages containing *Filter Value*. Select *No Filter* to trigger on any message with defined *Message Name*.
No Filter

Buttons: Set, Factory, Restore, Close

2. Click **Edit** to display and configure the event properties in detail.

The screenshot shows the MOBOTIX web interface for configuring an event. The interface is titled "M73 mx10-32-6-96 Message Events". It features a table with columns for "Events", "Value", and "Explanation". The "FFLPRME" event is selected and highlighted in blue. Below the table, the configuration details for the selected event are shown:

- Event Dead Time:** 5 (Time to wait [0..3600 s] before the event can trigger anew.)
- Event Sensor Type:** MxMessageSystem (Choose the message sensor.)
- Event Description:** Event on receiving a message from the MxMessageSystem.
- Message Name:** FFLPRME (Defines an MxMessageSystem name to wait for.)
- Message Range:** Local (There are two different ranges of message distribution: *Global*: across all cameras within the current LAN. *Local*: camera internal.)
- Filter Message Content:** No Filter (Optionally choose how to ignore messages containing *Filter Value*. Select *No Filter* to trigger on any message with defined *Message Name*.)


At the bottom of the configuration panel, there are four buttons: "Set", "Factory", "Restore", and "Close".

Action handling - Configuration of an Action Group


CAUTION! To use events, trigger Action Groups or record images the general arming of the camera must be enabled ([http\(s\)/<camera IP address>/control/settings](http(s)/<camera IP address>/control/settings))

An Action Group defines which action(s) is (are) triggered by the FF Group License Plate Recognition App - Region ME event.

1. In the camera web interface, open: **Setup Menu / Action Group Overview** ([http\(s\)://<camera IP address>/control/actions](http(s)://<camera IP address>/control/actions)).



2. Click **Add new group** ① and give a meaningful name.
3. Click **Edit** ②, to configure the group.



MxMessageSystem: Processing the automatically generated app event

Action handling - Configuration of an Action Group

4. Enable **Arming** ③ of the Action Group.
5. Select your message event in the **Event selection** list ④ . To select multiple events, hold the shift key.
6. Click **Add new Action** ⑤ .
7. Select a proper action from list **Action Type and Profile** ⑥ .

The screenshot shows the MOBOTIX M73 mx10-32-6-96 Action Group Details configuration window. The window is divided into several sections:

- Settings:** Includes a dropdown for "(No time table)" and a "Time Table" section with a link to "Time Tables".
- Event Selection:** A dropdown menu is open, showing a list of actions. The action "IP Notify: MxMC-Alarm" is selected and circled with a "6".
- Action Details:** A section for configuring the selected action.
- Actions:** A section for adding and managing actions. The "Action 1" dropdown shows "FTP: FTP-Webcam".
- Right Panel:** Contains detailed settings for the selected action, including "Event Selection", "Action Deadtime", "Action Chaining", and "Explanation".

At the bottom of the window, there are buttons for "Set", "Factory", "Restore", and "Close".

NOTE! If the required action profile is not yet available, you can create a new profile in the Admin Menu sections "MxMessageSystem", "Transfer Profiles" and "Audio and VoIP Telephony".

If necessary, you can+ add further actions by clicking the button again. In this case, please make sure that the "action chaining" is configured correctly (e.g. at the same time).

8. Click on the **Set** ⑦ button at the end of the dialog box to confirm the settings.
9. Click on **Close** ⑧ to save your settings permanently.

Action settings - Configuration of the camera recordings

1. In the camera web interface, open: **Setup Menu / Event Control / Recording**([http\(s\)/<camera IP address>/control/recording](http(s)/<camera IP address>/control/recording)).

The screenshot displays the MOBOTIX web interface for configuring camera recordings. The interface is organized into several sections:

- General Settings:**
 - Arming:** A dropdown menu is set to "Enabled" (indicated by a circled 1). The explanation states: "Arm Recording: Controls camera recording. Enabled: activate recording. Off: deactivate recording. St: recording armed by signal input. CS: recording armed by custom signal as defined in General Event Settings. From Master: copies recording arming state from master camera."
 - Time Table Profile:** A dropdown menu is set to "(No time table)". The explanation states: "Time table profile for time-controlled recording (Time Tables)."
- Storage Settings:**
 - Recording (REC):** A dropdown menu is set to "Event Recording" (indicated by a circled 2). The explanation states: "Recording Mode: Type of event and story recording. Snap Shot Recording: stores single JPEG pictures. Event Recording: stores stream files for every event using MxPEG codec. Continuous Recording: continuously streams video data to stream files using MxPEG codec. Events can be recorded with a higher frame rate using Start Recording, Retrigger Recording and Stop Recording."
 - Record Audio Data:** A dropdown menu is set to "Include audio". The explanation states: "Record Audio Data: Store audio data in stream file if available. Enable and configure microphone."
- Start Recording:**
 - A list of events is shown, with "Message: FFLPRME" selected (indicated by a circled 3). Other events include "(Image Analysis: VM)", "(Image Analysis: VM2)", "Message: DermalogFaceAttendance", and "Message: FFLPR_MMCR". The explanation states: "Start Recording: Select the events which will start recording. Use [Ctrl]-Click to select more than one event. Events in parentheses need to be activated first."
 - Max fps:** A dropdown menu is set to "0". The explanation states: "Event Frame Rate: Recording speed if an event is detected, in frames per second."
 - Recording Time Before Event:** A dropdown menu is set to "0".

At the bottom of the interface, there are buttons for "Set" (indicated by a circled 4), "Factory", "Restore", "Close" (indicated by a circled 5), and "More".

2. Activate **Arm Recording**① .
3. Under **Storage Settings / Recording (REC)** select a **Recording mode**② . The following modes are available:
 - Snap Shot Recording
 - Event Recording
 - Continuous Recording
4. In list **Start recording**③ select the message event just created.
5. Click on the **Set**④ button at the end of the dialog box to confirm the settings.
6. Click on **Close**⑤ to save your settings permanently.

MxMessageSystem: Processing the automatically generated app event


Action settings - Configuration of the camera recordings

NOTE! Alternatively, you can save your settings in the Admin menu under Configuration / Save current configuration to permanent memory.

MxMessageSystem: Processing the meta data transmitted by apps

Meta data transferred within the MxMessageSystem

For each event, the app also transfers meta data to the camera. This data is sent in the form of a JSON schema within a MxMessage.




```
{
  "local": {
    "FFLPRME": {
      "custom": {
        "blacklist": "false",
        "notlisted": "true",
        "whitelist": "false"
      },
      "plate": {
        "camera_id": "defaultID",
        "Confidence": "0.70",
        "Country": "KWT",
        "Direction": "in",
        "EventType": "lost",
        "LicensePlate": "2011909",
        "List": "not listed",
        "Time": "1635221909.755",
        "Zone": "1",
        "carID": "1"
      }
    }
  }
}
```

NOTE! To view the meta data structure of the last App event, enter the following URL in the address bar of your browser: [http\(s\)://IPAdresseOfYourCamera/api/json/messages](http(s)://IPAdresseOfYourCamera/api/json/messages)

Creating a Custom Message Event

1. Go to **Setup-Menu / Event Control / Event Overview**. In section **Message Events** the automatically generated message event profile is named after the application (e. g. FFLPRME).



2. Click **Edit** ^① to display and configure the event properties in detail.

The screenshot shows the MOBOTIX Message Events configuration window. At the top, there's a title bar with 'M73 mx10-32-6-96 Message Events'. Below it is a table with columns 'Attribute', 'Value', and 'Explanation'. The 'IP Receive' attribute is set to '8000'. Below the table, there's a section for 'Events' with a list of events. The 'FFLPRME' event is selected and its configuration is shown in detail. The configuration includes fields for 'Event Dead Time' (5), 'Event Sensor Type' (MxMessageSystem), 'Message Name' (FFLPRME.custom.blacklist), 'Message Range' (Local), 'Filter Message Content' (JSON Comparison), and 'Filter Value' ('true').

3. Click on the event (e. g. FFLPRME) ^① to open the event settings.

4. Configure the parameters of the event profile as follows:

- **Message Name:** Enter the "Message Name" ^② according to the event documentation of the corresponding app (see [Examples for message names and filter values of the FF Group License Plate Recognition App - Region ME, p. 48](#))
- **Message Range:**
 - **Local:** Default settings for the FF Group License Plate Recognition App - Region ME
 - **Global:** (MxMessage is forwarded from another MOBOTIX camera in the local network.
- **Filter Message Content:**
 - **Generic Event:** "No Filter"
 - **Filtered Event:** "JSON Comparison"

Filter Value: [Examples for message names and filter values of the FF Group License Plate Recognition App - Region ME, p. 48.](#)

CAUTION! “Filter Value“ is used to differentiate the MxMessages of an app / bundle. Use this entry to benefit from individual event types of the apps (if available).

Choose “No Filter” if you want to use all incoming MxMessages as generic event of the related app.

2. Click on **Set**④ at the end of the dialog box to confirm the settings.

Examples for message names and filter values of the FF Group License Plate Recognition App - Region ME

FF Group License Plate Recognition App - Region ME	MxMessage Name	Filter Value
Generic Event	FFLPRME	
White list Event	FFLPRME.custom.whitelist	“true”
Black list Event	FFLPRME.custom.Black list	“true”
Not listed Event	FFLPRME.custom.notlisted	“true”
Unique license plate event	FFLPRME.plate.LicensePlate	License plate code as “STRING”, e.g. “2011909” (compare Meta data transferred within the MxMessageSystem , p. 45)
Incoming Vehicle Event	LPRAM.plate.Direction	“in”
Outgoing Vehicle Event	LPRAM.plate.Direction	“out”

MOBOTIX

BeyondHumanVision

[EN_02/24](#)

MOBOTIX AG • Kaiserstrasse • D-67722 Langmeil • Tel.: +49 6302 9816-103 • sales@mobotix.com • www.mobotix.com

MOBOTIX is a trademark of MOBOTIX AG registered in the European Union, the U.S.A., and in other countries. Subject to change without notice. MOBOTIX do not assume any liability for technical or editorial errors or omissions contained herein. All rights reserved. © MOBOTIX AG 2021