

Quick Installation

MOBOTIX VDS Thermal Camera

© 2023 MOBOTIX AG



Table of Contents

| | |
|-------------------------------------------------------|-----------|
| Table of Contents | 2 |
| Before You Start | 5 |
| Support | 6 |
| MOBOTIX Support | 6 |
| MOBOTIX eCampus | 6 |
| MOBOTIX Community | 6 |
| Safety Notes | 6 |
| Legal Notes | 7 |
| Intended Use | 9 |
| Tested Measurement Distances | 10 |
| VdS Certification/Firmware | 10 |
| System Overview | 10 |
| Delivered Parts and Dimensions | 11 |
| MOBOTIX VDS Thermal Camera: Scope of Delivery | 12 |
| Installation | 13 |
| Wiring Overview | 14 |
| Information on Installing the Components | 14 |
| M16B Thermal TR | 15 |
| MX-232-IO-Box | 15 |
| MX-NPA-Box | 15 |
| MX-Overvoltage-Protection-Box-LSA | 16 |
| Configuration | 17 |
| Prerequisites | 18 |
| Initial Camera Setup | 18 |
| Create VdS_Admis User Group | 19 |
| Add vds-admin User | 19 |
| Configure MxBus Interface | 20 |
| Configure Event Control | 21 |
| Adjusting the Configuration | 21 |
| Adjusting the Sensitivity of the Shock Detector Event | 22 |
| Adjusting the Thermal Event | 23 |

| | |
|----------------------------------------------------------------------------------|-----------|
| Technical Specifications | 25 |
| Product Information | 25 |
| Thermal Lenses/Sensors, 50 mK, 336 x 252 (Factory-Assembled) | 26 |
| Optical Lenses/Sensors, 6MP, 3072 x 2048 (Available With Optional Sensor Module) | 26 |
| Hardware | 27 |
| Image Formats, Frame Rates, Image Storage | 29 |
| General Functions | 30 |
| Video Analysis | 31 |
| Video Management Software | 31 |

Before You Start

This section contains the following information:

| | |
|---------------------------|----------|
| Support | 6 |
| MOBOTIX Support | 6 |
| MOBOTIX eCampus | 6 |
| MOBOTIX Community | 6 |
| Safety Notes | 6 |
| Legal Notes | 7 |

Support

MOBOTIX Support

If you need technical support, please contact your MOBOTIX dealer. If your dealer cannot help you, he will contact the support channel to get an answer for you as quickly as possible.

If you have internet access, you can open the MOBOTIX help desk to find additional information and software updates.

Please visit www.mobotix.com > **Support** > **Help Desk**.



MOBOTIX eCampus

The MOBOTIX eCampus is a complete e-learning platform. It lets you decide when and where you want to view and process your training seminar content. Simply open the site in your browser and select the desired training seminar.

Please visit www.mobotix.com/ecampus-mobotix.



MOBOTIX Community

The MOBOTIX community is another valuable source of information. MOBOTIX staff and other users are sharing their information, and so can you.

Please visit community.mobotix.com.



Safety Notes

- This camera must be installed by qualified personnel and the installation should conform to all local codes.

- This product must not be used in locations exposed to the dangers of explosion.
- Do not use this product in a dusty environment.
- Protect this product from moisture or water entering the housing.
- Install this product as outlined in this document. A faulty installation can damage the product!
- Do not replace batteries of the camera. If a battery is replaced by an incorrect type, the battery can explode.
- This equipment is not suitable for use in locations where children are likely to be present.
- External power supplies must comply with the Limited Power Source (LPS) requirements and share the same power specifications with the camera.
- When using a Class I adapter, the power cord shall be connected to a socket-outlet with proper ground connection.
- To comply with the requirements of EN 50130-4 regarding the power supply of alarm systems for 24/7 operation, it is highly recommended to use an uninterruptible power supply (UPS) for backing up the power supply of this product.

Legal Notes

Special Export Regulations!

Cameras with thermal image sensors ("thermal cameras") are subject to the special export regulations of the U.S.A. and including the ITAR (International Traffic in Arms Regulation):

- According to the currently applicable export regulations of the U.S.A. and the ITAR, cameras with thermal image sensors or parts thereof must not be exported to countries embargoed by the U.S.A., except if a special permit can be presented. At present, this applies to the following countries: Crimea region of Ukraine, Cuba, Iran, North Korea, Sudan, and Syria. The same export ban applies to all persons and institutions listed in "The Denied Persons List" (see www.bis.doc.gov, "Policy Guidance > Lists of Parties of Concern"; <https://www.treasury.gov/resource-center/sanctions/tdn-list/pages/default.aspx>).
- Under no circumstances must the camera itself or its thermal image sensors be used in the design, the development or in the production of nuclear, biological or chemical weapons or in the weapons themselves.

Legal Aspects of Video and Sound Recording

You must comply with all data protection regulations for video and sound monitoring when using MOBOTIX AG products. Depending on national laws and the installation location of the cameras, the recording of video

and sound data may be subject to special documentation or it may be prohibited. All users of MOBOTIX products are therefore required to familiarize themselves with all applicable regulations and to comply with these laws. MOBOTIX AG is not liable for any illegal use of its products.

Declaration of Conformity

The products of MOBOTIX AG are certified according to the applicable regulations of the EC and other countries. You can find the declarations of conformity for the products of MOBOTIX AG on www.mobotix.com under **Support > Download Center > Marketing & Documentation > Certificates & Declarations of Conformity**.

RoHS Declaration

The products of MOBOTIX AG are in full compliance with European Unions Restrictions of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment (RoHS Directive 2011/65/EC) as far as they are subject to these regulations (for the RoHS Declaration of MOBOTIX, please see www.mobotix.com, **Support > Download Center > Marketing & Documentation > Brochures & Guides > Certificates**).

Disposal

Electrical and electronic products contain many valuable materials. For this reason, we recommend that you dispose of MOBOTIX products at the end of their service life in accordance with all legal requirements and regulations (or deposit these products at a municipal collection center). MOBOTIX products must not be disposed of in household waste! If the product contains a battery, please dispose of the battery separately (the corresponding product manuals contain specific directions if the product contains a battery).

Disclaimer

MOBOTIX AG does not assume any responsibility for damages, which are the result of improper use or failure to comply to the manuals or the applicable rules and regulations. Our General Terms and Conditions apply. You can download the current version of the **General Terms and Conditions** from our website at www.mobotix.com by clicking on the corresponding link at the bottom of every page.

Intended Use

The MOBOTIX VDS Thermal Camera Mx-M16TB-Rxxx-VdS is intended for use in environments with increased fire risk. It can be used, for example, in waste management to discover possible sources of fire at an early stage by detecting critical temperature thresholds and reporting them to the fire alarm system in use.

NOTE!

- The tested and approved temperature measurement range is between 50°C and 200°C/122°F and 392°F.
- The temperature events trigger when one pixel exceeds the threshold.
- The system must be operated with a power supply recognized according to DIN EN 54-4.
- A pan-tilt unit and an optional optical sensor module are not part of the VdS approval.

Tested Measurement Distances


| Camera Type | Field of View (HxV) | Distance |
|----------------|---------------------|-------------|
| M16TB-R079-VdS | 45°x32° | 40 m/132 ft |
| M16TB-R119-VdS | 25°x19° | 50 m/164 ft |
| M16TB-R237-VdS | 17°x13° | 60 m/197 ft |

VdS Certification/Firmware

This product has the VdS certification number **G 222015**; the camera firmware must be **MX-V5.4.0.49-VdS**.

NOTE! Only a person who has successfully completed the MOBOTIX **VdS Early Fire Detection** certification training is allowed to make configuration changes!

System Overview



Delivered Parts and Dimensions

This section contains the following information:

| | |
|------------------------------------------------------------|-----------|
| MOBOTIX VDS Thermal Camera: Scope of Delivery | 12 |
|------------------------------------------------------------|-----------|

MOBOTIX VDS Thermal Camera: Scope of Delivery



Scope of delivery MOBOTIX VDS Thermal Camera

| Item | Count | Description |
|------|-------|-----------------------------------|
| 1.1 | 1 | Mx-M16TB-Rxxx-VdS |
| 1.2 | 1 | MX-232-IO-Box |
| 1.3 | 1 | MX-NPA-Box |
| 1.4 | 1 | MX-Overvoltage-Protection-Box-LSA |

Installation

This section contains the following information:

| | |
|-------------------------------------------------------|-----------|
| Wiring Overview | 14 |
| Information on Installing the Components | 14 |
| M16B Thermal TR | 15 |
| MX-232-IO-Box | 15 |
| MX-NPA-Box | 15 |
| MX-Overvoltage-Protection-Box-LSA | 16 |

Wiring Overview




Fig. 1: Wiring of the MOBOTIX VDS Thermal Camera system

NOTE!

- The cable between the MOBOTIX VDS Thermal Camera and the MX-Overvoltage-Protection-Box must not exceed 0.5 m. It is recommended to install the MX-Overvoltage-Protection-Box in the wall arm of the camera.
- For MxBus wiring, use a cable of type J-Y(ST)Y with $2 \times 2 \times 0.8 \text{ mm}^2$. The maximum length for the MxBus cable is 100 m/110 yd.
- For alarm and fault output, use cables of type J-Y(ST)Y with $2 \times 2 \times 0.8 \text{ mm}^2$. The maximum length for these cables is 3 m/10 ft.
- The battery-backed power supply (not included) must comply with EN54-4.

Information on Installing the Components

For more information on installing the individual components of the MOBOTIX VDS Thermal Camera system, please refer to the documents listed below.

M16B Thermal TR

| Quick Installation | Manual | Technical Specifications |
|-----------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------|
|  |  |  |

MX-232-IO-Box

| Quick Installation/Technical Specifications |
|------------------------------------------------------------------------------------|
|  |

MX-NPA-Box

| Quick Installation/Technical Specifications |
|-------------------------------------------------------------------------------------|
|  |

MX-Overvoltage-Protection-Box-LSA

Quick Installation/Technical Specifications



Configuration

This section contains the following information:

| | |
|-------------------------------------------------------|-----------|
| Prerequisites | 18 |
| Initial Camera Setup | 18 |
| Create VdS_Admns User Group | 19 |
| Add vds-admin User | 19 |
| Configure MxBus Interface | 20 |
| Configure Event Control | 21 |
| Adjusting the Configuration | 21 |
| Adjusting the Sensitivity of the Shock Detector Event | 22 |
| Adjusting the Thermal Event | 23 |

Prerequisites

Before you start using the camera, please make sure that the following conditions are met:

- The camera is a MOBOTIX VDS Thermal Camera with the order code **Mx-M16TB-Rxxx-VdS**.
- The camera is running the VdS-approved firmware **MX-V5.4.0.49-VdS**.
- When using an M16B Thermal TR camera purchased previously that it is running the VdS-approved firmware **MX-V5.4.0.49-VdS**.
- A person who has successfully completed the MOBOTIX **VdS Early Fire Detection** certification training.

NOTE! Only a person who has successfully completed the MOBOTIX **VdS Early Fire Detection** certification training is allowed to make configuration changes!

Initial Camera Setup

- Start your web browser.
- Enter the IP address of your camera. This can be found on the label of the camera as well as on the shipping box.
- You will be prompted to set a password for the admin user of the camera. Make sure you keep the password in a safe place.




Fig. 2: Setting the new *admin* password

Create VdS_Admins User Group

- Open the **Admin Menu** of the camera.
- In the **Group Access Control Lists** dialog, create a group named `VdS_Admins` with these rights:
 - **Browser Screen / View:**
 - Live
 - **Configuration:**
 - Admin
 - Image Setup
 - Event Setup

| Access Rights | Browser Screen / View | | | | MxMC & VMS | | Configuration | | | Remove Group |
|---------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-------------------------------------|-----------------------------|
| | Guest | Live | Player | MultiView | Event Stream | HTTP API | Admin | Image Setup | Event Setup | |
| Public Access | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | Disable all |
| Groups | | | | | | | | | | |
| admins | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| es_admins | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| es_guests | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| es_users | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| www_guests | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| www_users | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |
| VdS_Admins | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input checked="" type="checkbox"/> | <input type="checkbox"/> |

Open [Users and Passwords](#) to manage users and to assign groups.

Set Factory Restore Close More

Fig. 3: Creating the `VdS_Admins` group

- Click on **Set**, then on **Close** and permanently save the settings.

Add vds-admin User

NOTE! Only a person who has successfully completed the MOBOTIX **VdS Early Fire Detection** certification training is allowed to make configuration changes!

Configuration

Configure MxBus Interface

- Open the **Admin Menu** of the camera.
- In the **Users and Passwords** dialog, create a user named `vds-admin` and set a password (see the **Users and Passwords** help topic for password requirements).

| User | Group | Password | Confirm Password | Remark/Action |
|-----------|------------|----------|------------------|---------------------------------|
| admin | admins | *** | *** | <input type="checkbox"/> Remove |
| vds-admin | Vds_Admins | ***** | ***** | <input type="checkbox"/> Remove |
| | undefined | | | |

Scheduled access control by

Supervisor: ☐ Activated

Super PIN (8 to 16 digits):

Open [Group Access Control Lists](#) to manage the group definitions and to set the group access rights.

Caution! Make sure to store user names and passwords in a safe place.
There is absolutely no back door into the camera without the administrator's login.
Passwords have changed!
If you are prompted for a password, remember to enter the new password.

Fig. 4: Creating the `vds-admin` user

- Click on **Set**, then on **Close** and permanently save the settings.

Configure MxBus Interface

- Open the **Admin Menu** of the camera.
- In the **Manage MxBus Modules** dialog, activate the connected MX-232-IO-Box.
- Check **Use in Classic Mode**, switch **Line Termination** to **On** and click on **Activate**. The LEDs of the MX-232-IO-Box light up green and blue.

MxBus-Schnittstelle

Schnittstelle: Wählen Sie diese Option, um MxBus-Module über die MxBus-Schnittstelle anzubinden.

Status: [Neue Geräte verfügbar](#) MxBus-Statusprotokoll öffnen.

Service-Funktionen

Nachrichtenkonfiguration für nachrichtenfähige Module erzeugen.

Backup und Wiederherstellung der Konfiguration für jedes MxBus-Modul separat durchführen.

MxBus-Module auf Werkseinstellungen zurücksetzen.

Die Modul-Software ist kompatibel mit der Kamera-Software.

Gerät

| Gerätetyp | Seriennummer | SW Version | HW Version | Verwenden im Classic-Modus | Status Details |
|---------------|--------------|------------|------------|-------------------------------------|----------------|
| MX-232-IO-Box | 7275061 | 1.0.2.21 | 1.3 | <input checked="" type="checkbox"/> | Adressierbar |

Leitungsabschluss:

Fig. 5: Activating the MxBus interface

- Click on **Set**, then on **Close** and permanently save the settings.

Configure Event Control

The MOBOTIX VDS Thermal Camera contains preconfigured events and action groups that are required for proper system operation.

Preconfigured events

- Shock Detector: For reporting possible manipulation of the camera.
- Thermal Event: To detect and report the exceeding of a critical temperature threshold.
- Fault Message Input: To report a fault in the VdS Thermal System.
- User Click: For acknowledging events.

The preset action groups **Stoerung**, **Thermal Event** and **Quittierung** trigger various messages via the assigned outputs and/or by means of internal camera action types.

Adjusting the Configuration

The individual events of the MOBOTIX VDS Thermal Camera can be adapted to the conditions of your installation using the following steps.

- Open the camera's web interface in your browser using the IP address you have set.
- Open the **Setup Menu** of the camera.

- Edit the individual events in **Event Control > Event Overview**.




Fig. 6: Event overview in the Setup Menu

Adjusting the Sensitivity of the Shock Detector Event

The sensitivity can be adjusted using the dropdown list. Lower values trigger earlier. Test the trigger sensitivity on-site based on the conditions and requirements of the installation.




Fig. 7: Configuring the Shock Detector event

Adjusting the Thermal Event

You can adjust the **Thermal Event** of the camera to the on-site conditions as follows:

- Unfold the corresponding event.
- To edit the measurement area, use **Shift-click** in the live image of the camera to define a rectangle around the area you want to measure.




Fig. 8: Editing the measurement area

- In the **Thermal Event** dialog, click **Insert Rectangle** to define the area.
- Click on **Set** to save the settings.

- To change the trigger level of the event, enter the desired temperature value in the dialog and click on **Set**.

| | |
|------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Temperaturwert ▼ | Alarmtyp: Wählen Sie den Alarmtyp aus. |
| °C ▼ | Temperatur-Einheit: Einheit für den Schwellwert. |
| 80 | Temperaturwert: Geben Sie den Temperaturwert ein [-40..550 °C] [-40..1022 °F]. |
| Größer als ▼ | Vergleich: <ul style="list-style-type: none">• <i>Größer als:</i> Löst ein Ereignis aus, wenn die Temperatur im Messbereich diesen Wert überschreitet.• <i>Kleiner als:</i> Löst ein Ereignis aus, wenn die Temperatur im Messbereich diesen Wert unterschreitet. <p>Abhängig vom ausgewählten Messmodus ist die in 'Temperaturwert' festgelegte Temperatur entweder eine absolute Temperatur oder die Durchschnittstemperatur in einem definierten Referenzbereich.</p> |

Fig. 9: Adjusting the trigger level of the Thermal Event

- Click on **Set**, then on **Close** and permanently save the settings.

For more general settings of the camera, please refer to the general [M16 Camera Manual](#).



Technical Specifications

Product Information

| | |
|---------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Specialties | Thermographic IP camera with Thermal Radiometry technology (TR) and Germanium lens; can be optionally equipped with a second optical 6MP sensor module (day/-color or night/black and white to be ordered separately for easy self-assembly) |
| Area of Application | TR temperature measurement of each pixel in the whole image area, up to 20 independent temperature events |

Thermal Lenses/Sensors, 50 mK, 336 x 252 (Factory-Assembled)

| | |
|----------------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| Calibrated Thermal sensor | Mx-M16TB-R075 |
| TR/Thermal Radiometry, horiz./vert. image angle 42°/32° & 45°/35° | Mx-M16TB-R079 |
| Calibrated Thermal sensor | Mx-M16TB-R090 |
| TR/Thermal Radiometry, horiz./vert. image angle 35°/27° & 25°/19° | Mx-M16TB-R119 |
| Calibrated Thermal sensor | Mx-M16TB-R237 |
| TR/Thermal Radiometry, horiz./vert. image angle 17°/13° | |
| Thermal image sensor | Uncooled microbolometer, 336 x 252 pixels, Pixel Pitch 17 µm, IR range 7,5 to 13,5 µm |
| Sensitivity NETD (thermal resolution) | Typ. 50 mK, < 79 mK (50 mK is equal to temperature changes of 0,05°C) |
| Thermal image representation | False colors or black and white |
| Temperature measuring range (adjustable) | High Sensitivity: -40 to 170°C/-40 to 320°F – Low Sensitivity: -40 to 550°C/-40 to 1022°F |
| Temperature measuring method (via camera) | Complete image areas (customizable temperature measurement windows) |

Optical Lenses/Sensors, 6MP, 3072 x 2048 (Available With Optional Sensor Module)

| | |
|----------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| Sensor module with Fisheye Lens B016 (180° x 180°), night version optionally with long-pass filter (LPF) | Day/Color: Mx-O-SMA-S-6D016 Night/Black&White: Mx-O-SMA-S-6N016 LPF/Black&White: Mx-O-SMA-S-6L016 |
| Sensor module with Ultra Wide Lens B036 (103° x 77°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D036 Night/Black&White: Mx-O-SMA-S-6N036 LPF/Black&White: Mx-O-SMA-S-6L036 |

| | |
|------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------|
| Sensor module with Super Wide Lens B041 (90° x 67°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D041 Night/Black&White: Mx-O-SMA-S-6N041 LPF/Black&White: Mx-O-SMA-S-6L041 |
| Sensor module with Wide Lens B061 (60° x 45°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D061 Night/Black&White: Mx-O-SMA-S-6N061 LPF/Black&White: Mx-O-SMA-S-6L061 |
| Sensor module with Standard Lens B079 (45° x 34°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D079 Night/Black&White: Mx-O-SMA-S-6N079 LPF/Black&White: Mx-O-SMA-S-6L079 |
| Sensor module with Tele Lens B119 (31° x 23°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D119 Night/Black&White: Mx-O-SMA-S-6N119 LPF/Black&White: Mx-O-SMA-S-6L119 |
| Sensor module with Distant Tele Lens B237 (15° x 11°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D237 Night/Black&White: Mx-O-SMA-S-6N237 LPF/Black&White: Mx-O-SMA-S-6L237 |
| Sensor module with Super Tele Lens B500 (8° x 6°), night version optionally with LPF | Day/Color: Mx-O-SMA-S-6D500 Night/Black&White: Mx-O-SMA-S-6N500 LPF/Black&White: Mx-O-SMA-S-6L500 |
| Sensor module with CS-Mount (no lens included) | Day/Color: Mx-O-SMA-S-6DCS Night/Black&White: Mx-O-SMA-S-6NCS |
| Sensor module with CSVario Lens B045-100-CS | Day/Color: Mx-O-SMA-S-6DCSV Night/Black&White: Mx-O-SMA-S-6NCSV |
| Image sensor with individual exposure zones | 1/1.8" CMOS, 6MP (3072 x 2048), Progressive Scan Color or Black And White |
| Light sensitivity in lux at 1/60 s and 1/1 s | Color Sensor: 0,1/0,005 Black And White Sensor: 0,02/0,001 |

Hardware

| | |
|----------------------|---------------------------------------------------------------------|
| Microprocessor | iMX 6 Dual Core incl. GPU (1 GB RAM, 512 MB Flash) |
| H.264 Hardware-Codec | Yes, bandwidth limitation available; output image format up to QXGA |

Technical Specifications

Hardware

| | |
|--------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Protection class | IP66 and IK06; with second 6MP sensor module: IK04 with B036 to B237, IK06 with B016 |
| Intended use | Not for use in hazardous areas (Ex area); no mounting behind glass windows |
| Ambient temperature (range, incl. storage) | -40 to 60°C/-40 to 140°F (cold boot from -30°C/-22°F) |
| Internal DVR, ex works | 4 GB (microSD) |
| Microphone/speaker | Microphone Sensitivity: -35 +/-4 dB (0 dB = 1 V/pa, 1 kHz) Speaker: 0.9 W at 8 Ohm |
| 16bit/16kHz HD wideband audio (Opus codec) | Yes (live and audio messages) |
| Passive infrared sensor (PIR) | Yes |
| Temperature sensor | Yes |
| Shock detector (tamper detection) | Yes |
| Power consumption (typically at 20°C/68°F) | 9 W (10 W possible over the short term) |
| PoE class (IEEE 802.3af) | Class 2 or 3 (variable), factory setting: class 3 (required for thermal operation) |
| Interfaces Ethernet 100BaseT/MxBus/USB | Yes (MxRJ45)/Yes/Yes |
| Interface RS232 | With accessory (MX-232-IO-Box) |
| Mounting options | Wall, pole or ceiling (wall and ceiling mount included) |
| Dimensions (height x width x depth) | With wall mount bracket (default): 244 x 158 x 239 mm With ceiling mount bracket (optional accessory MX-DH-M24-SecureFlex): 210 x 158 x 207 mm |
| Weight | 1,320 g |
| Housing | PBT-30GF, color: white |
| Standard accessory | Screws, dowels, screw caps, 2 Allen wrenches, module key, VarioFlex wall and ceiling mount with rubber sealing, 0.5 m ethernet patch cable, 1 blind module, Quick Install |
| Detailed technical documentation | www.mobotix.com > Support > Download Center |
| Online version of this document | www.mobotix.com > Support > Download Center |

| | |
|------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| MTBF | > 80,000 hours |
| Certifications | EN55032:2012 EN55022:2010; EN55024:2010 EN61000-6-1:2007; EN 61000-6-2:2005 EN61000-6-3:2007+A1:2011 EN61000-6-4:2007+A1:2011 AS/ NZS CISPR22:2009+A1:2010 CFR47 FCC part15B |
| Protocols | IPv4, IPv6, HTTP, HTTPS, FTP, FTPS, SFTP, RTP, RTSP, UDP, SNMP, SMTP, DHCP (client and server), NTP (client and server), SIP (client and server) G.711 (PCMA and PCMU) and G.722 |
| Manufacturer's warranty (since May 2018) | 5 years |

Image Formats, Frame Rates, Image Storage

| | |
|-----------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Available video codecs | MxPEG/MJPEG/H.264 |
| Image formats | Freely configurable format 4:3, 8:3, 16:9 or customized format (Image Cropping), such as 2592x1944 (5MP), 2048x1536 (QXGA), 1920x1080 (Full-HD), 1280x960 (MEGA) |
| Multistreaming | Yes |
| Multicast stream via RTSP | Yes |
| Max. image format (dual image from both sensors) | 2x 6MP (6144 x 2048) |
| Max. frame rate for thermal images, Thermal Overlay and dual images (thermal & optical) | 9 frames per second (fps) |
| Max. frame rate for optional optical 6MP sensor module (fps, only single core used) | MxPEG: 42@HD(1280x720), 34@Full-HD, 24@QXGA, 15@5MP, 12@6MP, 6@2x 6MP MJPEG: 26@HD(1280x720), 13@Full-HD, 9@QXGA, 5@5MP, 4@6MP, 2@2x 6MP H.264: 25@Full-HD, 20@QXGA |
| Number of images with 4 GB microSD (internal DVR) | CIF: 250,000, VGA: 125,000, HD: 40,000, QXGA: 20,000, 6MP: 10,000 |

General Functions

| | |
|------------------------------------------------------------------------------------------|-----------------------------------------------------------------------|
| TR temperature measurement in the whole image area | Yes |
| Event trigger for temperatures above or below a limit between -40 to 550°C/-40 to 1022°F | Yes |
| Digital zoom and pan | Yes |
| ONVIF compatibility | Yes (Profile S, audio support with camera firmware V5.2.x and higher) |
| Genetec protocol integration | Yes |
| Programmable exposure zones | Yes |
| Snapshot recording (pre/post-alarm images) | Yes |
| Continuous recording with audio | Yes |
| Event recording with audio | Yes |
| Time controlled flexible event logic | Yes |
| Weekly schedules for recordings and actions | Yes |
| Event video and image transfer via FTP and email | Yes |
| Playback and QuadView via web browser | Yes |
| Bidirectional audio in browser | Yes |
| Animated logos on the image | Yes |
| Master/Slave functionality | Yes |
| Privacy zone scheduling | Yes |
| Customized voice messages | Yes |
| VoIP telephony (audio/video, alert) | Yes |
| Remote alarm notification (network message) | Yes |
| Programming interface (HTTP-API) | Yes |

| | |
|---------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| DVR/Storage Management | Inside camera via microSD card, externally via USB device and NAS, different streams for live image and recording, MxFFS with archive function, pre-alarm and post-alarm images, monitoring recording with failure reporting |
| Camera and data security | User and group management, SSL connections, IP-based access control, IEEE802.1x, intrusion detection, digital image signature |
| MxMessageSystem: Sending and receiving of MxMessages | Yes |

Video Analysis

| | |
|-----------------------|-----|
| Video motion detector | Yes |
| MxActivitySensor | Yes |

Video Management Software

| | |
|--------------------|-----|
| MxManagementCenter | Yes |
| Mobile MOBOTIX App | Yes |



[EN_11/23](#)

MOBOTIX AG • Kaiserstrasse • D-67722 Langmeil • Tel.: +49 6302 9816-103 • sales@mobotix.com • www.mobotix.com

MOBOTIX is a trademark of MOBOTIX AG registered in the European Union, the U.S.A., and in other countries. Subject to change without notice. MOBOTIX do not assume any liability for technical or editorial errors or omissions contained herein. All rights reserved. © MOBOTIX AG 2021